

Industrial Automation Headquarters

Delta Electronics, Inc. Taoyuan Technology Center No.18, Xinglong Rd., Taoyuan District, Taoyuan City 33068, Taiwan TEL: 886-3-362-6301 / FAX: 886-3-371-6301

Asia

Delta Electronics (Shanghai) Co., Ltd. No.182 Minyu Rd., Pudong Shanghai, P.R.C. Post code : 201209 TEL: 86-21-6872-3988 / FAX: 86-21-6872-3996 Customer Service: 400-820-9595

Delta Electronics (Japan), Inc.

Tokvo Office Industrial Automation Sales Department 2-1-14 Shibadaimon, Minato-ku Tokyo, Japan 105-0012 TEL: 81-3-5733-1155 / FAX: 81-3-5733-1255

Delta Electronics (Korea), Inc.

Seoul Office 1511, 219, Gasan Digital 1-Ro., Geumcheon-gu, Seoul. 08501 South Korea TEL: 82-2-515-5305 / FAX: 82-2-515-5302

Delta Energy Systems (Singapore) Pte Ltd. 4 Kaki Bukit Avenue 1, #05-04, Singapore 417939

TEL: 65-6747-5155 / FAX: 65-6744-9228

Delta Electronics (India) Pvt. Ltd.

Plot No.43, Sector 35, HSIIDC Gurgaon, PIN 122001, Haryana, India TEL: 91-124-4874900 / FAX : 91-124-4874945

Delta Electronics (Thailand) PCL.

909 Soi 9, Moo 4, Bangpoo Industrial Estate (E.P.Z), Pattana 1 Rd., T.Phraksa, A.Muang, Samutprakarn 10280, Thailand TEL: 66-2709-2800 / FAX : 662-709-2827

Delta Energy Systems (Australia) Pty Ltd.

Unit 20-21/45 Normanby Rd., Notting Hill Vic 3168, Australia TEL: 61-3-9543-3720

Americas

Delta Electronics (Americas) Ltd. Raleigh Office P.O. Box 12173, 5101 Davis Drive, Research Triangle Park, NC 27709, U.S.A. TEL: 1-919-767-3813 / FAX: 1-919-767-3969

Delta Greentech (Brasil) S/A

São Paulo Office Rua Itapeva, 26 – 3° Andar - Bela Vista CEP: 01332-000 - São Paulo - SP - Brasil TEL: 55-11-3530-8642 / 55-11-3530-8640

Delta Electronics International Mexico S.A. de C.V. Mexico Office

Vía Dr. Gustavo Baz No. 2160. Colonia La Loma. 54060 Tlalnepantla Estado de Mexico TEL: 52-55-2628-3015 #3050/3052

EMEA

Headquarters: Delta Electronics (Netherlands) B.V.

Sales: Sales.IA.EMEA@deltaww.com Marketing: Marketing.IA.EMEA@deltaww.com Technical Support: iatechnicalsupport@deltaww.com Customer Support: Customer-Support@deltaww.com Service: Service.IA.emea@deltaww.com TEL: +31(0)40 800 3800

BENELUX: Delta Electronics (Netherlands) B.V.

De Witbogt 20, 5652 AG Eindhoven, The Netherlands Mail: Sales.IA.Benelux@deltaww.com TEL: +31(0)40 800 3800

DACH: Delta Electronics (Netherlands) B.V. Coesterweg 45, D-59494 Soest, Germany

Mail: Sales.IA.DACH@deltaww.com TEL: +49(0)2921 987 0

France: Delta Electronics (France) S.A.

ZI du bois Challand 2, 15 rue des Pyrénées, Lisses, 91090 Evry Cedex, France Mail: Sales.IA.FR@deltaww.com TEL: +33(0)1 69 77 82 60

Iberia: Delta Electronics Solutions (Spain) S.L.U Ctra. De Villaverde a Vallecas, 265 1º Dcha Ed. Hormigueras – P.I. de Vallecas 28031 Madrid

TEL: +34(0)91 223 74 20 C/Llull, 321-329 (Edifici CINC) | 22@Barcelona, 08019 Barcelona Mail: Sales.IA.Iberia@deltaww.com TEL: +34 93 303 00 60

Italy: Delta Electronics (Italy) S.r.l.

Ufficio di Milano Via Senigallia 18/2 20161 Milano (MI) Piazza Grazioli 18 00186 Roma Italy Mail: Sales.IA.Italy@deltaww.com TEL: +39 02 64672538

Russia: Delta Energy System LLC

Vereyskaya Plaza II, office 112 Vereyskaya str. 17 121357 Moscow Russia Mail: Sales.IA.RU@deltaww.com TEL: +7 495 644 3240

Turkey: Delta Greentech Elektronik San. Ltd. Sti. (Turkey)

Serifali Mah. Hendem Cad. Kule Sok. No:16-A 34775 Ümraniye - İstanbul Mail: Sales.IA.Turkey@deltaww.com TEL: + 90 216 499 9910

GCC: Delta Energy Systems AG (Dubai BR)

P.O. Box 185668, Gate 7, 3rd Floor, Hamarain Centre Dubai, United Arab Emirates Mail: Sales.IA.MEA@deltaww.com TEL: +971(0)4 2690148

Egypt + North Africa: Delta Electronics

511 Cairo Business Plaza, North 90 street, New Cairo, Cairo, Egypt Mail: Sales.IA.MEA@deltaww.com



Managed Industrial GbE **DIN-Rail Ethernet Switch DVS-G100** Series User Manual

DVS-G106 | DVS-G112 | DVS-G116



DVS Managed Industrial

GbE DIN-Rail Ethernet Switch User Manual Table of Contents

Chapter 1 Introduction

1.1	Product Overview1-3
1.1.	1 High Performance Network Technology1-3
1.1.	2 Industrial Grade Reliability1-3
1.1.	3 Robust Design
1.1.	4 Dimensions(mm) & Product Profile1-4
1.1.	5 LED Indicators 1-7
1.2	Installation1-8
1.2.	1 DIN-Rail Mounting1-8
1.2.	2 Wall-Mounting1-9
1.2.	3 SFP installation 1-9
1.2.	4 Wiring the Redundant Power Input 1-10
1.2.	5 Wiring the Alarm Contact 1-11
1.2.	6 Wiring the Digital Input 1-11
1.3	Package Checklist 1-12
1.4	MTBF (Mean Time Between Failures) 1-12

Chapter 2 User Interface Introduction

2.1	RJ45 Console Configuration	2-2
2.2	Telnet Console Configuration	2-4
2.3	Web Browser Configuration	2-5

Chapter 3 Featured Functions

3.1	Basi	c Setting	3-5
3.1.7	1	System Information	3-5
3.1.2	2	Network Interface	3-6

3.1.2.1	IPv4 Network Configuration	
3.1.2.2	IPv6 Network Configuration	3-7
3.1.2.3	IPv6 Network Neighbor	
3.1.3 Port	Setting	
3.1.3.1	Port Settings	3-9
3.1.3.2	LAG Settings	3-10
3.1.4 Tim	e	3-10
3.1.4.1	SNTP Scalars Configuration	3-11
3.1.4.2	SNTP Unicast Server Configuration	3-12
3.1.5 DH0	CP/BOOTP Settings	3-12
3.1.5.1	DHCP Server	3-12
3.1.5.2	DHCP Relay	3-17
3.1.5.3	DHCP L2 Relay	3-19
3.1.6 DNS	5	3-22
3.1.6.1	DNS Configuration	3-22
3.1.6.2	Host Configuration	3-23
3.1.7 Sys	tem File Update	3-24
3.1.7.1	Download File	3-24
3.1.7.2	Upload File	3-25
3.1.8 Mar	nagement Access	3-27
3.1.8.1	HTTP Configuration	3-27
3.1.8.2	HTTPS	3-28
3.1.8.3	SSH Configuration	3-30
3.1.8.4	Telnet Configuration	3-31
3.1.8.5	Console Port	3-32
3.1.9 Loo	pback-Detection	3-32
3.1.9.1	Global Configuration	3-32
3.1.9.2	Port Configuration	3-32
3.1.10 Eth	erNet/IP	3-33
3.2 SNMP M	anager	3-34
3.2 SNM	/P v1/v2c	3-34
3 2 1 1	Community Configuration	3-34
3 2 1 2	Tran Configuration	3-35
3 2 1 3	Tran Flags	3-36
322 SNIA	лар науз	3-30 2_27
3.2.2 310	User Configuration	3_37
0.2.2.1		
3.3 Network	Redundancy	3-38

3.3.	1	STP		3-38
	3.3.	1.1	STP Configuration	3-42
	3.3.	1.2	CST Configuration	3-43
	3.3.	1.3	CST Port Configuration	3-46
	3.3.	1.4	CST Port Status	3-48
	3.3.	1.5	MST Configuration	3-50
	3.3.	1.6	MST Port Status	3-51
	3.3.	1.7	STP Statistics	3-53
3.3.	2	Redu	undancy	3-54
	3.3.	2.1	ONE RING Configuration	3-54
	3.3.	2.2	ONE CHAIN Configuration	3-55
	3.3.	2.3	ONE COUPLING Configuration	3-55
	3.3.	2.4	Redundancy Cruiser	3-56
3.3.	3	Redu	undancy Application Setting	3-58
3.4	Virtu	ial LA	ANs	3-64
3.4.	1	VLA	N Mode Configuration	3-65
3.4.	2	VLA	N Configuration	3-65
3.4.	3	VLA	N Membership	3-66
3.4.	4	VLA	N Status	3-67
3.4.	5	Port	PVID Configuration	3-67
3.4.	6	GVR	P Configuration	3-68
3.4.	7	QinC	2 VLAN Configuration	3-69
3.4.	8	MAC	Based VLAN	3-70
3.4.	9	IP S	ubnet Based VLAN	3-71
3.5	Multi	icast	Filtering	3-71
3.5.	1	IGM	P Snooping Configuration	3-73
3.5.	2	IGM	P VLAN Configuration	3-74
3.5.	3	IGM	P Snooping Multicast Forwarding Table	3-74
3.5.	4	Mult	icast MAC Address Configuration	3-75
3.5.	5	GMR	P Configuration	3-75
3.5.	6	Mult	icast Forwarding Table	3-76
3.6	Traff	ic Pri	ioritization	3-77
3.6.	1	QoS		3-77
	3.6.	1.1	QoS Setting	3-77
	3.6.	1.2	CoS Queue Mapping	3-78
	3.6.	1.3	DSCP Queue Mapping	3-78

3	3.7	Traffic (Control	. 3-80
	3.7.	1 Poi	rt Isolation Configuration	. 3-80
-	2 0	Dort Ra	ndwidth	2 01
	3 Q	1 Sta		2-81
	5.0.	2 8 1 1	Storm Control Setting	2-81
		2 9 1 2	Pato Limiting	2 92
		5.0.1.2		. 5-02
3	3.9	Port Tru	Inking	. 3-82
	3.9.	1 LA	G	. 3-83
		3.9.1.1	LAG Membership	. 3-83
		3.9.1.2	LAG Information	. 3-84
3	3.10	Access	Control List	. 3-84
	3.10	D.1 MA	AC ACL	. 3-84
		3.10.1.	1 MAC Rules	. 3-85
		3.10.1.	2 MAC Binding Configuration	. 3-87
		3.10.1.	3 MAC Binding Table	. 3-88
3	3.10.2	AR	P ACL	. 3-88
		3.10.2.	1 ARP Rules	. 3-89
		3.10.2.	2 ARP Binding Configuration	. 3-90
		3.10.2.	3 ARP Binding Table	. 3-91
3	3.11	Security	y Settings	. 3-91
	3.11	l.1 Se	curity	. 3-91
		3.11.1.	1 Port Security	. 3-91
		3.11.1.	2 IP Source	. 3-93
		3.11.1.	3 802.1X	. 3-94
	3.11	l.2 Ma	inagement Security	. 3-99
		3.11.2.	1 Local Users Management	. 3-99
		3.11.2.	2 RADIUS Server Config	3-100
		3.11.2.	3 RADIUS Statistics	3-101
		3.11.2.	4 TACACS+ Server	3-102
		3.11.2.	5 TACACS+ AS	3-102
		3.11.2.	6 Login Authentication	3-103
		3.11.2.	7 Login User Sessions	3-103
	3.11	I.3 De	nial of Service	3-104
-	3 12	Monitor	ina Settinas	3-104
•	3 12	λιστητοί 2 1 ΜΔ	AC Address Table	3-105
	3 12))) SF	P DDM (Only for SEP Module)	3-106
	5.12			5 100

3.12	.3	System CPU Status	3-106
3.12	.4	Interface Statistics	3-107
3.12	.5	ARP Configure	3-107
	3.12	2.5.1 Basic	3-107
3.12	.6	RMON	3-108
	3.12	2.6.1 Basic Settings	3-108
	3.12	2.6.2 Alarms	3-108
	3.12	2.6.3 Events	3-109
	3.12	2.6.4 Event Log	3-110
	3.12	2.6.5 History	3-110
	3.12	2.6.6 RMON Ethernet Statistics	3-111
	3.12	2.6.7 Ethernet History Statistics	3-113
3.12	.7	SYSLOG	3-115
	3.12	2.7.1 Show Logs	3-115
	3.12	2.7.2 Logs Configuration	3-115
	3.12	2.7.3 Syslog Fwd Table	3-117
	3.12	2.7.4 Syslog Email Configuration	3-118
	3.12	2.7.5 Syslog Email Alarm Table	3-118
3.13	Diad	anostic Settings	3-120
3.13	.1	LLDP	3-120
	3.13	3.1.1 LLDP Basic Settings	3-120
	3.13	3.1.2 LLDP Interface Configuration	3-121
	3.13	3.1.3 LLDP TLV Options	3-122
	3.13	3.1.4 LLDP Local Information	3-123
	3.13	3.1.5 LLDP Neighbor Information	3-124
	3.13	3.1.6 LLDP Traffic	3-126
	3.13	3.1.7 LLDP-MED Global Configuration	3-126
	3.13	3.1.8 LLDP-MED Interface Configuration	3-127
3.13	.2	Port Mirroring	3-128
	3.13	3.2.1 Multiple Port Mirroring	3-128
3.14	Auto	o Warning	3-129
3.14	.1	Relay Alarm	3-129
	3.14	4.1.1 Relay Alarm Setting	3-129
	3.14	4.1.2 Relay Alarm Table	3-132
2 15	Due	Limago	2 122
2 15	ud 1	Conv	ے در -رع 2_120
3.13 2.15	. ı 2	Configuration	2_122
5.10	· 🗠		

3.16 Sa	ve Config3-133
3.16.1	Save Configuration3-133
3.16.2	Auto-Save Configuration3-133
3.16.3	Configuration Copy3-133
3.16.4	Restore
3.16.5	Erase
3.17 Re	set3-134
3.17.1	Device Reboot3-134
3.17.2	Factory Default Settings3-135
3.18 Tro	publeshooting3-135
3.18.1	Ping IPv43-135
3.18.2	Ping IPv63-136
3.18.3	Traceroute IPv43-137
3.18.4	Traceroute IPv6
3.19 Lo	gout3-138
Chapter 4 I	EXplorer Utility Introduction
4.1 Sta	arting the Configuration 4-3
4.2 De	evice
4.2.1	Search4-4
4.2.2	Live Viewer4-4
4.3 Se	ttings
4.3.1	Device Configuration4-5

4.3.	2	Configuration Web Page	4-6
4.4	Tool	S	4-7
4.4.	1	IP Setting	4-7
4.4.	2	Ping Test	4-7
4.4.	3	Parameter Import	4-8
4.4.	4	Parameter Export	4-8
4.4.	5	Device Reboot	4-9
4.4.	6	Update Firmware	4-9
4.5	Help	9	-10

Appendix A Private MIB Group

A.1	Private MIB	Group	A-2

Appendix B MODBUS TCP Map

B.1	DVS-G106W02-2GF	B-2
B.2	DVS-G112W02-4GF	B-8
B.3	DVS-G116W02-4GF	3-14

Appendix C EtherNet/IP

C.1	DVS-G106W02-2GF	2-2
C.2	DVS-G112W02-4GF C-	.13
C.3	DVS-G116W02-4GF C-	·23

Appendix D EDS File

D.1 EDS(Electronic Data Sheet) File	D-2
-------------------------------------	-----

1

Chapter 1 Product Introduction

Table of Contents

1.1	Product Overview	
1.1.	1 High Performance Network Technology	
1.1.	2 Industrial Grade Reliability	1-3
1.1.	3 Robust Design	1-3
1.1.	4 Dimensions(mm) & Product Profile	
1.1.	5 LED Indicators	
1.2	Installation	
1.2.	1 DIN-Rail Mounting	1-8
1.2.	2 Wall-Mounting	1-9
1.2.	3 SFP installation	
1.2.	4 Wiring the Redundant Power Input	1-10
1.2.	5 Wiring the Alarm Contact	1-11
1.2.	6 Wiring the Digital Input	1-11
1.3	Package Checklist	1-12
1.4	MTBF (Mean Time Between Failures)	1-12

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates radio frequency signal and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ---Reorient or relocate the receiving antenna.
- ---Increase the separation between the equipment and receiver.
- ---Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ---Consult the dealer or an experienced radio/TV technician for help.

CE Declaration of Conformity

The DVS series switches are CE certificated products. They could be used in any kind of the environments under CE environment specification. For keeping more safe application, we strongly suggest to use the CE-compliant industrial enclosure products.

1.1 Product Overview

Thank you for purchasing the DVS Managed Industrial Ethernet Switches. The DVS series switches including Unmanaged and Managed switches. Except the DVS-G100 Series, the DVS series switches are equipped with the intelligent alarm function, and allow the wide range of operating temperature (-40 to 75°C or -20 to 70°C). The DVS series switches are designed to support the application in any rugged environment and comply with UL, CE and FCC standards.

1.1.1 High Performance Network Technology

- 10/100/1000Base-T(X) (RJ45) , 100/1000Base-SFP Fiber
- IEEE 802.3/802.3u/802.3ab/802.3z
- Auto negotiation speed
- Auto MDI/MDI-X

1.1.2 Industrial Grade Reliability

- 2 set of DC power inputs
- 1 set of Digital Input
- 1 set of Relay Alarm

1.1.3 Robust Design

- Operating temperature: -40~75°C
- Storage temperature: -40~85°C
- Humidity: 0%~95% (non-condensing)
- Protection: IP40

1.1.4 Dimensions(mm) & Product Profile

• DVS-G106W02-2GF

1







1



• DVS-G116W02-4GF





No	Description
1	DI/DO port
2	Ground screw
3	Power terminal
4	SFP port
5	Ethernet communication port
6	Micro USB CONSOLE port
7	LED indicator
8	Reset button

	DVS-G106W02-2GF	DVS-G112W02-1GF	DVS-116W02-4GF	
Case	IP40 Metal Case			
Dimension(mm)	135H x 51W x 135D	135H x 51W x 135D	135H x 65W x 135D	
Weight(g)	520	500	564	

1

1.1.5 LED Indicators

LED		Color	Status	Description	
SYS		Croop	ON	The system is normal.	
		Green	Blinking	The system is booting.	
		Red	OFF	The system is abnormal.	
				The communication is interrupted, power failure, or alarm event	
		Ded	ON	which has been configured happened.	
F		Reu	OFF	The communication is NOT interrupted, power failure, or alarm event	
			OFF	which has been configured doesn't happen.	
0\//D		Croon	ON	The power is supplied normally.	
PVV	NI/ PWKZ	Green	OFF	The power is not supplied.	
		Croon	ON	The DI is triggered.	
	ט	Green	OFF	The DI is not triggered.	
		Croop	ON	Ethernet ports capable of are 1000Mbps	
	10/100/100014	Green	OFF	Ethernet port is inactive	
	10/100/1000M	Amber	ON	Ethernet ports capable of are 100/10Mbps	
KJ40			OFF	Ethernet port is inactive	
(Copper)	LINK/ACT	K/ACT Amber	ON	The Network communication connection has been established.	
			Blinking	Data is transmitting	
			OFF	Ethernet port is inactive	
			ON	SPF ports capable of are 1000Mbps	
		Green	Blinking	Data is transmitting at 1000Mbps	
SFP	400/400004		OFF	SPF port is inactive	
(Fiber)	100/100000		ON	SPF ports capable of are 100Mbps	
		Amber	Blinking	Data is transmitting at 100Mbps	
			OFF	SPF port is inactive	
			ON	As a master of ONE RING, or a forwarding path of Coupling Ring.	
R.M/CPLG.R		Amber	Blinking	Any node disconnection is occurred in ONE RING or Coupling Ring.	
			OFF	A slave of ONE RING, or ONE RING or Coupling Ring is not available.	
			ON	As a head or a tail of ONE CHAIN.	
				As a head or a tail of ONE CHAIN, any node disconnection is	
C.HD/C.TL		L Green	Green Blinking		occurred.
			OFF	ONE CHAIN is not available.	

1.2 Installation

1.2.1 DIN-Rail Mounting

DIN-rail mounting 1:

1

Step 1: Hook the upper end of the DIN clip of the DVS series switch on the DIN-Rail.

Step 2: Lightly push the DVS series switch toward the DIN-Rail until they contact each other closely.

DIN-rail removal2:

Step 1: Insert the flat-blade screwdriver into the DIN clip and pull the DIN clip downward.

Step 2: Pull the DVS series switch, and you can remove it from the DIN-Rail



1.2.2 Wall-Mounting

Wall-Mounting:

Step 1: Insert the wall mounting bracket into the slot on the rear panel of the DVS series switch, and tighten the screw on it, as shown in the diagram below.

Step 2: Place the wall mounting bracket in an appropriate position, and tighten the two screws on the bracket and the DIN clip.



1.2.3 SFP installation

Insert

Insert SFP Module into the SFP combo port.

Remove

Pull the tab on the module, and then pull out it.





Note:

- Delta has LCP-100 and LCP-1000 series SFP module. DVS switch can promise 100% compatible with Delta SFP module.
- The actual link distance of a particular fiber optic link given the optical budget, the number of connectors and splices, and cabling quantity. Please measure and verify the actual link loss values once the link is established to identify any potential performance issues.

1.2.4 Wiring the Redundant Power Input

The DVS series switches are equipped with one to two sets of DC input (PWR1 / PWR2). Both sets of DC input can be connected to a wide range of power sources (12 to 48VDC). If one power source fails, the other live source can work as a backup to ensure that the machine operates normally. (Should connected with SELV power sources) Step 1: Insert the negative and positive DC wires into the terminal block, and make sure that the positive DC wire is

connected to V1+ or V2+, and that the negative DC wire is connected to 0V.

Step 2: To prevent the loose DC wires, tighten the wire clamp screws on the terminal block connector with the flat-blade screwdriver.





Note:

Please use copper wire 60/75°C, conductor 16 to 24 AWG; screw up at torque 4.5 in-lbs

Step 3: Insert the plastic terminal block connector into the terminal block receptor on the DVS series switch.



Note:

Grounding the ground terminal or Protective conductor terminal (PE) on the DVS series switch can avoid the noise effect due to the electromagnetic interference (EMI).

1.2.5 Wiring the Alarm Contact

The DVS-G100 series switches are equipped with one alarm. The alarm contact is a dry relay. If one of the two power sources fails, one of digital input is triggered or the communication is interrupted, the contact will turns from an "OPEN" circuit to a "CLOSED" circuit. The relay can be connected to a 1A/24VDC or 0.5/48VDC power source.



1.2.6 Wiring the Digital Input

The DVS-G100 series switches are equipped with one sets of digital input. If the power source between 0 to 5V, the state of DI is OFF. If the power source between 11 to 30V, the state of DI is ON. The maximum input current is 6mA. (Note: DI should connected with SELV circuit only.)



1.3 Package Checklist

Unpack the package carefully and check the package contents. The package should contain the following items:

- One Delta DVS Managed Ethernet Switch
- Protective Caps for unused RJ45 ports and fiber ports
- Wall mounting Plate x1
- Micro-USB (RS-232 in Micro-USB connector) x1
- 2-PIN Terminal Block x 2, 4-PIN Terminal Block x1
- User manual and Software CD
- Instruction Sheet



Note:

Verify that nothing is missing from the DVS-G100 Series package by using the check list above. If any item is found missing or damaged, please contact your local sales representative for support.

1.4 MTBF (Mean Time Between Failures)

DVS-G106W02-2GF : More than 2,336,000 hours.

DVS-G112W02-4GF : More than 1,616,000 hours.

DVS-G116W02-4GF : More than 974,000 hours.



Chapter 2 User Interface Introduction

Table of Contents

2.1	RJ45 Console Configuration	. 2-2
2.2	Telnet Console Configuration	. 2-3
2.3	Web Browser Configuration	. 2-4

2.1 USB Console Configuration

Delta DVS G100 series managed switch supports configuration using the CLI interface, available on the Mirco USB port to RS232 interface. You can use the terminal software to connect to Delta DVS G100 series managed switch.

1. Open the terminal software, and select an appropriate COM port for **Console Connection**, **9600** for **Baud Rate**, **8** for **Data Bits**, **None** for **Parity**, and **1** for **Stop Bits**, **None** for **Flow Control**.

Tera Term: Serial port setu	qu	>	×
Port:	сом6 ~	ОК	
<u>B</u> aud rate:	9600 ~		
<u>D</u> ata:	8 bit \sim	Cancel	
P <u>a</u> rity:	none ~]	
<u>S</u> top:	1 bit \sim	<u>H</u> elp	
<u>F</u> low control:	none ~]	
Transmit delay	<u>c</u> har O	msec/ <u>l</u> ine	



Note:

The Windows 7 system does not support Hyper Terminal. If you need it, you can download the terminal software to use it.

2. The user name and the password are the same as Web Browser. The default **user name is "admin", and the password is blank.**



■ You can enter "en" and then "?" to list the commands.

COM6:9600baud - Tera Term VT File Edit Setup Control Window Help	
(DVS-G112W02-4SFP) > en (DVS-G112W02-4SFP) # ?	
boot clear clock configure copy debug delete dot1x erase exit factory filedescr listuser logout no ping reload restore run save script sfp show	Marks the given image as active for subsequent re-boots. Reset configuration to factory defaults. Anange the system clock. Enter into Global Config Mode. Copy files. Configure debug flags. Deletes given image on the node. Configure dot1x EXEC mode parameters Erase configuration file. Exit to EXEC mode. Reset the switch to factory defaults states. Sets text description for a given image. List all valid users, along with their permissible mode. Exit this session. Any unsaved changes are lost. Send ICMP echo packets to a specified IP address. Reload stack or a switch in the stack. Set the flag of the restore. run cable diagnostics. Save the running configuration to NVRAM. Apply/Delete/List/Show Configuration Scripts. Configure SFP EXEC mode parameters Display Switch Options and Settings.
traceroute vlan vtss write	Trace route to destination. Type 'vlan database' to enter into VLAN mode. Read or write vtss chip's register Save the current configuration to NVRAM.

2.2 Telnet Console Configuration

A Delta Layer 3 managed switch supports the telnet server function; it can be globally enabled or disabled. The user can use all CLI commands over a telnet session. The maximum number of inbound telnet sessions allowed on the switch can be configured to 0-5. The inactivity timeout value for the incoming Telnet sessions for the switch can be configured to 1-160 minutes. The login authentication supports the local user method or the remote user method which is configured. When the login authentication is the remote user method, it supports RADIUS and TACACS+.

1. Open a Command Prompt window and input "telnet 192.168.1.X" to login to a Delta switch.

Tera Term: New	connection			×
● TCP <u>/I</u> P	Hos <u>t</u> :	192.168.1.5		~
	Service:	⊻ Hist <u>o</u> ry ● Telnet	TCP por	t#: 23
		0 <u>s</u> sн	SSH <u>v</u> ersion:	$\rm SSH2 = \sim$
		○ Other	Proto <u>c</u> ol:	UNSPEC ~
○ S <u>e</u> rial	Po <u>r</u> t:	COM6: Silico	on Labs CP210x	USB to U \sim
	ОК	Cancel	<u>H</u> elp	

2. After entering the default user name is "admin" and the password is blank., you can use the CLI command to control the switch.



Note:

1. The IP Address by default is 192.168.1.5

2.3 Web Browser Configuration

A Delta Layer 3 managed switch supports a friendly GUI for normal users to configure the switch. You can monitor the port status of a Delta PoE managed switch, and configure the settings of each function via the web interface.

1. Open a web browser and connect to the default IP address 192.168.1.5. Enter a user name and a password. (The default user name is "admin" and the password is blank.)

	Login
Username	admin
Password	•••••
	Login



Note:

The default user name "admin" is in the lowercase not uppercase.
 By default, IE5.0 or later version does not allow Java Applets to open sockets.
 You need to explicitly modify the browser setting in order to enable Java Applets to use network ports.

2. You can use the menu tree in the left side frame to find the function you want to configure. And configure the detailed settings in the right side frame.



3. The port status and the LED status on the switch can be monitored in the top frame.



MEMO

3

Chapter 3 Featured Functions

Table of Contents

3.1	Basic Se	etting	3-5
3.1.	1 Syst	em Information	3-5
3.1.2	2 Netv	work Interface	3-6
3.	1.2.1	IPv4 Network Configuration	3-6
3.	1.2.2	IPv6 Network Configuration	3-7
3.	1.2.3	IPv6 Network Neighbor	3-8
3.1.3	3 Port	Setting	3-9
3.	1.3.1	Port Settings	3-9
3.	1.3.2	LAG Settings	3-10
3.1.4	4 Time	е	3-10
3.	1.4.1	SNTP Scalars Configuration	3-11
3.	1.4.2	SNTP Unicast Server Configuration	3-12
3.1.5	5 DHC	P/BOOTP Settings	3-12
3.	1.5.1	DHCP Server	3-12
3.	1.5.2	DHCP Relay	3-17
3.	1.5.3	DHCP L2 Relay	3-19
3.1.6	6 DNS) 	3-22
3.	1.6.1	DNS Configuration	3-22
3.	1.6.2	Host Configuration	3-23
3.1.	7 Syst	em File Update	3-24
3.	1.7.1	Download File	3-24
3.	1.7.2	Upload File	
3.1.8	8 Man	agement Access	
3.	1.8.1	HTTP Configuration	
3.	1.8.2	HTTPS	3-28
3.	1.8.3	SSH Configuration	
3.	1.8.4	Ielnet Configuration	
3.	1.8.5	Console Port	
3.1.9	9 Loop	bback-Detection	
3.	1.9.1	Global Configuration	
3.	1.9.2	Port Configuration	
3.1.	10 Et	therNet/IP	
3.2		anager	
3.2.		IP V I/V2C	
ა. ე	2.1.1	Trop Configuration	
ວ. ວ	2.1.2	Trap Configuration	
3. 22	2.1.3 2 SNN	ITAP Flags	
3.2.2	2 SINIV 221	IP V3	
3.	Z.Z. I		
3.3	Network	< Redundancy	3-38
3.3.7	1 STP		3-38
3.	3.1.1	STP Configuration	3-42
3.	3.1.2	CST Configuration	3-43

	3.3.1.3	CST Port Configuration	
	3.3.1.4	CST Port Status	
	3.3.1.5	MST Configuration	
	3.3.1.6	MST Port Status	
	3.3.1.7	STP Statistics	
	3.3.2 F	Redundancy	
	3.3.2.1	ONE RING Configuration	
	3.3.2.2	ONE CHAIN Configuration	
	3.3.2.3	ONE COUPLING Configuration	
	3.3.2.4	Redundancy Cruiser	
	3.3.3 F	Redundancy Application Setting	
3.	4 Virtu	al LANs	
	341 \	/I AN Mode Configuration	3-65
	342 V	/I AN Configuration	3-65
	343 V	/I AN Membership	3-66
	344	/I AN Status	
	345 F	Port PVID Configuration	3-67
	346	SVRP Configuration	3-68
	347 (Dino VI AN Configuration	
	348 N	AC Based VI AN	3-70
	340 1	P Subnet Based VI AN	3-71
	J.4.7 I		
3.	5 Multi	cast Filtering	3-71
	3.5.1 I	GMP Snooping Configuration	
	3.5.2 I	GMP VLAN Configuration	
	3.5.3 I	GMP Snooping Multicast Forwarding Table	
	3.5.4 N	Julticast MAC Address Configuration	
	3.5.5 0	GMRP Configuration	
	3.5.6 N	Aulticast Forwarding Table	
3.	6 Traffi	ic Prioritization	3-77
	361 (3-77
	3611	OoS Satting	
	3612	CoS Queue Manning	
	3613	DSCP Queue Mapping	
	5.0.1.5		
3.	7 Traffi	ic Control	3-81
	3.7.1 F	Port Isolation Configuration	
3.	8 Port	Bandwidth	3-81
	3.8.1 5	Storm Control	
	3.8.1.1	Storm Control Setting	3-82
	3.8.1.2	Rate Limiting	
3.	9 Port	Trunking	
	201	• • • • • • • • • • • • • • • • • • •	0.04
	3.7.1 L	AG	
	3.9.1.1		
	3.9.1.2	LAG INFORMATION	
3.	10 Acces	ss Control List	3-85
	3.10.1	MAC ACL	
	3.10.1.1	MAC Rules	
	3.10.1.2	2 MAC Binding Configuration	
	3.10.1.3	3 MAC Binding Table	
	3.10.2	ARP ACL	

3.10.2.1	ARP Rules	3-90
3.10.2.2	ARP Binding Configuration	3-91
3.10.2.3	ARP Binding Table	3-92
2.4.4		2 02
3.11 Secur	ity settings	3-92
3.11.1	Security	3-92
3.11.1.1	Port Security	3-92
3.11.1.2	IP Source	3-94
3 11 1 3	802 1X	3-95
3 11 2	Management Security	3-100
3 11 2 1	Local Users Management	3-100
3 11 2 2	RADIUS Server Config	3-101
3 11 2 2	PADIUS Statistics	3-107
2 11 2 /	TACACS + Sorvor	3-102
2 11 2 5		2 102
3.11.2.3 2.11.2.4	IACACS+ AS	2 4 0 4
3.11.2.0 2.11.2.7		2 4 0 4
3.11.2.7	Login User Sessions	. 3-104
3.11.3		3-105
3.12 Monit	oring Settings	3-105
0 1 0 1		0.400
3.12.1	MAC Address Table	
3.12.2	SFP DDM (Only for SFP Module)	
3.12.3	System CPU Status	3-107
3.12.4	Interface Statistics	. 3-108
3.12.5	ARP Configure	3-108
3.12.5.1	Basic	3-108
3.12.6	RMON	. 3-109
3.12.6.1	Basic Settings	. 3-109
3.12.6.2	Alarms	. 3-109
3.12.6.3	Events	3-110
3.12.6.4	Event Log	3-111
3.12.6.5	History	3-111
3.12.6.6	RMON Ethernet Statistics	3-112
3.12.6.7	Ethernet History Statistics	3-114
3.12.7	SYSLOG	3-116
3.12.7.1	Show Logs	3-116
3.12.7.2	Logs Configuration	3-116
3.12.7.3	Syslog Fwd Table	3-118
3.12.7.4	Syslog Email Configuration	3-119
3.12.7.5	Syslog Email Alarm Table	3-119
0.40 Di		
3.13 Dia	gnostic Settings	3-121
3.13.1	LLDP	. 3-121
3.13.1.1	LLDP Basic Settings	. 3-121
3.13.1.2	LLDP Interface Configuration	. 3-122
3.13.1.3	LLDP TLV Options	3-123
3.13.1.4	LLDP Local Information	3-124
3 13 1 5	LLDP Neighbor Information	
3 13 1 6	LI DP Traffic	3-127
3 13 1 7	LIDP-MED Global Configuration	3-127
3 13 1 9	LLDP-MED Interface Configuration	3-128
3 12 2	Port Mirroring	3_120
3.13.∠ 2.12.2.1	Multiple Port Mirroring	3_120
J. I J. Z. I		. 5-123
3.14 Aut	o Warning	3-130
3 14 1	Relay Alarm	3-130
0.11.1		

3.14	4.1.1 Relay Alarm Setting	
3.14	4.1.2 Relay Alarm Table	
3.15	Dual Image	
3.15.1	I Сору	
3.15.2	2 Configuration	
3.16 Sa	ave Config	3-134
3.16.1	I Save Configuration	
3.16.2	2 Auto-Save Configuration	
3.16.3	3 Configuration Copy	
3.16.4	Restore	
3.16.5	5 Erase	
3.17 R	eset	3-135
3.17.1	Device Reboot	
3.17.2	2 Factory Default Settings	
3.18 Tı	roubleshooting	3-136
3.18.1	Ping IPv4	
3.18.2	2 Ping IPv6	
3.18.3	3 Traceroute IPv4	
3.18.4	Traceroute IPv6	
3.19	Logout	

3.1 Basic Setting

The basic setting group includes the most common settings, and an administrator can maintain the control of the Delta switch in this group.

3.1.1 System Information

System Information includes the basic switch status items and the version .It also displayed in the banner of the GUI. These informations can help the administrator identify the switch in the network.

System Information

Switch Status	
System Name	
System Location	
System Contact	
Serial Number	DVS1120119100009
System Object ID	1.3.6.1.4.1.6785.501.7.6
Date & Time	Thu 00:04:50 1970-01-01
System Up Time	0 hrs, 4 mins, 52 secs
MAC Address	00:18:23:12:e0:2b
Auto Save	Disable

Versions		
Model Name	Boot Version	Software Version
DVS-G112W02-4GF	0.6	1.06

Refresh Cancel Apply

• System Status

Description	Factory default
System Name	
Input the system name of the switch.	None
System Location	
Input the system location of the switch.	None
System Contact	
Input the system contact of the switch.	None
Serial Number	
The serial number of the switch.	Fixed
System Object ID	
The based object ID for the Management Information Base (MIB) of the switch.	Fixed
Date & Time	
The current date and time.	None
System Up Time	
The time of hours, minutes, and seconds since the switch was last started.	None

3

Description	Factory default
MAC Address	
The MAC address of the switch.	Fixed
Auto Save	
When enable it, any configuration will be saved to flash automatically in WEB/CLI/SNMP and startup-configuration and backup-configuration can't be erased through WEB or CLI.	Disable

Versions

Description	Factory default
Model Name	
The model name of the switch.	Model Name
Boot Version	
The boot version of the switch.	Boot Version
Software Version	
The software version of the switch.	Software Version

3.1.2 Network Interface

The network interface on the network device is a logical interface. Each network device must have one or more interfaces to connect with other network devices. But the configuration of the network interface does not affect the traffic which is forwarded.

3.1.2.1 IPv4 Network Configuration

You can configure a static IP address, a subnet mask and a default gateway for the switch. Or you can enable DHCP mode or BOOTP mode for receiving a dynamic IP address, a subnet mask and a default gateway. If you enable DHCP mode or BOOTP mode, but there is no DHCP or BOOTP server in the network, the default link local IP address will be **169.254.100.100**.

IPv4 Network Interface Configuration

IPv4 Network Interface Configuration			
IP Address	192.168.1.5		
Subnet Mask	255.255.255.0		
Default Gateway	0.0.0.0		
MAC Address	00:18:23:12:e0:2b		
Current Network Configuration Protocol	None DHCP BOOTP		
Management VLAN ID	1		

Refresh Cancel Apply

Note:

The default Current Network Configuration Protocol is None. And the default IP address is **192.168.1.5**.

IPv4 Network Interface Configuration

Description	Factory default
IP Address	
Input the IP address of the IPv4 network interface.	
Note:	192.168.1.5
After you change the IP address and clicking Apply, we suggest you to	
login again, and making sure the URL is the latest IP address.	
Subnet Mask	
Input the IP subnet mask of the IPv4 network interface.	255.255.0
Default Gateway	
Input the default gateway of the IPv4 network interface.	0.0.0.0.
MAC Address	
This field displays the MAC address of the switch.	MAC address
Current Network Configuration Protocol	
Select one item to specify how the switch gets its IP information:	
• None: Specify the static IP address information.	
• DHCP : DVS will be a DHCP client, waiting for the DHCP server to assign an IP	
address. At this point DVS IP address will become 169.254.100.100 if there is no	None
DHCP server to assign an IP address.	
• BOOTP : DVS will be a BOOT client, waiting for the BOOT server to assign an IP	
address. At this point DVS IP address will become 169.254.100.100 if there is no	
BOOTP server to assign an IP address.	
Management VLAN ID	
Input the management VLAN ID in the range from 1 to 4094.	1

3.1.2.2 IPv6 Network Configuration

If you need to configure a global IPv6 address, please follow the standard format: "IPv6 Prefix/Prefix Length". Example: "1001:2002:3003::7007:8008/64"

IPv6 Network Interface Configuration

Global Configuration	
Admin Mode	 Disable Enable
IPv6 Gateway	



Global Configuration

Description	Factory default
Admin Mode	
Specify the IPv6 administrative status of the network interface by selecting one item:	
Disable: IPv4 only mode. Only support IPv4, not support IPv6.	Enable
Enable: IPv4 / IPv6 mode. Support both IPv4 and IPv6.	

IPv6 Gateway	
Input the IPv6 address of the IPv6 gateway.	None

IPv6 Network Interface Configuration

Description	Factory default
IPv6 Prefix / Prefix Length	
Enter the IPv6 address followed by a slash and then the prefix length of the network	IDv6 address
interface.	IF VO address
EUI64	
Specify whether the IPv6 address is in the 64-bit extended unique identifier (EUI-64)	
format:	Nana
 True: The IPv6 address is in the EUI-64 format. 	inone
• False: The IPv6 address is not in the EUI-64 format.	

Note:

An IPv6 address in the EUI-64 format is an automatically self-assigned unique 64-bit IPv6 interface identifier. You do not need to manually configure such an IPv6 address, and it is not assigned by a DHCP server.

3.1.2.3 IPv6 Network Neighbor

The IPv6 network interface neighbor table can display the neighbor IPv6 address.

IPv6 Network Interface Neighbor Table

IPv6 Network Interface Neighbor Table				
IPv6 Address	MAC Address	Neighbor State		
fe80::4419:f6e8:dd10:be18	60:d8:19:18:cf:74	Stale		

Refresh

IPv6 Network Interface Neighbor Table

Description	Factory default
IPv6 Address	
The IPv6 address of the neighbor.	None
MAC Address	
The MAC address of the neighbor.	None
Neighbor State	
The status of the neighbor:	
Static: The neighbor has a static IP address.	
• Reachable: The neighbor was reached very recently (that is, within a	
period of tens of seconds).	
Incomplete: The address resolution for the neighbor is in progress, but the	
link-layer address of the neighbor has not yet been determined.	
• Stale: The neighbor can no longer be reached. Until the traffic is sent to the	
neighbor, no attempt is made to verify it if it can be reached again.	None
• Delay: The neighbor can no longer be reached. The traffic was recently	
sent to the neighbor, but neighbor solicitation probes are delayed because	
the confirmation that the neighbor can be reached might be received.	
Probe: The neighbor can no longer be reached. Unicast neighbor	
solicitation probes are sent to verify whether the neighbor can be reached	
again.	
Unknown: The status of the neighbor is unknown.	

3.1.3 Port Setting

You can configure the basic port settings and LAG settings of the Delta switch in the Port Settings group.

3.1.3.1 Port Settings

You can configure and monitor the port status on this page.

Р	0	r	t	5	e	t	tı	n	g	S
	-									

1	Port Settings										
		Port	Link Status	Admin Mode	Alias	Port Type	Physical Mode	Physical Status	Flow Control Mode	Jumbo Frame	Link Trap
				-		- v	· 💌		-	- 💌	· 💌
		0/1	Link Up	Enable		Normal	Auto	100 Mbps Full Duplex	Disable	Disable	Enable
		0/2	Link Down	Enable		Normal	Auto	Unknown	Disable	Disable	Enable
		0/3	Link Down	Enable		Normal	Auto	Unknown	Disable	Disable	Enable
		0/4	Link Down	Enable		Normal	Auto	Unknown	Disable	Disable	Enable
		0/5	Link Down	Enable		Normal	Auto	Unknown	Disable	Disable	Enable
		0/6	Link Down	Enable		Normal	Auto	Unknown	Disable	Disable	Enable

• Port Settings

Description	Factory default	
Port		
This field displays the interface number.	interface number	
Link Status		
This field displays the connection of the interface.		
Link Up: There is a network device connecting to the interface.	Link down	
Link Down: No network device is connecting to the interface.		
Admin Mode		
The administrative state of the interface:		
• Enable: The interface is switched on and the network device can connect to the		
interface.	Enable	
• Disable : The interface is switched off and the network device can not connect to		
the interface.		
Alias		
Specify an alias for the port to help administrators differentiate between different ports.	None	
For example: Head port.	None	
Port Type		
This field displays whether the interface is a member of a port channel:		
• Trunk Member : The interface is a member of a link aggregation group.		
• Normal : The interface is not a member of a link aggregation group (port channel).	Normal	
Note:		
If you add ports in the lag, the port type will show "Trunk Member". The		
LAG configuration could be configured in Port Trunk.		
Physical Mode		
Specify the speed capability of each interface:		
• Auto: The duplex mode and the speed of the interface are set by the		
auto-negotiation process. The interface can support the maximum capability: Full		
duplex and 1 Gbps or 100Mbps.		
• 10 MDps Hait Duplex: Indicates that the interface works at 10 MDps in the haif		
auplex mode.	Auto	
• To mops Full Duplex. Indicates that the interface works at To mops in the full duplex mode.		
• 100 Mbps Half Dupley: Indicates that the interface works at 100 Mbps in the half		
dupley mode		
100 Mbns Full Duplex: Indicates that the interface works at 100 Mbns in the full		
dunlex mode		
Physical Status		
This field displays the actual port speed and the duplex mode	None	
Flow Control Mode	T tono	
This field displays whether the flow control is enabled for the port		
Enable: The flow control is enabled. If the port buffers become full, the switch	Disable	
sends pause packets.	Dicabio	
	L	

Description	Factory default
• Disable : The flow control is disabled. If the port buffers become full, the switch does	
not send pause packets.	
Jumbo Frame	
The field displays whether the jumbo frame is enabled for the port.	
• Enable : The jumbo frame is enabled. The switch supports a fixed jumbo frame size	Disable
- 9000 bytes payload (9018 bytes frame) size.	Disable
Disable: The jumbo frame is disabled.	
Link Trap	
Specify whether to send a trap when the interface link status changes:	
• Enable: When the link status changes, the switch sends a trap. This is the default	Enable
setting.	Enable
• Disable : When the link status changes, the switch does not send a trap.	

3

3.1.3.2 LAG Settings

You can configure the LAG settings and monitor the LAG status on this page.

LAG Settings

LAG Settings								
Port	Link Status	Admin Mode	Jumbo Frame	Link Trap				
		- •	- •	- •				
po1	Link Down	Enable	Disable	Enable				
po2	Link Down	Enable	Disable	Enable				
po3	Link Down	Enable	Disable	Enable				
	Port po1 po2 po3	G Settings Port Link Status po1 Link Down po2 Link Down po3 Link Down	G SettingsPortLink StatusAdmin ModepoltInk DownInablepo2Link DownEnablepo3Link DownEnable	G SettingsPortLink StatusAdmin ModeJumbo FrameImage: StatusImage: Sta				

Refresh Apply Cancel

LAG Settings

Description	Factory default
Port	
This field shows the interface number.	interface number
Link Status	
This filed shows the connection of the interface.	
Link Up: The interface is connected to another device.	Link Down
• Link Down: The interface is not connected to another device.	
Admin Mode	
Specify the administrative state of the interface:	
• Enable: The interface is switched on and can be connected to another device.	Enable
• Disable: The interface is switched off and can not be connected to another	Enable
device.	
Jumbo Frame	
The filed displays whether the jumbo frame is enabled for the port.	
• Enable: The jumbo frame is enabled. The switch supports a fixed jumbo	Dicabla
frame size - 9000 byte payload (9018 byte frame) size.	Disable
Disable: The jumbo frame is disabled.	
Link Trap	
Specify whether the switch sends a trap when the interface link status changes:	
• Enable: When the link status changes, the switch sends a trap. This is the	Enable
default setting.	Ellane
• Disable: When the link status changes, the switch does not send a trap.	

3.1.4 Time

The Delta managed switch supports SNTP (Simple Network Time Protocol). It can work as an SNTP client to get time from an SNTP or NTP server, and it also can work as an SNTP server to provide time service and send a time reply to a client.
3.1.4.1 SNTP Scalars Configuration

SNTP Scalars Configuration lets a user configure the time of the switch which can be gotten from the SNTP server. And it also can be configured manually.

SNTP Scalars Configuration

SNTP Scalars Con	figuration
SNTP Client Status SNTP Server Status	 Disabled Enabled Disabled Enabled
Date	DD/MM/YYYY (DD/MM/YYYY)
Time	HH:MM:SS (HH:MM:SS)
Time Zone	+00:00 (+/-HH:MM)
DST StartTime	For example, First-Sun-Mar,05:10
DST EndTime	For example, Second-Sun-Nov,06:10

Cancel Apply

• SNTP Scalars Configuration

Description	Factory default
SNTP Client Status	
Specify whether the switch works as an SNTP client, and the switch will send an NTP	
request to the server which the user specify on the SNTP Unicast Server Configuration	
page.	Disable
Enable: The switch works as an SNTP client.	
Disable: The switch does not work as an SNTP client.	
SNTP Server Status	
Specify whether the switch works as an SNTP server.	
Enable: The switch works as an SNTP server.	Disable
Disable: The switch does not work as an SNTP server.	
Date	
The date parameter format is DD/MM/YYYY.	
When an SNTP client is disabled, you can manually set the date. When an SNTP client	DD/MM/YYYY
is enabled, the field is grayed out.	
Time	
The time parameter format is HH:MM:SS.	
When an SNTP client is disabled, you can mpinganually set the time. When an SNTP	HH:MM:SS
client is enabled, the field is grayed out.	
Time Zone	
The time zone setting format HH:MM is preceded by a plus (+) or minus (-). For	
example, for Taipei, enter +08:00. And it allows the conversion from GMT (Greenwich	+00:00
Mean Time) to the local time.	
DST StarTime	
Enter the daylight saving time (DST) start time. Specify the date and time in the following	
format:	
Week of the month-day of the week-month-HH:MM.	None
For example, if DST starts on the first Saturday in May at 03:00 AM, enter the following	
format: First-Sat-May-03:00.	
DST EndTime	
Enter the daylight saving time (DST) end time. Specify the date and time in the following	
format:	
Week of the month-day of the week-month-HH:MM.	None
For example, if DST ends on the second Monday in December at 04:00 AM, enter the	
following format: Second-Mon-Dec-04:00.	

0	1.	After you have clicked Apply, the date and time are applied and the fields revert to their default
		setting of DD/MM/YYYY and HH:MM:SS.
	2.	The manual date and time setting will be lost after the switch is rebooted, even if you have
		saved the changes

3.1.4.2 SNTP Unicast Server Configuration

If you want to specify a known SNTP server, you can enter the IP address or DNS on this page. **SNTP Unicast Server Configuration**

SNTP Unicast Server Configuration					
	Forward Address Type	Unicast Server IP Address	Unicast Server Type	Last Updated	Tx Requests
	- •		- •		
		Add Cancel D	elete Apply		

SNTP Unicast Server Configuration

Description	Factory default
Forward Address Type	
Specify a type of SNTP server IP address:	
• IPv4: Use an IPv4 address to recognize an SNTP server. This is the default	
setting.	IPv4
• IPv6: Use an IPv6 address to recognize an SNTP server.	
DNS: Use FQDN to recognize an SNTP server.	
Unicast Server IP Address	
Enter the server IPv4, IPv6 address or host name (FQDN). (Depend on the type you	Nono
select in the Forward Address Type field.)	None
Unicast Server Type	
Specify a type of server by selecting Primary or Secondary from the drop-down list.	None
Last Updated	
This field displays the last time the SNTP unicast server updated its time information.	None
Tx Requests	
This field displays the number of SNTP transmit requests made by the switch since it	Nono
was last rebooted.	none

Note:

I

We recommend that you add the SNTP unicast server for the Delta switch to synchronize the time. It can make sure that the time on the Delta switch is accurate.

3.1.5 DHCP/BOOTP Settings

The Delta switch can function as a DHCP server, DHCP relay and DHCP L2 relay. If there is no DHCP server in your network, then you can enable a DHCP server function on the Delta switch. If there is a DHCP server in your network, then you can configure the Delta switch as a DHCP relay. If there is already a DHCP server and a DHCP relay in your network, or there are L2 devices between DHCP clients and relay agents, then you can configure the Delta switch as a DHCP L2 relay in this network.

3.1.5.1 DHCP Server

If the DHCP server is enabled on the switch, it can assign an IP address which is in the same network as the switch to the client. The Delta switch also supports the MAC Based DHCP Configuration and the Port Based DHCP Configuration.

• DHCP Server Configuration

You can enable or disable the DHCP server function and configure the DHCP configuration on this page.

The following is a DHCP Server example:

Set Network to 192.168.1.0, DVS will send the IP address of the network segment 192.168.1.1-192.168.1.254 DHCP Client.

DHCP Server Configuration

DHCP Server Configuration	
Admin Mode	Enable 🔻
Next Server	0.0.0.0
Boot File	None
Network	192.168.1.0
Subnet Mask	255.255.255.0
Lease Time Type	Infinite •
Lease Time	D H M
Default Router	
DNS Server	
Domain Name	

Excluded Addresses					
	IP Range From		IP Range To	Method	

Add	Delete	Cancel	Apply

DHCP Server Configuration	
Description	Factory default
Admin Mode	
Specify the status of the DHCP server on the switch:	
• Disable: The DHCP server is disabled. When you want to enable the DHCP	Disable
relay function, please select this setting.	Disable
Enable: The DHCP server is enabled.	
Next Server	
Specify the boot server host name.	0.0.0.0
Boot File	
Specify the boot file name.	None
Network	
Enter the network for the DHCP pool.	None
Subnet Mask	
Enter the IP subnet mask for the DHCP pool.	None
Lease Time Type	
Specify a type of lease time:	
Specified Duration: The leased IP address has a specific duration. You	Nono
need to specify the duration in the Lease Time fields.	NONE
Infinite: The leased IP address does not expire.	
Lease Time	
If you select Specified Duration from the Lease Time Type in the drop-down list,	
specify the duration by entering the days, hours, and minutes in the Lease	None
Time fields.	
Default Router	
Specify the default gateway IP address. The information will be included in the	None
DHCP offer packet.	INDITE

Description	Factory default
DNS Server	
Specify the DNS server IP address. The information will be included in the	Nono
DHCP offer packet.	NONE
Domain Name	
Specify the domain name. The information will be included in the DHCP offer	Nono
packet.	none

Excluded Addresses

Description	Factory default
IP Range From	
Enter the start IP address of the exclusion IP range which you created in the DHCP server pool.	None
IP Range To	
Enter the end IP address of the exclusion IP range which you created in the	Nono
DHCP server pool.	None
Method	None
It indicates that the excluded address is created by a DHCP server or a user.	
There are two values:	Nono
Auto: The entry is created by a DHCP server.	None
Manual: The entry is created by a user.	

• DHCP Server Pool Option Configuration

DHCP messages contain many option fields. These options have much control information and many configuration parameters.

DHCP Server Pool Option Configuration



Add Delete Cancel Apply

• DHCP Server Pool Option Configuration

Description	Factory default
Option Code	
It supports the following configured options now:	
 Option 1 – Subnet Option 	
 Option 3 – Router Option 	
 Option 6 – Domain Name Server 	
 Option 15 – Domain Name 	None
 Option 42 – Network Time Protocol Servers Option 	
(If you need more information, please refer to RFC2132, DHCP Options and	
BOOTP Vendor Extensions.)	
Option Type	
Specify the option type:	
ASCII: Enter an ASCII value in the Option Value field.	Nono
• Hex: Enter a hexadecimal value in the Option Value field.	None
• IP Address: Enter an IP address or a subnet mask in the Option Value field.	
Option Value	
Enter the value that corresponds to the option type you select.	None

• DHCP Server Binding Table

If the DHCP server function is activated, you can see the DHCP client's information which is get the IP address from the DHCP server on this page.

DHCP Server Binding Table

DH	DHCP Server Binding Table			
	IP Address	Hardware Type	Hardware Address	Expire Time
	192.168.1.11	Ethernet	00:18:23:01:1f:2f	infinite

Refresh Delete Cancel

DHCP Server Binding Table

Description	Factory default	
IP Address		
The IP address of the DHCP client.	None	
Hardware Type		
This field displays a type of hardware address of the client.		
• Client ID: If the client uses DHCP option 61 to specify itself, the hardware		
type is the client ID, and the hardware address is the string identifier.	None	
• Ethernet: The hardware type is Ethernet, and the hardware address is an		
MAC address.		
Hardware Address		
This field displays the MAC address or the string identifier of the DHCP client.	None	
Expire Time		
The expiration time of the DHCP client.	None	

MAC Based DHCP Configuration •

MAC Based DHCP Configuration supports the administrator assigned the specific IP address to the MAC address in the list.

Note:
MAC Based DHCP Mode and Port Based DHCP Mode can't enable and work at the same
time.
 · · · · · · · · ·

MAC Based DHCP Configuration

	Mada		
AC Based DHCP	Mode		
lmin Mode		🔘 Disable 💿 Enable	
	Descript	ion	Factory
			default
Admin Mode			
Specify the status o	f the MAC Based DHCP or	n the switch.	
• Disable: The MA	AC Based DHCP Configura	ation is disabled.	
• Enable: The MA	C Based DHCP Configura	tion is enabled.	Disable
Note:			Disable
If you ne	ed to enable the admin mo	de of MAC Based DHCP Mode, it m	ust
be enabl	ed the DHCP server mode	first.	
MAC Based D	HCP Binding Configura	ition	
Pool ID	Hardware Type	Hardware Address	IP Address
1	- ·		
	Add Delete	Cancel Apply Clea	r
AC Based DHCP E	Binding Configuration		
	Description		Factory default
Pool ID			
t's the DHCP Pool	number.		fixed
Lendurana Turaa		· · ·	

Description	Factory default
This field displays a type of hardware address of the client.	
• Client ID: The type of the HW address. If the client uses DHCP option 61 to	
specify itself, the hardware type is the client ID, and the hardware address is	Nono
the string identifier.	NONE
Ethernet: The type of the HW address, and the hardware address is an	
MAC address.	
Hardware Address	
This field displays the MAC address or the string identifier.	None
IP Address	
It's the static IP address which assigned to the specified HW Address.And it	None
should be included in the Excluded Address of DHCP Server Configuration.	none

• Port Based DHCP Configuration

Note:

Port Based DHCP Configuration supports the administrator assigned the specific IP address for the port number in the list.

MAC Based DHCP Mode and Port Based DHCP Mode can't enable and work at the same time.

Port Based DHCP Configuration

Port Based DHCP Mode			
Admin Mode	O Dis	able 🔘 Enable	
Port Based DHCP Mode			
	Description		Factory default
Admin Mode			
Specify the status of the Port Base	ed DHCP on the switch.		
• Disable: The Port Based DHC	P Mode is disabled.		
• Enable: The Port Based DHCI	P Mode is enabled.		Disable
Note:			Disable
If you need to enable the DHCP	ne admin mode of MAC Base server mode first.	ed DHCP Mode, it must	
Port Based DHCP Binding	Configuration		
Pool ID	Interface	IP Address	
1			

Port Based DHCP Binding Configuration

Description	Factory default
Pool ID	
It's the DHCP Pool number.	1
Interface	
The interface number. You can specify the interface which will assign the specific IP address when the DHCP client is connect to the specific interface.	None
IP Address	
The static IP address which assigned to the specified interface. And it should be included in the Excluded Address of DHCP Server Configuration.	None

• RARP Bindings Configuration

The RARP Bindings Configuration supports to use RARP to acquire IP for device without DHCP client function.



3.1.5.2 DHCP Relay

A DHCP Relay can make broadcast messages to be sent over routers. And a DHCP relay can receive a DHCP broadcast request packet and forward it to a specified server. The operating theory is shown in the figure below.





Notice:

When a DHCP request packet comes, the DHCP relay receives it and then sends it to all VLANs. But according to RFC 2131, when a unicast DHCP request packet renews, it will be sent to a DHCP server directly without passing a DHCP relay, so it is recommended to make sure that the DHCP client can ping the server after getting an IP address.

• DHCP Relay Configuration

The DHCP relay sends a unicast DHCP packet to the specified server(s). The maximum number of specified servers is 5. You can enable or disable a DHCP relay function, and configure the parameters of the circuit ID sub-option (the interface ID on the switch which connects to the host) and the remote ID sub-option (the MAC address of the host which sends DHCP request) on this page.

DHCP Relay Configuration DHCP Relay Configuration Admin Mode Disable Circuit ID Sub-Option Remote ID Sub-Option DHCP Server Address Configuration Server Address

Add Delete Cancel Apply

DHCP Relay Configuration

Description	Factory default	
Admin Mode		
Specify the status of the DHCP relay on the switch:		
• Disable: The DHCP relay is disabled. This is the default setting.		
Enable: The DHCP relay is enabled.	Disable	
Notice:	Disable	
Before you enabled Admin Mode, please create at least one server		
IP in DHCP Server Address Configuration.		
Circuit ID sub-option		
Specify whether the circuit ID sub-option (the interface ID of the switch) is		
enabled.		
• Disable : The circuit ID can not be added to a DHCP packet. This is the default	Disable	
setting.		
• Enable: The circuit ID can be added to a DHCP packet.		
Remote ID Sub-Option		
Enter a remote ID string (the MAC address of the host which sends the DHCP		
request) for the circuit ID mode. This is a local identifier of the circuit from which a		
DHCP client-to-server packet is received. It ensures that the DHCP relay sends		
DHCP server responses back to the correct circuit.		

DHCP Server Address Configuration

Description	Factory default
Server Address	
The IP address of the DHCP server IP.	None

• DHCP Relay Statistics

DHCP Relay Statistics

DHCP Relay Statistics	
No of Packets inserted Circuit-Id option	0
No of Packets inserted Remote-Id suboption	0
No of Packets dropped	0
No of Packets which did not inserted RAI option	0

Refresh Clear

DHCP Relay Statistics		
Item	Description	
No of Packets inserted	The number of packets which inserted the circuit-Id option.	

Circuit-Id option	
No of Packets inserted	The number of packets which inserted the remote-Id suboption.
Remote-Id suboption	
No of Packets dropped	The number of packets which dropped.
No of Packets which did	The number of packets which did not insert the RAI (Relay Agent
not inserted RAI option	Information) option.

3.1.5.3 DHCP L2 Relay

In some networks, DHCP servers rely on the Relay Agent Information option appended by Relay Agents for the IP address and other parameter assignment policies. This works fine when end hosts are directly connected to Relay Agents. In some network configurations, one or more Layer 2 devices may reside between DHCP clients and a Relay agent. In these network scenarios, it is difficult to use the Relay Agent Information option for an IP address and other parameter assignment policies effectively. So there is a requirement for the device that is closest to the end hosts to append a Relay Agent Information option in DHCP messages. These devices are typically known as Layer 2 Relay Agents. The operating theory is shown in the figure below.



DHCP snooping steps:

- 1. A DHCP client sends a DHCP request via the broadcast.
- 2. When a switch (relay agent) receives the DHCP request, it will add DHCP option-82 to the packet. DHCP option-82 includes the MAC address of the host which sends a DHCP request (remote-ID sub-option) and the interface ID on the switch which connects to the host (circuit-ID sub-option).
- 3. If the switch has configured an IP address, the IP address will be added to the DHCP packet.
- 4. If a DHCP server supports option-82, after the DHCP server receives the DHCP request, it will allocate the IP address numbers according to the remote-ID sub-option or circuit ID sub-option.
- 5. A DHCP server responds to the switch via the unicast. And the switch checks whether the remote-ID or the circuit-ID in option-82 matches the value of the DHCP request, and makes sure it sends from the certificated DHCP server. Then it removes the information of option-82, and sends back to the interface on the switch which sends the DHCP request.

DHCP L2 Relay Global Configuration

You can enable or disable a DHCP relay function, and configure the parameters of the circuit ID sub-option (the interface ID on the switch which connects to the host) and the remote ID sub-option (the MAC address of the host



DHCP L2 Relay Global Configuration

Description	Factory default
Admin Mode	
Specify whether the global status of the DHCP relay is enabled.	
• Enable: The DHCP relay function is enabled.	Disable
• Disable : The DHCP relay function is disabled. This is the default setting.	

DHCP L2 Relay VLAN Configuration

Description	Factory default
VLAN ID	
If you have added VLANs on the VLAN Configuration page, the VLANs can be	
shown in the VLAN ID column, and you can configure the DHCP L2 relay	1
setting of each VLAN.	
Admin Mode	
Specify whether the status of the DHCP relay is enabled on the VLAN:	
• Enable: Enable the DHCP relay on the VLAN. You can configure the VLAN	
DHCP relay settings if the DHCP relay is globally disabled. But the settings	Disable
do not take effect even if you have applied it.	
Disable: Disable the DHCP relay on the VLAN.	
Circuit ID	
Specify whether the DHCP relay agent information option (DHCP option 82) is	
enabled:	
Enable: Enable the relay agent information option.	Disable
• Disable: Disable the relay agent information option. This is the default	
setting for the default VLANs 1, 2, and 3.	
Remote ID String	
Enter the remote ID string for the circuit ID mode. This is a local identifier of the	
circuit from which a DHCP client-to-server packet is received. It can make sure	Nono
that the DHCP relay responds to packets from the DHCP server to the correct	INDITE
circuit.	

• DHCP L2 Relay Interface Configuration

The interface which is connected to a DHCP server is a trusty interface; the interface which is connected to a DHCP client is an untrustful interface.

1. Trusted port:

- (a) When a DHCP request packet with opt82 is received, it will be forwarded.
- (b) When a DHCP reply packet with opt82 is received, if the remote ID is same as the switch's ID, opt82 will be stripped and forwarded; if the remote ID is not same as the switch's ID, it will be forwarded directly.
- (c) When a DHCP packet without opt82 is received, it will be dropped.

2. Un-trusted Port:

(a) When a DHCP packet with opt82 is received, it will be dropped.

(b) When a DHCP packet without opt82 is received, opt82 will be inserted and the packet will be forwarded.

DHCP L2 Relay Interface Configuration

DHCP L2 Relay Interface Configuration				
	Interface	Admin Mode	82 Option Trust Mode	
		- 🗸	- 🗸	
	0/1	Disable	Disable	
	0/2	Disable	Disable	
	0/3	Disable	Disable	
	0/4	Disable	Disable	
	0/5	Disable	Disable	
	0/6	Disable	Disable	
	0/7	Disable	Disable	
	0/8	Disable	Disable	
	po1	Disable	Disable	
	po2	Disable	Disable	
	po3	Disable	Disable	

Cancel Apply

DHCP L2 Relay Interface Configuration

Description	Factory default
Interface	
The interface number.	interface number
Admin Mode	
Specify whether the DHCP relay is enabled on the interface:	
• Enable: Enable the DHCP relay on the interface. If the DHCP relay is globally	
disabled on the switch, you can still configure the interface DHCP relay	Disable
settings, but the settings do not take effect even if you have applied it.	
Disable: Disable the DHCP relay on the interface.	
82 Option Trust Mode	
As a security consideration, specify whether the interface is trusted when the	
DHCP relay agent information (DHCP option 82) is received on the interface:	
• Enable: The relay agent information that is received on the interface can be	Disabla
trusted.	Disable
• Disable : The relay agent information that is received on the interface can not	
be trusted and should be ignored.	

• DHCP L2 Relay Statistics

You can see the statistics of DHCP L2 relay messages on this page.

DHCP L2 Relay Interface Statistics				
Interface	Untrusted Server Messages With Opt82	Untrusted Client Messages With Opt82	Trusted Server Messages Without Opt82	Trusted Client Messages Without Opt82
0/1	0	0	0	0
0/2	0	0	0	0
0/3	0	0	0	0
0/4	0	0	0	0
0/5	0	0	0	0
0/6	0	0	0	0
0/7	0	0	0	0
0/8	0	0	0	0
po1	0	0	0	0
po2	0	0	0	0
ро3	0	0	0	0

DHCP L2 Relay Interface Statistics

Clear Refresh

DHCP L2 Relay Interface Statistics

Item	Description
Interface	The interface number.
Untrusted Server Messages	The number of DHCP packets with option 82 that were received from
With Opt82	an untrusted server.
Untrusted Client Messages	The number of DHCP packets with option 82 that were received from
With Opt82	an untrusted client.
Trusted Server Messages	The number of DHCP packets without option 82 that were received
Without Opt82	from a trusted server.
Trusted Client Messages	The number of DHCP packets without option 82 that were received
Without Opt82	from a trusted client.

3.1.6 DNS

The Delta switch can function as a DNS client and forward the DNS queries to a DNS server. You can configure DNS servers manually or add them via a DHCP server.

3.1.6.1 DNS Configuration

You can configure the global DNS settings and add a DNS server manually on this page.

DNS Configuration

D	NS Configuration				
DNS	Status		🔿 Disable 🧕) Enable	
DNS	Default Name			(1 t	o 255 characters)
D	NS Server Configurati	on			
	Serial No	DNS Serve	r		Preference
	1	192.168.100).1		1
Add Delete Cancel Apply					

DNS Configuration

Description	Factory default
DNS Status	

 Specify whether the switch functions as a DNS client: Disabled: The switch does not function as a DNS client and does not send DNS queries. The settings do not take effect even if you configure a DNS server. Enabled: The switch functions as a DNS client and can send DNS queries to a DNS server. 	Enable
DNS Default Name	1
Enter the DNS default domain name to be included in DNS queries. When the switch performs a lookup for an unqualified host name, the DNS default domain name is provided as the domain name. For example, if the DNS default domain name is delta.com and you enter " <u>dvs</u> " for a DNS query, then " <u>dvs</u> " is changed to " <u>dvs.delta.com</u> " to resolve the name. The length of the name can not be longer than 255 characters.	None

DNS Server Configuration

Description	Factory default
Serial No	
The sequence number of the DNS server in the table. If the IP address of the DNS	
server was dynamically added through DHCP, the number is followed by an asterisk	None
(*).	
DNS Server	
The DNS server can be added manually or added dynamically through DHCP. The	Nono
Delta switch can support 8 DNS servers.	NONE
Preference	
The preference of the DNS server. The preference is determined by the order in which	
the IP address was added to the table. So preference number 1 is the first IP address	None
that was added to the table.	

3.1.6.2 **Host Configuration**

You can map a DNS host name to an IP address on this page.

DNS Host Configuration

192.168.1.50					
Dynamic Host Manning					
Total Elapsed Type Address					

Add Delete Clear Cancel

DNS Host Configuration

Description	Factory default
Host Name	
Specify the static host name. The maximum number of characters is 255.	None
IP Address	
Specify the IP address of the host name.	None
Dynamic Host Mapping	

Description	Factory default
Host	
The host name was added dynamically.	None
Total	

The total time to live (TTL) for the dynamic entry.	None
Elapsed	
The elapsed time since the dynamic entry was added to the table.	None
Туре	
The dynamic entry types:	
• IPv4	Nono
• IPv6	INOTIE
Canonical name	
Address	
The IP address of the host name.	None

3.1.7 System File Update

The Delta switch supports downloading the firmware, configuration, or log file from a TFTP server or local host. And it also supports uploading the files to a TFTP server or local host.

3.1.7.1 Download File

The Delta switch supports 2 ways for users to download files. If there is no TFTP server in your network environment, you can choose the HTTP way to download files from the local host.



TFTP Download

TFTP File Download

TFTP File Download	
File Type Image Name Server Address Type Server Address Remote File Name	Archive v image1 v IPv4 v
Transfer Status	
	Caucol

TFTP File Download

Description	Factory default
File Type	
Specify a type of file in the drop-down list that you want to download:	
Archive: When you select Archive, the Image Name drop-down list is	
displayed.	
• Startup Configuration: When the switch boots up, Startup Configuration will	Nono
be applied.	NOTE
• SSL Server Certificate PEM File: For more information about the SSL server	
certificate PEM file, please see the Certificate Information page.	
Script File: This file is used to configure the switch by the CLI script.	
Image Name	

Description	Factory default
Only when you select Archive from the File Type drop-down list is the Image	
Name drop-down list displayed. Specify the image:	image1
image1: The downloaded image firmware as image1.	inager
image2: The downloaded image firmware as image2.	
Server Address Type	
Specify a type of server address and enter the IP address or host name in the	
Server Address field:	
IPv4: The IPv4 address of a TFTP server.	IF V 4
DNS: The DNS host name of a TFTP server.	
Server Address	
Enter an IPv4 address or a DNS host name of the TFTP server.	None
Remote File Name	
Enter the name of the file that you want to download to the switch. You can enter	Nono
up to 32 characters.	inone

If you select Archive in the File Type drop-down list, the image name item will show up. After selecting File Type, setting up Server Address and specifying Remote File Name, click **Apply** to start the downloading.

HTTP Download

HTTP File Download

HTTP File Download	
File Type	Archive
Image Name	image1 💌
Select File	瀏覽
Transfer Status	
	Cancel Apply

HTTP Download

Description	Factory default
File Type	
Specify a type of file in the drop-down list that you want to download:	
 Archive: When you select Archive, the Image Name drop-down list is displayed. 	
 Startup Configuration: When the switch boots up, Startup Configuration will be applied. 	None
• SSL Server Certificate PEM File: For more information about the SSL server	
certificate PEM file, please see the Certificate Information page.	
• Script File: This file is used to configure the switch by the CLI script.	
Image Name	
Only when you select Archive from the File Type drop-down list is the Image	
Name drop-down list displayed. Specify the image:	imaged
• image1: The downloaded image firmware as image1.	imager
• image2: The downloaded image firmware as image2.	
Select File	
Specify the file that you want to download.	None

If you select Archive in the File Type drop-down list, the image name item will show up. After selecting File Type and the path of the file on your PC, click **Apply** to start the downloading.

3.1.7.2 Upload File

The Delta switch supports 2 ways for user to upload files. If there is no TFTP server in your network environment, you can choose HTTP way to upload files.

TFTP Upload

TFTP File Upload

TFTP File Upload	
File Type	Archive
Image Name	image1 💌
Server Address Type	IPv4 💌
Server Address	
Remote File Name	

Cancel Apply

TFTP Upload

Description	Factory default
File Type	
 Specify a type of file in the drop-down list that you want to upload: Archive: When you select Archive, the Image Name drop-down list is displayed. Startup Configuration: When the switch boots up, Startup Configuration will be applied. Backup Configuration: It is used to backup the Startup Configuration file. Log: This file records the log information of the switch. Script File: This file is used to configure the switch by the CLI script. 	None
Image Name	
Only when you select Archive from the File Type drop-down list is the Image Name drop-down list displayed. Specify the image: • image1: The uploaded image firmware as image1. • image2: The uploaded image firmware as image2.	
Server Address Type	
Specify a type of server address and enter the IP address or host name in the IPv4 Server Address field: IPv4: The IPv4 address of a TFTP server. • DNS: The DNS host name of a TFTP server. IPv4	
Server Address	
Enter an IPv4 address or a DNS host name of the TFTP server.	
Remote File Name	
Enter the name of the file that you want to upload to the switch. You can enter up to 32 characters.	None

If you select Archive in the File Type drop-down list, the image name item will show up. After selecting File Type, you have to set up Server Address, specify Remote File Name, and click **Apply** to start uploading.

HTTP Upload

HTTP File Upload

HTTP File Upload	
File Type	Archive
Image Name	image1 💌
	Cancel Apply

HTTP Upload

Description	Factory default
File Type	
Specify a type of file in the drop-down list that you want to upload:	
 Archive: When you select Archive, the Image Name drop-down list is displayed. 	
 Startup Configuration: When the switch boots up, Startup Configuration will be applied. 	
• Backup Configuration: It is used to backup the Startup Configuration file.	
• Log: This file records the log information of the switch.	None
• Script File: This file is used to configure the switch by the CLI script.	
Notice:	
The Backup Configuration file is for user to back up the Startup	
Configuration file, but it must use CLI to back up the file. You can use	
the command: "copy nvram:startup-config nvram:backup-config"	
to back up the Startup Configuration file by Hyper Terminal or Telnet.	
Description	Factory default
Image Name	
Only when you select Archive from the File Type drop-down list is the Image	
Name drop-down list displayed. Specify the image:	imaga1
• image1: The uploaded image firmware as image1.	inager
 image2: The uploaded image firmware as image2. 	

If you select Archive in File Type drop-down list, the image name item will show up. After selecting File Type, you have to click **Apply** and specify a path to start uploading.

3.1.8 Management Access

The Delta switch supports not only one way to access the web management interface. You can configure HTTP or secure HTTP (HTTPS), and you also can configure Secure Shell (SSH), Telnet and the console port access.

3.1.8.1 HTTP Configuration

HTTP Configuration

HTTP Configuration	
HTTP Access	🔿 Disable 💿 Enable
HTTP Port	80
HTTP Session Timeout (minutes)	30 (0 to 60)

Cancel Apply

HTTP Configuration

Description	Factory default
HTTP Access	
Specify whether the web management interface can be accessed from a web	
browser over an HTTP connection.	
• Disable : The web management interface can not be accessed over an HTTP	
connection. You need to use a Telnet, SSH, or console connection to access	Enable
the switch.	
Enable: The web management interface can be accessed over an HTTP	
connection.	
HTTP Port	
The HTTP port number. The number must be in the range of 1 to 65535. The	00
default setting is port number 80.	00
HTTP Session Timeout (minutes)	

Description	Factory default
The HTTP session timeout period in minutes. The HTTP session will be closed	
when there is no activity and the timeout period is reached. Enter a period in the	30
range of 0 to 60 minutes. Entering 0 disables the timeout.	

3.1.8.2 HTTPS

Hypertext Transfer Protocol Secure (HTTPS) is a protocol for secure communication. It enables the transmission of HTTP over an encrypted Secure Sockets Layer (SSL) or Transport Layer Security (TLS) connection. So HTTPS can help protect the communication between a computer and a switch from eavesdroppers and man-in-the-middle (MITM) attacks. If you want to configure the switch to access an HTTPS connection from a computer, the switch needs a public key certificate. You can configure the switch to generate a key or download it to the switch.

• HTTPS Configuration

HTTPS Configuration

HTTPS Configuration	
HTTPS Admin Mode	⊙ Disable ○ Enable
HTTPS Port	443
HTTPS Session Timeout (minutes)	30 (1 to 60)

Cancel Apply

HTTPS Configuration

Description	Factory default
HTTPS Admin Mode	
Specify whether the web management interface can be accessed from a web	
browser over an HTTPS connection.	
• Disable: The web management interface can not be accessed over an HTTPS	
connection. You need to use a Telnet, SSH, or console connection to access	
the switch.	
• Enable: The web management interface can be accessed over an HTTPS	Disable
connection.	
Notice:	
If you want to enable the HTTPS Admin mode, you need to use	
Generate Key, then apply Generate Certificate, please refer to	
Certificate Management.	
HTTPS Port	
The HTTP port number. The number must be in the range of 1 to 65535.	443
HTTPS Session Timeout (minutes)	
The HTTPS session timeout period in minutes. When there is no activity and the	
timeout period is reached, the HTTP session will be closed. The time period must	30
be in the range of 1 to 60 minutes.	

After you enable the HTTPS connection, you can type https://Delta switch's IP address into the web browser to establish an HTTPS connection.

For example, if a switch's IP address is 192.168.1.5, the complete address is <u>https://192.168.1.5</u>.

Certificate Management

You can use the function on this page to generate a self-signed certificate for an HTTPS connection.

Certificate Management

Certificate Management	
None	
O Generate Key (RSA-1024 bits)	(It may take a while)
Generate Certificate	
O Delete Certificate	
Certificate Present :	No



Certificate Management

Description	Factory default
None	
No certificate is to be generated.	None
Generate Key (RSA-1024 bits)	
Generate a 1024-bit RSA key.	
After the key has been generated, the page reverts to its default setting and the	None
None item will be selected.	
Generate Certificate	
Generate a certificate.	
After the key has been generated, the page reverts to its default setting and the	None
None item will be selected.	
Delete Certificate	
Delete the certificate on the switch.	None
Certificate Present	
Displays the present certificate on the switch.	None

• Certificate Download

Make sure of the conditions before you download a certificate to the switch:

- The file which is ready to be downloaded from the TFTP server is on the server and in the appropriate directory.
- The file's format is in PEM.
- The switch has a path to the TFTP server.

Certificate Download

Certificate Download	
File Type	SSL Server Certificate PEM File
TFTP Server IP	0.0.0.0
Remote File Name	
	Start File Transfer

Cancel Apply

Certificate Download

Description	Factory default
TFTP server IP	
Specify a TFTP server IP address.	0.0.0.0
Remote File Name	
Specify a certificate file name which can be downloaded.	None

• Certificate Information Certificate Information

Certificate Information

```
Certificate:
   Data:
        Version: 3 (0x2)
        Serial Number:
            6f:06:0c:5c:98:5d:69:ba:08:f6:f5:14:98:7f:3d:47
       Signature Algorithm: md5WithRSAEncryption
       Issuer: CN=self-signed
        Validity
           Not Before: Jan 1 01:05:00 1970 GMT
           Not After : Jan 1 01:05:00 1972 GMT
        Subject: CN=192.168.1.15
        Subject Public Key Info:
            Public Key Algorithm: rsaEncryption
            RSA Public Key: (1024 bit)
                Modulus (1024 bit):
                    00:bb:c3:9a:6a:e9:83:65:85:7d:fb:ee:d6:0f:93:
                    e2:de:f9:5c:63:41:4f:f8:d7:01:4c:a7:d6:52:6c:
                    3a:80:cc:19:a5:d2:ff:4f:87:e7:31:87:38:6e:f6:
                    21:84:82:80:b0:15:84:f8:f9:85:05:0d:94:c9:29:
                    9b:a7:f3:7b:4d:64:cb:dc:73:34:a3:7d:dc:c3:ac:
                    e8:be:38:74:46:8a:53:df:71:13:70:41:17:88:0e:
                    b3:f9:7c:e4:eb:69:34:96:67:1b:2e:fa:2f:68:8d:
                    cc:1b:9e:31:70:68:d8:05:b2:cb:77:b7:46:72:74:
                    1f:05:86:e7:17:fc:dd:be:73
                Exponent: 65537 (0x10001)
    Signature Algorithm: md5WithRSAEncryption
        6d:b9:e6:07:7e:17:7a:e6:3b:63:ae:b2:28:98:65:7f:de:b8:
```

Ξ

Refresh

Click Refresh for updating the information of the certificate.

3.1.8.3 SSH Configuration

You can configure an SSH configuration on this page.

SSH Configuration

SSH Configuration			
SSH Admin Mode	💿 Disable	◯ Enable	
SSH Version 1	🔿 Disable	💿 Enable	
SSH Version 2	🔿 Disable	📀 Enable	
SSH Session Timeout (minutes)	30		(1 to 160)
Maximum Number of SSH Sessions	5		
Current Number of SSH Sessions	0		

Refresh Cancel Apply

SSH Configuration

Description	Factory default
SSH Admin Mode	
Specify the status of SSH.	
Disable: SSH is disabled. This is the default setting.	Disable
Enable: SSH is enabled.	
SSH Version 1	
Specify whether SSH version 1 is supported.	
Disable: SSH version 1 is not supported.	Enable
• Enable: SSH version 1 is supported. Both version 1 and version 2 can be	LIIADIE
supported on the switch.	
SSH Version 2	
Specify whether SSH version 2 is supported.	
Disable: SSH version 2 is not supported.	Enable
• Enable: SSH version 2 is supported. Both version 1 and version 2 can be	Lilable
supported on the switch.	
SSH Session Timeout (minutes)	
The SSH session timeout period in minutes. When there is no activity and the	
timeout period is reached, the SSH session will be closed. Enter a period in the	30
range of 1 to 160 minutes.	
Maximum Number of SSH Sessions	
The maximum number of inbound SSH sessions. The number must be in the range	5
of 0 to 5.	5
Current Number of SSH Sessions	
This field displays the number of simultaneous SSH sessions.	0

3.1.8.4 Telnet Configuration

You can configure the Telnet configuration on this page.

Telnet Configuration

Telnet Configuration		
Telnet Admin Mode	◯ Disable ④ Enable	
Telnet Session Timeout (minutes)	30	(1 to 160)
Maximum Number of Telnet Sessions	5	(0 to 5)
Current Number of Telnet Sessions	0]



Telnet Configuration

Description	Factory default
Telnet Admin Mode	
Specify the status of Telnet.	
Disable: Telnet is disabled.	Enable
Enable: Telnet is enabled.	
Telnet Session Timeout (minutes)	
The Telnet session timeout period in minutes. When there is no activity and the timeout	
period is reached, the Telnet session will be closed. The period must be in the range of	30
1 to 160 minutes.	
Maximum Number of Telnet Sessions	
The maximum number of inbound Telnet sessions that are allowed on the switch. The	F
number must be in the range of 0 to 5.	5
Current Number of Telnet Sessions	
This field displays the number of simultaneous Telnet sessions.	0

3.1.8.5 Console Port

You can configure the console port configuration on this page.

Console Port

Console Port		
Console Login Timeout (minutes)	30	(0 to 160)
	Cancel Auply	

Console Port

Description	Factory default
Console Login Timeout (minutes)	
The console port session timeout period in minutes. When there is no activity and	
the timeout period is reached, the console port session is closed. The period must	30
be in the range of 0 to 160 minutes. Entering 0 disables the timeout.	

3.1.9 Loopback-Detection

A loopback error occurs when the keep-alive packet is looped back to the port that sent the keep-alive packet. The Delta managed switch provide the Loopback-Detection function to detecting the error in the network environment.

1

We suggest that the Loopback-Detection function and redundancy protocol should not enable in the same time because the operating theory of these two functions are conflict.

3.1.9.1 Global Configuration

Notice:

The module status of Loopback- Detection Global Configuration is used to enable/disable the Loopback-Detection feature.

Loopback-Detection Global Configuration

Loopback-Detection Global Configuration Module Status © Disable © Enable Cancel Apply

Loopback-Detection Global Configuration

Description	Factory default
Module Status	
Specify whether the status in global configuration is activated or not.	Enable

3.1.9.2 Port Configuration

The parameters of Loopback-Detection should be set for each port.



Notice: If you need to configure Loopback-Detection Port Configuration, you must enable the Loopback-Detection Global mode.

Loopback-Detection Port Configuration					
	Interface	terface Port Control Recovery Mode Recovery Interval			
		- •	-		
	0/1	Disable	Manual	300	
	0/2	Disable	Manual	300	
	0/3	Disable	Manual	300	
	0/4	Disable	Manual	300	
	0/5	Disable	Manual	300	
	0/6	Disable	Manual	300	
	0/7	Disable	Manual	300	
	0/8	Disable	Manual	300	
	po1	Disable	Manual	300	
	po2	Disable	Manual	300	
	ро3	Disable	Manual	300	

Loopback-Detection Port Configuration

Apply Refresh

Loopback-Detection Port Configuration

Description	Factory default
Interface	
The interface number.	interface number
Port Control	
Enable/Disable the Loopback-Detection feature on the port.	Disable
Recovery Mode	
 There are two recovery modes for recovering the blocking port. Loops occur as the reason for blocking the port. Auto Mode: After the port is blocked, the port will be automatically linked up after a recovery interval. Manual Mode: After the port is blocked, we have to manually enable the port. Follow Basic Setting > Port Setting > Port Settings (Admin Mode) to enable the 	Manual
blocking port.	
Recovery Interval	
In Auto Mode, the blocking port will be linked up after a recovery interval. The unit is a second and the range is between 30 and 38400.	300

3.1.10 EtherNet/IP

The module status of EtherNet/IP is used to enable/disable the EtherNet/IP feature. If you need to set parameters, please refer to Appendix C EtherNet/IP.

EtherNet/IP Configura	ation		
EtherNet/IP Configuratio	n		
EtherNet/IP Status	🔘 Disable	Enable	
	Cancel A	ylqq	

Click Apply to cause the changes and occurring on the switch.

3.2 SNMP Manager

Simple Network Management Protocol (SNMP) is an application protocol used for exchanging management information between network devices. SNMP is a member of the TCP/IP protocol suite. SNMP v1, v2c and v3 are supported on the Delta switch, and it is enabled by default.

The Delta switch supports standard public MIBs for standard functionality and private MIBs that provide additional functionality. You can use SNMP to enable or disable authentication traps, cold-start and warm-start functionality traps, link up and link down traps, Spanning Tree Protocol (STP) traps, SFP traps, and password and IP address change traps.

IMPORTANT:

Make sure that you save the configuration in the Save Configuration page after you have applied the configuration changes. (Save Config \rightarrow Save Configuration) If you do not save the configuration, then the configuration will be cleared after the switch is rebooted.

3.2.1 SNMP v1/v2c

SNMP version 1 (SNMP v1) is the initial implementation of the SNMP protocol. The authentication of clients is performed by a "community string", like a type of password, which is transmitted in clear text.

SNMP v2c revises version 1 and includes improvements of performance, security, confidentiality, and manager-to-manager communications. It adds a GetBulkRequest command; it sends iterative GetNextRequests for retrieving large amounts of management data in a single request.

3.2.1.1 Community Configuration

There are two default communities preconfigured for SNMP v1 and SNMP v2c:

- public: All IP addresses can be accessed with a read-only permission.
- private: All IP addresses can be accessed with a read/write permission.

Community Configuration

Co	Community Configuration				
	Community Name	Client Address	Client IP Mask	Access Mode	
				- 🔻	
	public	0.0.0.0	0.0.0.0	ReadOnly	
	private	0.0.0.0	0.0.0	ReadWrite	
Add Cancel Delete Anniv					

Community Configuration

Description	Factory default
Community Name	
Enter a case-sensitive string. The maximum length is 16 characters. The maximum	Nono
community is 10.	None
Client Address	
Enter the client's IP address. Any IP address can be accessed if the IP address is	0000
0.0.0.0.	0.0.0
Client IP Mask	
Enter the client's IP mask. All addresses allow accesses that are associated with a	
single client's IP address.	
For example, the client's IP address is 192.168.1.X, and its subnet mask is	0000
255.255.255.0. If the client's IP address is between 192.168.1.0 and 192.168.1.255, it	0.0.0.0
is allowed to be accessed. If the client's IP address is 192.168.1.15, and its subnet	
mask is 255.255.255.255, only this client allows to be accessed.	
Access Mode	
Specify the access mode:	None

	Description	Factory default
•	ReadOnly: Only allow the client to read information.	
•	ReadWrite: Only allow the client to read information and modify configuration.	



Notice:

The client address and client IP mask denote a range of IP addresses from which the SNMP clients can access the community on the switch.

3.2.1.2 Trap Configuration

If network engineers need to get information from an SNMP agent (network device), they usually use the SNMP software to poll information and get a response from an agent. But the SNMP Trap is the unsolicited trap which sends from the agent to the NMS (Network Management System). The operating theory is shown in the figure below.



An SNMP agent sends SNMP trap messages to the trap community (trap receiver). It monitors the switch for particular events or conditions, and generates trap messages based on these events or conditions.

Trap Configuration

Trap Configuration					
	Community Name	Version	Protocol	Address	
		- •	- 🔻		
	Ad	id Cancel I	Delete Aj	עוקט	

Trap Configuration

Description	Factory default	
Community Name		
Enter a case-sensitive string. The maximum length is 16 characters. The maximum	Nono	
trap is 10.	None	
Version		
Specify the SNMP version that is used for the trap community:		
• SNMP v1: Uses SNMP v1 to send traps to the trap community.	None	
SNMP v2c: Uses SNMP v2c to send traps to the trap community.		

Description	Factory default
Protocol	
Specify the IP version that is used for the trap community:	
• IPv4: Sends traps to an IPv4 address. Input an IPv4 address in the Address field.	None
• IPv6: Sends traps to an IPv6 address. Input an IPv6 address in the Address field.	
Address	
Enter an IPv4 or IPv6 address according to the selection in the Protocol drop-down list.	
For an IPv6 address, enter the address in the field	None
XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX	

3.2.1.3 Trap Flags

After you configure the trap communities, you also need to configure the SNMP traps which the switch can generate and send. When the switch detects the active trap which is an identified condition, a trap will be sent to the trap communities. **Trap Flags**

Trap Flags				
Authentication	۲	Enable	\bigcirc	Disable
Cold Start	۲	Enable	\bigcirc	Disable
Warm Start	۲	Enable	\bigcirc	Disable
Link Up/Down	۲	Enable	\bigcirc	Disable
Spanning Tree	\bigcirc	Enable	۲	Disable
Password Change	0	Enable	۲	Disable
IP Address Change	۲	Enable	\bigcirc	Disable
Loopback-Detection	۲	Enable	\bigcirc	Disable
Redundancy	۲	Enable	\bigcirc	Disable
POOLUTL	\bigcirc	Enable	۲	Disable
				1
	Cancel	App	Jy -	

Trap Flags

Description	Factory default
Authentication	
Specify whether authentication traps are enabled.	
• Enable: Specify the switch which sends authentication trap messages.	Enable
• Disable: Specify the switch which does not send authentication trap messages.	
Cold Start	
Specify whether cold-start traps are enabled.	
• Enable: Specify the switch which sends cold-start trap messages.	Enable
• Disable: Specify the switch which does not send cold-start trap messages.	
Warm Start	
Specify whether warm-start traps are enabled.	
• Enable: Specify the switch which sends warm-start trap messages.	Enable
• Disable: Specify the switch which does not send warm-start trap messages.	
Link Up/Down	
Specify whether link status traps are enabled.	
• Enable: Specify the switch which sends link status trap messages when a link	Frabla
comes up or goes down. This is the default setting.	Enable
• Disable: Specify the switch which does not send link status trap messages.	
Spanning Tree	
Specify whether spanning tree traps are enabled.	Disable

Description	Factory default
• Enable: Specify the switch which sends spanning tree trap messages.	
• Disable: Specify the switch which does not send spanning tree trap messages.	
Password Change	
Specify whether Password Change traps are enabled.	
• Enable: Specify the switch which sends Password Change trap messages.	Disable
• Disable: Specify the switch which does not send Password Change messages.	
IP Address Change	
Specify whether IP Address Change traps are enabled.	
• Enable: Specify the switch which sends IP Address Change trap messages.	Enable
• Disable: Specify the switch which does not send IP Address Change messages.	
Loopback-Detection	
Specify whether Loopback-Detection traps are enabled.	Enable
• Enable: Specify the switch which sends Loopback-Detection trap messages.	Enable
• Disable: Specify the switch which does not send Loopback-Detection messages	
Redundancy	
Specify whether Redundancy traps are enabled.	Enable
• Enable: Specify the switch which sends Redundancy trap messages.	LIIADIE
Disable: Specify the switch which does not send Redundancy messages	
POOLUTL	
Specify whether POOLUTL traps are enabled.	Dicabla
• Enable: Specify the switch which sends POOLUTL trap messages.	Disable
Disable: Specify the switch which does not send POOLUTL messages	

3.2.2 SNMP v3

SNMP v3 primarily added security and remote configuration enhancements. The authentication in SNMP v1 and v2c uses a password (community string) sent in clear text between a manager and an agent. But the SNMP v3 message contains security parameters which are encoded as an octet string. You can choose the authentication protocol which you need for each user account.

3.2.2.1 User Configuration

The following default users are preconfigured for SNMP v3:

- admin: All admin users can access data with the read/write permission.
- guest: All IP guest users can access data with the read-only permission. **SNMP User Configuration**

SNMP User Configuration						
	User Name	Authentication Protocol	Authentication Key	Private Protocol	Privacy Key	Access Mode
		- 🔻		- 🔻		- •
	admin	No Authentication		No Privacy		ReadWrite
	guest	No Authentication		No Privacy		ReadOnly

Add Cancel Delete Apply

SNMP User Configuration

Description	Factory default
User Name	
Enter a case-sensitive string. The maximum length is 32 characters.	None
Authentication Protocol	
Specify the authentication protocol, if any, for the user:	
• No Authentication: Users can access data without authentication. If you select this	
item, the Authentication Key, Privacy Protocol, and Privacy Key fields are masked	
out and can not be configured.	None
HMAC-MD5: Users are authenticated by Hash-based Message Authentication	NONE
Code (HMAC) with MD5. If you select this item, please enter a password in the	
Authentication Key field.	
HMAC-SHA: Users are authenticated by HMAC with SHA-1. If you select this item,	

Description	Factory default
please enter a password in the Authentication Key field.	
Authentication Key	
If the authentication protocol is HMAC-MD5 or HMAC-SHA, please enter a	Nana
case-sensitive string for the password. The maximum length is 40 characters.	none
Private Protocol	
If the authentication protocol is HMAC-MD5 or HMAC-SHA, you can specify whether to	
use an SNMP v3 privacy protocol (encryption) for the user:	
No Privacy: The users can access data without encryption.	None
• DES : User communication is encrypted by Data Encryption Standard (DES). You	
need to enter a password in the Privacy Key field.	
Privacy Key	
If the privacy protocol is DES, please enter a case-sensitive string for the password.	Nono
The maximum length is 40 characters.	None
Access Mode	
Specify the access mode:	
• ReadOnly: The client can only have read permission to get information.	Nana
• ReadWrite: The client can both have the read permission and the configuration	none
permission to modify the information.	

3.3 Network Redundancy

In some network environments, users need to set up redundant loops in the network to provide a backup path for disconnection or a network device breakdown. But if there are many network devices in the network, then each host needs to spend more time and cross many network devices to associate with each other. And sometimes the disconnection happens in a busy network, so the network must recover in a short time. Setting up redundancy on your network helps protect critical links against failure, protects against network loops, and keeps network downtime at a minimum. For example, if the Delta switch is used as a key communication component of a production line, several minutes of downtime may cause a big loss in production and revenue.

IMPORTANT:

Make sure that you save the configuration in the Save Configuration page after you have applied the configuration changes. (Save Config \rightarrow Save Configuration) If you do not save the configuration, then the configuration will be cleared after the switch is rebooted.

3.3.1 STP

Spanning Tree Protocol (STP) provides a tree topology that helps reduce link failure in a network, find one path between end devices and protect loops in the network. Bridge Protocol Data Unit (BPDU) includes the calculation of information and it is used to negotiate between switches and establish STP. STP is a bridge based system and it defines 5 kinds of port statuses: blocking, listening, learning, forwarding and disabling. If the status of the blocking changes to forwarding, STP needs to spend more than 30 seconds.

Rapid Spanning Tree Protocol (RSTP) was defined by IEEE in 2001. RSTP provides faster tree convergence after a topology changes. Sometimes it only needs to spend a few hundred milliseconds. And RSTP can be backward compatible with standard STP.

Delta switch supports different protocols to support communication redundancy. When configuring a redundant ring, all switches on the same ring must be configured to use the same redundant protocol.

STP/RSTP can let you establish a redundant ring and protect the loop in a network, as shown in the figure below.



If STP/RSTP is enabled, it will detect duplicate paths, calculate the cost of each path and block the lowest cost path (ex. the path between A and C) from forwarding traffic. So bridges can communicate with each other without loops, as shown in the figure below.



If the link failure is detected between bridge B and bridge C, STP/RSTP will start to reconfigure the network, as shown in the figure below.



Then the traffic between bridge B and bridge C will flow through bridge A, as shown in the figure below. Bridge A



But STP/RSTP can not support more VLANs in your network topology. If there are 2 VLANs between 2 bridges, one path is blocked when STP/RSTP is enabled. So IEEE defined an extension to RSTP to further develop the usefulness of VLANs.



Multiple Spanning Tree Protocol (MSTP) is an extension protocol of RSTP. It can provide an independent spanning tree for different VLANs. MSTP builds a separate Multiple Spanning Tree (MST) for each instance. And MST Region may include multiple MSTP instances. The operating theory is shown in the figure below.





3.3.1.1 STP Configuration

STP Configuration

Global Settings			
Spanning Tree Admin Mode	🔘 Disable	Enable	
Force Protocol Version	STP	RSTP	MSTP
Configuration Name	00:18:23:01	:08:60	
Configuration Revision Level	0	(0 to 65	535)
Forward BPDU while STP Disabled	Oisable	🔘 Enable	
Configuration Digest Key	0xac36177f50)283cd4b83821d8ab2	26de62
Configuration Format Selector	0		

Global Settings Description

Description	Factory default
Spanning Tree Admin Mode	
Specify the admin mode of STP on the switch:	
• Disable: STP is disabled. The settings do not take effect after you have	
applied them, but you still can configure STP.	Enable
Enable: STP is enabled. The settings take effect after you have applied	
them.	
Force Protocol Version	
Specify the version of the STP protocol:	
STP: Spanning Tree Protocol.	MOTO
RSTP: Rapid Spanning Tree Protocol.	INISTP
MSTP: Multiple Spanning Tree Protocol.	
Configuration Name	
Enter the STP identifier for the switch. You can configure alphanumeric characters	MAC address of
and special characters, and the maximum length is 32.	the switch
Configuration Revision Level	
Enter an identifier that specifies the current configuration. The number must be in the	0
range of 0 to 65535.	0
Forward BPDU while STP Disabled	
Specify whether spanning tree bridge protocol data units (BPDUs) are forwarded:	Diachla
• Disable: When STP is disabled, Spanning tree BPDUs are not forwarded.	Disable

Description	Factory default
• Enable: When STP is disabled, Spanning tree BPDUs are forwarded.	
Configuration Digest Key	
This field displays a calculated value from the MSTP configuration. The switches are	Fixed
qualified by the key and the function in the same region.	Fixeu
Configuration Format Selector	
This field displays the configuration identifier format selector that is used.	0

STP Status			
MST ID	VID	FID	
0	1	1	

Refresh Cancel Apply

STP Status

Description	Factory default
MST ID	
The ID of the MST instance	0
VID	
The VLAN ID	1
FID	
The filtering ID (FID)	1

3.3.1.2 CST Configuration

Internal Spanning Tree (IST) is one of spanning trees in the MST region. Common Spanning Tree (CST) interconnects ISTs in the MST region. And Common and Internal Spanning Tree (CIST) consist of IST and CST. The operating theory is shown in the figure below.



CST Configuration

CST Configuration				
Bridge Priority	32768	(0 to 61440)		
Bridge Max Age (secs)	20	(6 to 40)		
Bridge Hello Time (secs)	2	(1 to 2)		
Bridge Forward Delay (secs)	15	(4 to 30)		
Spanning Tree Maximum Hops	20	(6 to 40)		
Dynamic Path Cost	💿 Disable 🛛 🔿 Enabl	e		
Extend System ID Status	💿 Disable 🛛 🔘 Enabl	e		

CST Status	
Bridge Identifier	80:00:00:11:22:33:44:55
Time Since Topology Change	0 day 3 hr 49 min 48 sec
Topology Change Count	1
Designated Root	80:00:00:11:22:33:44:55
Root Path Cost	0
Root Port Identifier	00:00
Max Age (secs)	20
Forward Delay (secs)	15
Hold Time (secs)	1
CST Regional Root	80:00:00:11:22:33:44:55
CST Path Cost	0

Refresh Cancel Apply

CST Configuration

Description	Factory default			
Bridge Priority				
Each switch or bridge is assigned a priority when they are running STP. After the devices exchange BPDUs, the lowest priority value becomes the root bridge. Enter the bridge priority value for the CIST. Enter a number that is a multiple of 4096 and it must be in the range of 0 to 61440.	32768			
Bridge Max Age (secs)				
Enter the maximum age time for the CIST in seconds. This time is the period that a STP bridge or switch waits before implementing a topological change. The device will recognize itself as a root if it does not receive a hello message in the time of Bridge Max Age. Enter a number in the range of 6 to 40 seconds, considering that the period needs to be less than or equal to 2 *(Bridge Forward Delay–1) and greater than or equal to 2 * (Bridge Hello Time +1).	20			
Bridge Hello Time (secs)				
The switch hello time for the CIST. This time is the period in seconds that a root bridge waits between configuration messages. The value is fixed at 2 seconds.	2			
Bridge Forward Delay (secs)				
Enter the switch forward delay time, which is the period in seconds that a bridge remains in a listening and learning state before forwarding packets. Enter a number in the range of 4 to 30 seconds, considering that the period needs to be greater than or equal to (Bridge Max Age / 2) + 1.	15			
Spanning Tree Maximum Hops				
Enter the maximum number of bridge hops; the information for a CST instance can travel before being discarded. Enter a number in the range of 6 to 40.	20			

Description	Factory default
Dynamic Path Cost	
Specify whether the path cost is automatically calculated by selecting one of the	Diachla
following radio buttons:	
Disable: The path cost is not automatically calculated.	Disable
Enable: The path cost is automatically calculated.	
Extend System ID Status	
Specify whether the extended system identifier is added to the bridge priority by	
selecting one of the following radio buttons:	
• Disable: The extended system identifier is not added to the bridge priority.	Disable
Enable: The extended system identifier is added to the bridge priority. For	Disable
example, bridge priority is 32768, for VLAN 1, the priority will be 32768+1;	
for VLAN 2, the priority will be 32768+2.	

CTS Status

Description	Factory default
Bridge Identifier	
The STP bridge identifier for the Common Spanning Tree (CST) on the switch. The	
identifier consists of the bridge priority and the base (fixed) MAC address of the switch.	
Time Since Topology Change	
The time that has passed since the last change of the CST topology occurred. The	day-hour-minute-s
time is displayed in the day-hour-minute-second format.	econd
Topology Change Count	
The number of times the CST topology has changed.	0
Designated Root	
The STP bridge identifier of the root bridge. The identifier consists of the bridge priority	MAC address
and the base MAC address of the root bridge.	MAC address
Root Path Cost	
The path cost to the designated root for the CST.	0
Root Port Identifier	
The interface that provides access to the designated root for the CST.	00:00
Max Age (secs)	
The timer that controls the maximum time that passes before an STP bridge port saves	20
its configuration BPDU.	20
Forward Delay (secs)	
The value that is derived from the bridge forward delay parameter of the STP root port.	15
Hold Time (secs)	
The minimum period between the transmissions of configuration BPDUs.	1
CST Regional Root	
The priority and the base MAC address of the CST regional root.	MAC address
CST Path Cost	·
The path cost to the CST tree regional root.	0

3.3.1.3 CST Port Configuration

CST Port Configuration

CST Port Configuration								
	Interface	Port Priority	Admin Edge Port	Port Path Cost	Auto Calculated Port Path Cost	Hello Time		
			- 🔻					
	0/1	128	Disable	20000	Disabled	2		
	0/2	128	Disable	20000	Disabled	2		
	0/3	128	Disable	20000	Disabled	2		
	0/4	128	Disable	200000	Disabled	2		
	0/5	128	Disable	20000	Disabled	2		
	0/6	128	Disable	200000	Disabled	2		
	0/7	128	Disable	20000	Disabled	2		
	0/8	128	Disable	20000	Disabled	2		
	po1	128	Disable	10000	Disabled	2		
	po2	128	Disable	10000	Disabled	2		
	po3	128	Disable	10000	Disabled	2		

BPDU Forwarding	Auto Edge	Root Guard	TCN Guard	Port Mode	Port Forwarding State	Protocol Migration	PointToPoint Status
- •	- •	- •	- •	· •			- •
Disable	Enable	Disable	Disable	Enable	Discarding	False	Auto
Disable	Enable	Disable	Disable	Enable	Discarding	False	Auto
Disable	Enable	Disable	Disable	Enable	Discarding	False	Auto
Disable	Enable	Disable	Disable	Enable	Discarding	False	Auto
Disable	Enable	Disable	Disable	Enable	Discarding	False	Auto
Disable	Enable	Disable	Disable	Enable	Forwarding	False	Auto
Disable	Enable	Disable	Disable	Enable	Discarding	False	Auto
Disable	Enable	Disable	Disable	Enable	Discarding	False	Auto
Disable	Enable	Disable	Disable	Enable	Discarding	False	Auto
Disable	Enable	Disable	Disable	Enable	Discarding	False	Auto
Disable	Enable	Disable	Disable	Enable	Discarding	False	Auto

Apply Refresh
CST Port Configuration

Interface interface This field displays the interface number or port channel number. interface number Port Priority Enter the priority for the interface in the CIST. Enter a value between 0 and 240 that is a numble of 16. The default priority is 128. 128 Admin Edge Port All ports directly connected to end stations can not create bridging loops in the network. Therefore, the edge port directly changes to the forwarding state, and skips the listening and learning stages. Specify whether the interface is an edge port in the CIST. Disable • Enable: The interface is an edge port. • Disable: The interface is not an edge port. Disable Port Part Cost Eave the existing path cost, or enters a new path cost that is used for the interface in the CIST. Enter a number in the range of 1 to 200,000,000. Enter a blank (that is, remove the number and make sure that there is no space character in the field) to reset the path cost. 20000 Auto Calculated Port Path Cost Ibisable Disable Heilo Time The hello time for the interface in the CIST. This time is the period in seconds that the interface sets the molex flag to forward BPDUS: 2 Post Path Cost Ibisable 2 EPDU Forwarding Disable Disable Specify whether the interface in the CIST. This time is the period in seconds that the interface in the first aco sets the molex of gas to troward BPDUS: <	Description	Factory default
This field displays the interface number or port channel number. Interface number Port Priority Interface number Port Priority Interface number Port Priority Interface number Enter the priority for the interface in the CIST. Enter a value between 0 and 240 that is a multiple of 16. The default priority is 128. Interface number Admin Edge Port Interface number in the network. Therefore, the edge port directly changes to the forwarding state, and skips the listering and learning stages. Specify whether the interface is an edge port in the CIST. Disable: The interface is not an edge port. Port Path Cost Interface number in the range of 1 to 200,000,000. Enter a blank (that is, remove the number and make sure that there is no space character in the field) to reset the path cost. 20000 Post Calculated Port Path Cost Interface in the CIST. This time is the period in seconds that the interface with barb cost. Disable This field one for the interface in the CIST. This time is the period in seconds that the interface walts between configuration messages. Enter 1 or 2 seconds. 2 Notice: Notice: 2 You can set the hello time only when the STP operation mode is MSTP. Disable EPDU Forwarding Enable: Depending on the STP operation mode is MSTP. Specify whether the interface bar on the core of nowarded. Disable O	Interface	
Port Priority Enter the priority for the interface in the CIST. Enter a value between 0 and 240 that is a multiple of 16. The default priority is 128. 128 Admin Edge Port Image: Comparison of the edge port directly changes to the forwarding state, and skips the listening and learning stages. Specify whether the interface is an edge port in the CIST. Image: Comparison of the edge port directly changes to the forwarding state, and skips the listening and learning stages. Specify whether the interface is an edge port. Disable: The interface is not an edge port. Port Path Cost Image: Comparison of the compariso	This field displays the interface number or port channel number.	interface number
Enter the priority for the interface in the CIST. Enter a value between 0 and 240 that is 128 Admin Edge Port All ports directly connected to end stations can not create bridging loops in the network. Therefore, the edge port directly changes to the forwarding state, and skips the listening and learning stages. Specify whether the interface is an edge port. Disable: Port Path Cost Disable: The interface is not an edge port. Disable: Port Path Cost Eave the existing path cost, or enters a new path cost that is used for the interface in the CIST. Enter a number in the range of 1 to 200,000,000. Enter a blank (that is, remove the number and make sure that there is no space character in the field) to reset the path cost. 20000 Auto Calculated Port Path Cost This field shows whether you have globally enabled or disabled the dynamic path cost on the CST Configuration screen. Disable Helio Timer Notice: You can set the helio time only when the STP operation mode is MSTP. 2 BPUD Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable Specify whether the interface can enter the discarding state. Enable: Enable: Specify whether the interface can enter the discarding state. Enable Enable: Port Cost Configuration screen. Enable Enable Specify	Port Priority	
a multiple of 16. The default priority is 128. Admin Edge Port All ports directly connected to end stations can not create bridging loops in the network. Therefore, the edge port directly changes to the forwarding state, and skips the listening and learning stages. Specify whether the interface is an edge port in the CIST: • Enable: The interface is an edge port. Port Path Cost Leave the existing path cost, or enters a new path cost that is used for the interface in the CIST. Enter a number in the range of 1 to 200,000,000. Enter a blank (that is, remove the number and make sure that there is no space character in the field) to reset the path cost. Auto Calculated Port Path Cost This field shows whether you have globally enabled or disabled the dynamic path cost on the CST. Configuration screen. Helio Timer The helio time for the interface in the CIST. This time is the period in seconds that the interface waits between configuration messages. Enter 1 or 2 seconds. Notice: You can set the helio time only when the STP operation mode is MSTP. BPDU Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: • Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Auto Edge Specify whether the interface becomes an edge port. • Disable: The interface becomes an edge port. • Disable: The interface becomes an edge port. • Disable: The interface can enter the discarding state, • Disable: The interface can enter the discarding state. • Disable: The interface can enter the discarding state. • Disable: The interface can enter the discarding state. • Disable: The interface can enter the discarding state. • Disable: The interface can enter the discarding state. • Disable: The interface can enter the discarding state. • Disable: The interface can enter the discarding state. • Disable: The interface can enter the discarding state. • Disable: The interface can enter the discarding state. • Disable: The interface can enter the discarding state. • Disable: The interface can enter the dis	Enter the priority for the interface in the CIST. Enter a value between 0 and 240 that is	100
Admin Edge Port All ports directly connected to end stations can not create bridging loops in the network. Therefore, the edge port directly changes to the forwarding state, and skips the listening and learning stages. Specify whether the interface is an edge port in the CIST: Disable: The interface is an edge port. Port Path Cost Eave the existing path cost, or enters a new path cost that is used for the interface in the CIST. Enter a number in the range of 1 to 200,000,000. Enter a blank (that is, remove the number and make sure that there is no space character in the field) to reset the path cost. 20000 Auto Calculated Port Path Cost This field shows whether you have globally enabled or disabled the dynamic path cost on the CST. Configuration screen. Disable: Helio Timer The helio time for the interface in the CIST. This time is the period in seconds that the interface wills between configuration messages. Enter 1 or 2 seconds. 2 Notice: Notice: Disable You can set the helio time only when the STP operation mode is MSTP. Disable BPDU Forwarding Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Enable: • Disable: The interface boxens an edge port. Enable: Disable Poscify whether the interface boxens an edge port. Enable: Enable: Specify whether the interface boxens an edge port. Enable: Disable: Specify whether the tonet	a multiple of 16. The default priority is 128.	120
All ports directly connected to end stations can not create bridging loops in the network. Therefore, the edge port directly changes to the forwarding state, and skips the listening and learning stages. Specify whether the interface is an edge port in the CIST. Disable: The interface is not an edge port. Port Path Cost Eave the existing path cost, or enters a new path cost that is used for the interface in the CIST. Enter a number in the range of 1 to 200,000,000. Enter a blank (that is, remove the number and make sure that there is no space character in the field) to reset the path cost. 20000 Auto Calculated Port Path Cost This field shows whether you have globally enabled or disabled the dynamic path cost on the CST Configuration screen. Disable Hello Timer The hello time for the interface in the CIST. This time is the period in seconds that the interface withs between configuration messages. Enter 1 or 2 seconds. 2 Motice: You can set the hello time only when the STP operation mode is MSTP. 2 BPDU Forwarding Disable Disable Specify whether the interface automatically becomes an edge port if it does not process BPDUs for a while: Enable: Second any superior information neceived by the interface can end edge port. Enable Specify whether the root guard mode can cause the interface to discard any superior information received by the interface can enter the discarding state. Disable Disable: The interface can enter the discarding state. Disable Port Surd Caud </td <td>Admin Edge Port</td> <td></td>	Admin Edge Port	
network. Therefore, the edge port directly changes to the forwarding state, and skips the listening and learning stages. Specify whether the interface is an edge port in the CIST: Enable: The interface is an edge port. Disable: The interface is not an edge port. Port Path Cost Leave the existing path cost, or enters a new path cost that is used for the interface in the CIST. Enter a number in the range of 1 to 200,000,000. Enter a blank (that is, remove the number and make sure that there is no space character in the field) to reset the path cost. Auto Calculated Port Path Cost This field shows whether you have globally enabled or disabled the dynamic path cost on the CST Configuration screen. Hello Timer Notice: Notice: Notice: Notice: Specify whether the interface is the CIST. This time is the period in seconds that the interface waits between configuration messages. Enter 1 or 2 seconds. Emable: Depending on the STP operation mode is MSTP. BPUD Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable Disable: BPUs are not forwarded. Auto Edge Specify whether the interface becomes an edge port. Enable: The interface becomes an edge port. Enable: The interface on prevent the root of the device from changing. When this situation occurs, the interface to glocarding state. Disable: The interface can enter the discarding state. Disable: The interface can enter the discarding state. Disable: The interface can not enter discarding state. Di	All ports directly connected to end stations can not create bridging loops in the	
the listening and learning stages. Specify whether the interface is an edge port in the CIST: • Enable: The interface is an edge port. Port Path Cost Port Path Cost Leave the existing path cost, or enters a new path cost that is used for the interface in the CIST. Enter a number in the range of 1 to 200,000,000. Enter a blank (that is, remove the number and make sure that there is no space character in the field) to reset the path cost. Auto Calculated Port Path Cost This field shows whether you have globally enabled or disabled the dynamic path cost on the CST Configuration screen. Hello Timer The hello time for the interface in the CIST. This time is the period in seconds that the interface waits between configuration messages. Enter 1 or 2 seconds. Notice: You can set the hello time only when the STP operation mode is MSTP. BPDU Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: • Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. • Disable: BPDUs are not forwarded. Auto Edge Specify whether the interface becomes an edge port if it does not process BPDUs for a while: • Enable: The interface does not become an edge port. • Disable: The interface does not become an edge port. • Disable: The interface con not enter discarding state. • Disable: The interface con propagate the topology change information. • Disable: The interface con propagate to true, the port will not flush ins ins MAC address table and send out a BPDU with a topology change information. • Disable: The interface can propagate the topology change information. • Disable: The interface can propagate the topology change i	network. Therefore, the edge port directly changes to the forwarding state, and skips	
Enable: The interface is an edge port. Disable: The interface is not an edge port. Port Path Cost Leave the existing path cost, or enters a new path cost that is used for the interface in the CIST. Enter a number in the range of 1 to 200,000,000. Enter a blank (that is, remove the number and make sure that there is no space character in the field) to reset the path cost. Auto Calculated Port Path Cost This field shows whether you have globally enabled or disabled the dynamic path cost on the CST Configuration screen. Hello Timer The hello time for the interface in the CIST. This time is the period in seconds that the interface waits between configuration messages. Enter 1 or 2 seconds. Notice: You can set the hello time only when the STP operation mode is MSTP. BPDU Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: • Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable: BPDUs are not forwarded. Auto Edge Specify whether the interface becomes an edge port. • Disable: The interface becomes an edge port. • Disable: The interface becomes an edge port. • Disable: The interface to prevent the root of the device from changing. When this situation occurs, the interface enters the discarding state and no longer forwards any packets: • Enable: The interface can enter the discarding state. TCN Guard Specify whether the topology change notification (TCN) guard restricts the interface forwards any packets: • Enable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information.	the listening and learning stages. Specify whether the interface is an edge port in the CIST	Disable
Disable: The interface is not an edge port. Port Path Cost Leave the existing path cost, or enters a new path cost that is used for the interface in the CIST. Enter a number in the range of 1 to 200,000,000. Enter a blank (that is, remove the number and make sure that there is no space character in the field) to reset the path cost. Auto Calculated Port Path Cost This field shows whether you have globally enabled or disabled the dynamic path cost on the CST Configuration screen. Hello Timer The hello time for the interface in the CIST. This time is the period in seconds that the interface waits between configuration messages. Enter 1 or 2 seconds. Notice: Notice: Notice: Notice: Port Notice: Port Path Cost Specify whether the interface sets the mcheck flag to forward BPDUs: Fabble: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable: BPDUs are not forwarded. Auto Edge Specify whether the interface becomes an edge port. Disable: The interface becomes an edge port. Disable: The interface to grave the discarding state. Cost Guard Specify whether the root guard mode can cause the interface to discard any superior information received by the interface can enter the discarding state. Cost Guard Specify whether the topology change notification (TCN) guard restricts the interface Disable Disable Disable: Cost Guard Specify whether the topology change information. Disable: The interface can not propagate the topology change flag set to true. Cost Guard Specify whether the topology change information. Disable: The interface can not propagate the topology change flag set to true. Cost Guard Specify whether the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change inf	Enable: The interface is an edge port.	
Port Path Cost 20000 Leave the existing path cost, or enters a new path cost that is used for the interface in the CIST. Enter a number in the range of 1 to 200,000,000. Enter a blank (that is, remove the number and make sure that there is no space character in the field) to reset the path cost. 20000 Auto Calculated Port Path Cost Disable This field shows whether you have globally enabled or disabled the dynamic path cost on the CST Configuration screen. Disable Hello Timer The hello time for the interface in the CIST. This time is the period in seconds that the interface waits between configuration messages. Enter 1 or 2 seconds. 2 Notice: You can set the hello time only when the STP operation mode is MSTP. 2 BPDU Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable: BPDUs are not forwarded. Auto Edge Specify whether the interface automatically becomes an edge port. Disable: The interface does not become an edge port. Disable: The interface can not prevent the root of the device from changing. When this situation occurs, the interface to enters the discarding state. Disable: The interface can not enter discarding state. Disable: The interface can not enter discarding state. Disable: The interface can not enter discarding state. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology	Disable: The interface is not an edge port.	
Leave the existing path cost, or enters a new path cost that is used for the interface in 20000 the CIST. Enter a number in the range of 1 to 200,000,000. Enter a blank (that is, remove the number and make sure that there is no space character in the field) to reset the path cost. 20000 Auto Calculated Port Path Cost Disable This field shows whether you have globally enabled or disabled the dynamic path cost on the CST Configuration screen. Disable Hello Timer The hello time for the interface in the CIST. This time is the period in seconds that the interface waits between configuration messages. Enter 1 or 2 seconds. 2 Notice: You can set the hello time only when the STP operation mode is MSTP. 2 BPDU Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: Disable • Disable: BPDUs are not forwarded. Disable Disable Auto Edge Specify whether the interface automatically becomes an edge port if it does not process BPDUs for a while: Enable: The interface does not become an edge port. Enable • Disable: The interface does not become an edge port. Enable Disable • Root Guard Specify whether the root guard mode can cause the interface to discard any superior information received by the interface on prevent the root of the device from changing. When this situation occurs, the interface on revert the discarding state. Disable	Port Path Cost	
the CIST. Enter a number in the range of 1 to 200,000,000. Enter a blank (that is, remove the number and make sure that there is no space character in the field) to reset the path cost. 20000 Auto Calculated Port Path Cost Disable This field shows whether you have globally enabled or disabled the dynamic path cost on the CST Configuration screen. Disable Hello Timer The hells time for the interface in the CIST. This time is the period in seconds that the interface waits between configuration messages. Enter 1 or 2 seconds. 2 Notice: You can set the hello time only when the STP operation mode is MSTP. 2 BPDU Forwarding Disable Disable Specify whether the interface automatically becomes an edge port if it does not provess BPDUs for a while: Disable: Enable: The interface automatically becomes an edge port. Disable • Disable: The interface automatically becomes an edge port. Enable Enable • Disable: The interface does not become an edge port. Enable Disable • Disable: The interface can enter the discarding state and no longer forwards any packets: Disable Disable • Disable: The interface can not enter discarding state. Disable Disable Portored Guard Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change flag set to true, the port will not flush its MAC addr	Leave the existing path cost, or enters a new path cost that is used for the interface in	
remove the number and make sure that there is no space character in the field) to 20000 reset the path cost. Auto Calculated Port Path Cost Disable This field shows whether you have globally enabled or disabled the dynamic path cost on the CST Configuration screen. Disable Hello Timer The hello time for the interface in the CIST. This time is the period in seconds that the interface waits between configuration messages. Enter 1 or 2 seconds. 2 Notice: You can set the hello time only when the STP operation mode is MSTP. 2 BPDU Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: Disable: • Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable • Disable: BPDUS are not forwarded. Enable: Auto Edge Specify whether the interface automatically becomes an edge port if it does not process BPDUs for a while: Enable: The interface does not become an edge port. • Disable: The interface does not become an edge port. Enable Disable Specify whether the rot og uard mode can cause the interface to discard any superior information received by the interface can enter the discarding state and no longer forwards any packets: Enable: The interface can not enter discarding state. • Disable: The interface can not enter discarding state. Disable Disable • Enable: The	the CIST. Enter a number in the range of 1 to 200,000,000. Enter a blank (that is,	00000
reset the path cost. Auto Calculated Port Path Cost This field shows whether you have globally enabled or disabled the dynamic path cost on the CST Configuration screen. Hello Timer The hello time for the interface in the CIST. This time is the period in seconds that the interface waits between configuration messages. Enter 1 or 2 seconds. Notice: You can set the hello time only when the STP operation mode is MSTP. BPDU Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable: BPDUs are not forwarded. Auto Edge Specify whether the interface becomes an edge port if it does not process BPDUs for a while: Enable: The interface becomes an edge port. Specify whether the root guard mode can cause the interface to discard any superior information received by the interface to prevent the root of the device from changing. When this situation occurs, the interface can enter the discarding state. Disable: The interface can enter the discarding state. CTCN Guard Specify whether the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true. Enable: The interface can not propagate the topology change flag set to true. Enable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The inte	remove the number and make sure that there is no space character in the field) to	20000
Auto Calculated Port Path Cost Disable This field shows whether you have globally enabled or disabled the dynamic path cost on the CST Configuration screen. Disable Hello Time The hells time for the interface in the CIST. This time is the period in seconds that the interface waits between configuration messages. Enter 1 or 2 seconds. 2 Notice: You can set the hello time only when the STP operation mode is MSTP. 2 BPDU Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: • Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable • Disable: BPDUs are not forwarded. Disable Disable Auto Edge Specify whether the interface becomes an edge port. Enable • Disable: The interface becomes an edge port. Enable Enable • Disable: The interface does not become an edge port. Enable Disable Root Guard Specify whether the root guard mode can cause the interface to discard any superior information received by the interface oprevent the root of the device from changing. Disable When this situation occurs, the interface can enter the discarding state. Disable Disable • Disable: The interface can enter the discarding state. Disable Disable • Disable: The interface can not enter discarding state. Disable	reset the path cost.	
This field shows whether you have globally enabled or disabled the dynamic path cost on the CST Configuration screen. Disable Hello Timer The hello time for the interface in the CIST. This time is the period in seconds that the interface waits between configuration messages. Enter 1 or 2 seconds. 2 Notice: You can set the hello time only when the STP operation mode is MSTP. 2 BPDU Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: • Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable Auto Edge Specify whether the interface automatically becomes an edge port if it does not process BPDUs for a while: • Enable: The interface becomes an edge port. Enable Notice: Specify whether the root guard mode can cause the interface to discard any superior information received by the interface to prevent the root of the device from changing. When this situation occurs, the interface con prevent the discarding state. Disable Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true. Disable Specify whether the interface can not propagate the topology change information. Disable	Auto Calculated Port Path Cost	
on the CST Configuration screen. Disable Hello Timer The hello time for the interface in the CIST. This time is the period in seconds that the interface waits between configuration messages. Enter 1 or 2 seconds. 2 Notice: You can set the hello time only when the STP operation mode is MSTP. 2 BPDU Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: • Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable • Disable: BPDUs are not forwarded. Disable Disable Specify whether the interface automatically becomes an edge port if it does not process BPDUs for a while: • Enable: The interface does not become an edge port. Enable Note Guard Specify whether the root guard mode can cause the interface to discard any superior information received by the interface to prevent the root of the device from changing. Disable When this situation occurs, the interface can enter the discarding state. Disable Disable Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change information. Disable Disable: The interface can not propagate the topology change information. Disable Disable <td>This field shows whether you have globally enabled or disabled the dynamic path cost</td> <td>D: 11</td>	This field shows whether you have globally enabled or disabled the dynamic path cost	D: 11
Hello Timer The hello time for the interface in the CIST. This time is the period in seconds that the interface waits between configuration messages. Enter 1 or 2 seconds. 2 Notice: You can set the hello time only when the STP operation mode is MSTP. 2 BPDU Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: • Disable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable: • Disable: BPDUs are not forwarded. Disable Disable Auto Edge Specify whether the interface becomes an edge port if it does not process BPDUs for a while: • Enable: The interface becomes an edge port. Enable Specify whether the root guard mode can cause the interface to discard any superior information received by the interface on provent the root of the device from changing. Disable When this situation occurs, the interface can not enter discarding state. • Disable: The interface can not enter discarding state. Disable • Enable: The interface can not enter discarding state. • Disable Disable Specify whether the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change information. Disable Oreatif Whether the interface can not propagate the to	on the CST Configuration screen.	Disable
The hello time for the interface in the CIST. This time is the period in seconds that the interface waits between configuration messages. Enter 1 or 2 seconds. 2 Notice: You can set the hello time only when the STP operation mode is MSTP. 2 BPDU Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: • Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable: BPDUs are not forwarded. Auto Edge Specify whether the interface automatically becomes an edge port if it does not process BPDUs for a while: • Enable: The interface becomes an edge port. Enable Root Guard Specify whether the root guard mode can cause the interface to discard any superior information received by the interface on provent the root of the device from changing. When this situation occurs, the interface can enter the discarding state. • Disable: The interface can enter the discarding state. Disable Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change flag set to true. • Enable: The interface can propagate the topology change flag set to true. • Enable: The interface can propagate the topology change information. Disable Disable Specify whether the topology change flag set to true. • Disable: The interface can propagate the topology change information. • Disable the interface can not propagate the topology change information. Disable	Hello Timer	
interface waits between configuration messages. Enter 1 or 2 seconds. 2 Notice: You can set the hello time only when the STP operation mode is MSTP. BPDU Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: Disable: • Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable: BPDUs are not forwarded. Auto Edge Specify whether the interface automatically becomes an edge port if it does not process BPDUs for a while: Enable: The interface becomes an edge port. • Disable: The interface does not become an edge port. Enable Root Guard Specify whether the root guard mode can cause the interface to discard any superior information received by the interface to prevent the root of the device from changing. Disable When this situation occurs, the interface can enter the discarding state. Disable CN Guard Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change flag set to true. Disable • Disable: The interface can propagate the topology change flag set to true. Disable • Enable: The interface can propagate the topology change flag set to true. Disable • Disable: The interface can not enter discarding state. Disable CN Guard Specify whether the topology change flag set to true. Disable	The hello time for the interface in the CIST. This time is the period in seconds that the	
Notice: You can set the hello time only when the STP operation mode is MSTP. BPDU Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: Image: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable: BPDUs are not forwarded. Auto Edge Specify whether the interface automatically becomes an edge port if it does not process BPDUs for a while: Enable: The interface becomes an edge port. Enable Notice: • Disable: The interface does not become an edge port. Enable Enable Root Guard Specify whether the root guard mode can cause the interface to discard any superior information received by the interface to prevent the root of the device from changing. Disable When this situation occurs, the interface and the discarding state and no longer forwards any packets: • Enable: The interface can not enter discarding state. Disable • Disable: The interface can not enter discarding state. • Disable: The interface can not enter discarding state. Disable • Disable: The interface can not enter discarding state. • Disable: The interface can not enter discarding state. Disable • Disable: The interface can not enter discarding state. • Disable Disable • Disable: The interface can propagate the topology change flag set to	interface waits between configuration messages. Enter 1 or 2 seconds.	0
You can set the hello time only when the STP operation mode is MSTP. BPDU Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable: BPDUs are not forwarded. Disable: BPDUs are not forwarded. Auto Edge Enable: The interface becomes an edge port if it does not process BPDUs for a while: Enable: The interface does not become an edge port. Disable: The interface does not become an edge port. Disable: The interface does not become an edge port. Enable Root Guard Specify whether the root guard mode can cause the interface to discard any superior information received by the interface enters the discarding state and no longer forwards any packets: Enable: The interface can enter the discarding state. Disable: The interface can not enter discarding state. Disable: The interface can not enter discarding state. Disable: The interface flag to further the root will not flush its MAC address table and send out a BPDU with a topology change flag set to true. Enable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Poisable: The interface can not propagate the topology change information. Poisable: The interface can not propagate the topology change information.	Notice:	Z
BPDU Forwarding Specify whether the interface sets the mcheck flag to forward BPDUs: Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable: BPDUs are not forwarded. Disable: BPDUs are not forwarded. Auto Edge Enable: The interface automatically becomes an edge port if it does not process BPDUs for a while: Enable: The interface becomes an edge port. Disable: The interface does not become an edge port. Root Guard Enable: Specify whether the root guard mode can cause the interface to discard any superior information received by the interface on prevent the root of the device from changing. When this situation occurs, the interface enters the discarding state and no longer forwards any packets: Enable: The interface can enter the discarding state. Disable: The interface can not enter discarding state. Disable: The interface can not enter discarding state. Disable: The interface can not enter discarding state. Yor Guard Specify whether the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change flag set to true. Enable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Poisable: The interface can not propagate the topology change information. Disable <td>You can set the hello time only when the STP operation mode is MSTP.</td> <td></td>	You can set the hello time only when the STP operation mode is MSTP.	
Specify whether the interface sets the mcheck flag to forward BPDUs: Disable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. • Disable: BPDUs are not forwarded. Disable: BPDUs are not forwarded. Auto Edge Enable: The interface automatically becomes an edge port if it does not process BPDUs for a while: Enable: The interface becomes an edge port. • Disable: The interface does not become an edge port. Enable Root Guard Specify whether the root guard mode can cause the interface to discard any superior information received by the interface on prevent the root of the device from changing. When this situation occurs, the interface can enter the discarding state and no longer forwards any packets: Disable: The interface can enter the discarding state. • Disable: The interface can onter the discarding state. Disable • Disable: The interface can onter the discarding state. Disable • Disable: The interface can onter the discarding state. Disable • Disable: The interface can not enter discarding state. Disable • Disable: The interface can propagate flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change flag set to true. Disable • Enable: The interface can not propagate the topology change information. Disable • Disable: The interface can not propagate the topology change information. Disable	BPDU Forwarding	
Enable: Depending on the STP operation mode, RST or MST BPDUs are forwarded. Disable: BPDUs are not forwarded. Disable: BPDUs are not forwarded. Auto Edge Specify whether the interface automatically becomes an edge port if it does not process BPDUs for a while: Enable: The interface becomes an edge port. Disable: The interface does not become an edge port. Disable: The interface does not become an edge port. Disable: The interface does not become an edge port. Specify whether the root guard mode can cause the interface to discard any superior information received by the interface to prevent the root of the device from changing. When this situation occurs, the interface enters the discarding state and no longer forwards any packets: Enable: The interface can enter the discarding state. Disable: The interface can ont enter discarding state. Disable: The interface can not enter discarding state. Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change flag set to true. Enable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface (STD) administrative mode that is associated with	Specify whether the interface sets the mcheck flag to forward BPDUs:	
forwarded. Disable: BPDUs are not forwarded. Auto Edge Specify whether the interface automatically becomes an edge port if it does not process BPDUs for a while: Enable: The interface becomes an edge port. Enable: The interface does not become an edge port. Enable: Root Guard Specify whether the root guard mode can cause the interface to discard any superior information received by the interface to prevent the root of the device from changing. Disable: When this situation occurs, the interface enters the discarding state and no longer forwards any packets: Enable: The interface can enter the discarding state. Disable: The interface can not enter discarding state. Disable: TCN Guard Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change information. Disable Nac address table and send out a BPDU with a topology change information. Disable Port Mode Spacify the Spanning Trap Brateel (STP) administrative mede that is accounted with	Enable: Depending on the STP operation mode, RST or MST BPDUs are	Disable
 Disable: BPDUs are not forwarded. Auto Edge Specify whether the interface automatically becomes an edge port if it does not process BPDUs for a while: Enable: The interface becomes an edge port. Disable: The interface does not become an edge port. Root Guard Specify whether the root guard mode can cause the interface to discard any superior information received by the interface on prevent the root of the device from changing. When this situation occurs, the interface enters the discarding state and no longer forwards any packets: Enable: The interface can enter the discarding state. Disable: The interface can not enter discarding state. Disable: The interface can not enter discarding state. Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. 	forwarded.	Disable
Auto Edge Specify whether the interface automatically becomes an edge port if it does not process BPDUs for a while: Enable: The interface becomes an edge port. Disable: The interface does not become an edge port. Enable Root Guard Enable Specify whether the root guard mode can cause the interface to discard any superior information received by the interface to prevent the root of the device from changing. Disable When this situation occurs, the interface enters the discarding state and no longer forwards any packets: Enable: The interface can enter the discarding state. Disable: The interface can not enter discarding state. Disable: The interface can not enter discarding state. TCN Guard Enable: The interface can not enter discarding state. Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change information. Disable MAC address table and send out a BPDU with a topology change information. Disable: The interface can not propagate the topology change information. Port Mode Spanping Trop Brotegel (STB) administrative mede that is associated with Enable	Disable: BPDUs are not forwarded.	
Specify whether the interface automatically becomes an edge port if it does not process BPDUs for a while: Enable: The interface becomes an edge port. Disable: The interface does not become an edge port. Root Guard Specify whether the root guard mode can cause the interface to discard any superior information received by the interface enters the discarding state and no longer forwards any packets: Enable: The interface can enter the discarding state and no longer forwards any packets: Enable: The interface can enter the discarding state. Disable: The interface can not enter discarding state. Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change flag set to true. Enable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. 	Auto Edge	
process BPDUs for a while: • Enable: The interface becomes an edge port. Enable • Disable: The interface does not become an edge port. Enable Root Guard Specify whether the root guard mode can cause the interface to discard any superior information received by the interface to prevent the root of the device from changing. Disable: The interface can enter the root of the device from changing. When this situation occurs, the interface enters the discarding state and no longer forwards any packets: • Disable: The interface can enter the discarding state. Disable • Disable: The interface can enter the discarding state. • Disable: The interface can not enter discarding state. Disable TCN Guard Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change information. Disable • Enable: The interface can propagate the topology change information. Disable • Disable: The interface can not propagate the topology change information. Disable • Enable: The interface can not propagate the topology change information. Disable • Enable: The interface can not propagate the topology change information. Disable • Enable: The interface can not propagate the topology change information. <t< td=""><td>Specify whether the interface automatically becomes an edge port if it does not</td><td></td></t<>	Specify whether the interface automatically becomes an edge port if it does not	
 Enable: The interface becomes an edge port. Disable: The interface does not become an edge port. Root Guard Specify whether the root guard mode can cause the interface to discard any superior information received by the interface to prevent the root of the device from changing. When this situation occurs, the interface enters the discarding state and no longer forwards any packets: Enable: The interface can enter the discarding state. Disable: The interface can not enter discarding state. Disable: The interface can not enter discarding state. Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change information. Disable: The interface can propagate the topology change information. Port Mode	process BPDUs for a while:	Enable
Disable: The interface does not become an edge port. Root Guard Specify whether the root guard mode can cause the interface to discard any superior information received by the interface to prevent the root of the device from changing. When this situation occurs, the interface enters the discarding state and no longer forwards any packets: Enable: The interface can enter the discarding state and no longer Disable: The interface can enter the discarding state. Disable: The interface can not enter discarding state. Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change information. 	Enable: The interface becomes an edge port.	Lindbio
Root Guard Specify whether the root guard mode can cause the interface to discard any superior information received by the interface to prevent the root of the device from changing. When this situation occurs, the interface enters the discarding state and no longer forwards any packets: Enable: The interface can enter the discarding state and no longer Disable: The interface can enter the discarding state. Disable: The interface can not enter discarding state. Disable: TCN Guard TCN Guard Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change information. Disable: The interface can not propagate the topology change information. Disable: The interface can not propagate the topology change information. Port Mode 	Disable: The interface does not become an edge port.	
Specify whether the root guard mode can cause the interface to discard any superior information received by the interface to prevent the root of the device from changing. Disable: When this situation occurs, the interface enters the discarding state and no longer forwards any packets: Enable: The interface can enter the discarding state. Disable: The interface can not enter discarding state. Disable: The interface can not enter discarding state. TCN Guard Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change flag set to true. Disable: The interface can not propagate the topology change information. Disable Port Mode Specify the Spanning Trap Protocol (STP) administrative mode that is appoint that is appoint the topology in the topology change information. Specify change information. Disable	Root Guard	I
information received by the interface to prevent the root of the device from changing. Disable: When this situation occurs, the interface enters the discarding state and no longer forwards any packets: Enable: The interface can enter the discarding state. Disable: The interface can not enter discarding state. Disable: The interface can not enter discarding state. TCN Guard Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change flag set to true. Disable: The interface can not propagate the topology change information. • Disable: The interface can not propagate the topology change information. Disable Port Mode Specify the Spanning Tree Protocol (STP) administrative mede that is approximated with Specify the Spanning Tree Protocol (STP) administrative mede that is approximated with Specify the Spanning Tree Protocol (STP) administrative mede that is approximated with	Specify whether the root guard mode can cause the interface to discard any superior	
When this situation occurs, the interface enters the discarding state and no longer forwards any packets: Disable: The interface can enter the discarding state. Disable: • Enable: The interface can enter the discarding state. Disable: Disable: • Disable: The interface can not enter discarding state. Disable: TCN Guard Disable: Disable: Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change flag set to true. Disable: • Enable: The interface can propagate the topology change information. Disable • Disable: The interface can not propagate the topology change information. Disable • Disable: The interface can not propagate the topology change information. Disable • Disable: The interface can not propagate the topology change information. Disable	information received by the interface to prevent the root of the device from changing.	
forwards any packets: • Enable: The interface can enter the discarding state. • Disable: The interface can not enter discarding state. • Disable: The interface can not enter discarding state. TCN Guard Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change flag set to true. • Enable: The interface can propagate the topology change information. • Disable: The interface can not propagate the topology change information. • Disable: The interface can not propagate the topology change information. • Disable: The interface can not propagate the topology change information. • Disable: The interface can not propagate the topology change information.	When this situation occurs, the interface enters the discarding state and no longer	Disable
Enable: The interface can enter the discarding state. Disable: The interface can not enter discarding state. TCN Guard Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change flag set to true. Enable: The interface can propagate the topology change information. Disable: The interface can not propagate the topology change information. Port Mode Specify the Spanning Tree Protocol (STP) administrative mede that is approximated with	forwards any packets:	
Disable: The interface can not enter discarding state. TCN Guard Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change flag set to true. Enable: The interface can propagate the topology change information. Disable: The interface can not propagate the topology change information. Port Mode Specify the Spanning Tree Protocol (STP) administrative mode that is acceptioned with Disable: The interface Interface Interface Enable: The interface Interface Interface Enable: The interface Can not propagate the topology change information. 	Enable: The interface can enter the discarding state.	
Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change flag set to true. • Enable: The interface can propagate the topology change information. • Disable: The interface can not propagate the topology change information. • Disable: The interface can not propagate the topology change information. • Disable: The interface (STP) administrative mode that is appropriated with	• Disable: The interface can not enter discarding state.	
Specify whether the topology change notification (TCN) guard restricts the interface from propagating the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change flag set to true. Enable: The interface can propagate the topology change information. Disable: The interface can not propagate the topology change information. 	I CN Guard	
The interface can not propagate the topology change information. This means that even if a port receives a BPDU with the topology change flag set to true, the port will not flush its MAC address table and send out a BPDU with a topology change flag set to true. Enable: The interface can propagate the topology change information. Disable: The interface can not propagate the topology change information. Port Mode Specify the Spanning Tree Protocol (STP) administrative mode that is approximated with 	Specify whether the topology change notification (ICN) guard restricts the interface	
MAC address table and send out a BPDU with a topology change flag set to true. Enable: The interface can propagate the topology change information. Disable: The interface can not propagate the topology change information. Port Mode Specify the Spanning Tree Protocol (STP) administrative mode that is appropriated with	from propagating the topology change information. This means that even if a port	
Enable: The interface can propagate the topology change information. Disable: The interface can not propagate the topology change information. Port Mode Spacify the Spanning Tree Protocol (STP) administrative mode that is appropriated with	MAC address table and apped out a RDDL with a tapalagy change flag set to true.	Disable
Disable: The interface can not propagate the topology change information. Port Mode Spacify the Spanning Tree Protocol (STP) administrative mode that is appreciated with	mac address table and send out a BFDO with a topology change hag set to frue.	
Port Mode Spacify the Spanning Tree Protocol (STP) administrative mode that is appreciated with	Disable: The interface can propagate the topology change information	
Specify the Spanning Tree Protocol (STD) administrative mode that is associated with	Port Mode	<u> </u>
	Specify the Spanning Tree Protocol (STP) administrative mode that is associated with	
the port or port channel.	the port or port channel:	Enable
Disable: STP is disabled for the port or port channel.	Disable: STP is disabled for the port or port channel.	

Description	Factory default
• Enable: STP is enabled for the port or port channel.	
Port Forwarding State	
This field displays whether the port is up and forwards traffic (Forwarding) or down and	Discording
discards traffic (Discarding).	Discarding
Protocol Migration	
Force the specified port to set the mcheck flag to transmit RST or MST BPDUs:	
True: The interface can receive the BPDU flood.	False
False: The interface can not receive the BPDU flood.	
PointToPoint Status	
Specify the point-to-point status of the interface in the CIST:	
• ForceTrue: The interface has a point-to-point connection to a switch,	
bridge, or end node, irrespective of the actual connection.	Auto
• ForceFalse: The interface does not have a point-to-point connection to a	Auto
switch, bridge, or end node, irrespective of the actual connection.	
Auto: The type of connection is automatically detected.	

3.3.1.4 CST Port Status

The port role types of the interface:



- **Root Port:** It is a concept of STP. Every non-root switch has one root port. The lowest cost of the path to the root switch will be the root port.
- **Master Port:** It is a concept of MSTP. It must meet two conditions: one is the root port in CIST; the other one is an edge port. The edge port is the port which connects two regions.
- **Designated Port:** The port responsible for forwarding data to the downstream network segment or device.
- Alternate Port: The standby port for the root port or master port. If a root port or master port is blocked, the alternate port becomes the new root port or master port.
- **Backup Port:** The backup port of designated ports. When a designated port is blocked, the backup port becomes a new designated port and starts to forward data without delay. When a loop occurs while two ports of the same MSTP device are interconnected, the device will block either of the two ports, and the backup port is the port to be blocked.

Refresh

CST Port Status								
Interface	Port ID	Port Forwarding State	Port Role	Designated Root	Designated Cost	Root Priority	Designated Bridge	
0/1	80:01	Discarding	Disabled	80:00:00:18:23:01:20:61	0	32768	80:00:00:18:23:01:20:61	
0/2	80:02	Discarding	Disabled	80:00:00:18:23:01:20:61	0	32768	80:00:00:18:23:01:20:61	
0/3	80:03	Discarding	Disabled	80:00:00:18:23:01:20:61	0	32768	80:00:00:18:23:01:20:61	
0/4	80:04	Discarding	Disabled	80:00:00:18:23:01:20:58	0	32768	80:00:00:18:23:01:20:58	
0/5	80:05	Discarding	Disabled	80:00:00:18:23:01:20:61	0	32768	80:00:00:18:23:01:20:61	
0/6	80:06	Forwarding	Designated	80:00:00:18:23:01:20:61	0	32768	80:00:00:18:23:01:20:61	
0/7	80:07	Discarding	Disabled	80:00:00:18:23:01:20:61	0	32768	80:00:00:18:23:01:20:61	
0/8	80:08	Discarding	Disabled	80:00:00:18:23:01:20:61	0	32768	80:00:00:18:23:01:20:61	
po1	80:09	Discarding	Disabled	80:00:00:18:23:01:20:61	0	32768	80:00:00:18:23:01:20:61	
po2	80:0a	Discarding	Disabled	80:00:00:18:23:01:20:61	0	32768	80:00:00:18:23:01:20:61	
ро3	80:0b	Discarding	Disabled	80:00:00:18:23:01:20:61	0	32768	80:00:00:18:23:01:20:61	

CST Port Status

Regional Point-Regional CST Designated Edge to-Point **CST Regional Root** Root Path Path Port Port Priority MAC Cost Cost 0 80:01 Disabled False 80:00:00:18:23:01:20:61 32768 20000 80:02 Disabled False 80:00:00:18:23:01:20:61 32768 0 20000 80:03 Disabled False 80:00:00:18:23:01:20:61 32768 0 20000 Disabled 80:07 True 80:00:00:18:23:01:20:61 32768 0 200000 80:05 Disabled 80:00:00:18:23:01:20:61 0 20000 False 32768 80:06 Enabled True 80:00:00:18:23:01:20:61 32768 0 200000 0 20000 80:07 Disabled False 80:00:00:18:23:01:20:61 32768 20000 80:08 Disabled False 80:00:00:18:23:01:20:61 32768 0 80:09 Disabled 80:00:00:18:23:01:20:61 10000 True 32768 0 80:0a Disabled 80:00:00:18:23:01:20:61 0 10000 True 32768

80:00:00:18:23:01:20:61

32768

0

10000

CST Port Status

80:0b

Disabled

True

Item	Description					
Interface	The interface number or port channel number.					
Dort ID	The port identifier for the interface within the CST, which consists of the port					
	priority and the interface number.					
	The forwarding state of the interface. One of the following options is displayed:					
	Discarding: The interface is in the discarding mode; it can not					
	forward traffic and can not learn new MAC addresses.					
Port Forwarding State	Learning: The interface is in the learning mode; it can not forward					
	traffic, but it can learn new MAC addresses.					
	• Forwarding: The interface is in the forwarding mode; it can forward					
	traffic and learn new MAC addresses.					
	The role type of the interface in the spanning tree: One of the following options					
	is displayed:					
	Root					
Port Polo	Master					
	Designated					
	Alternate					
	Backup					
	Disabled					

Item	Description
Designated Root	The identifier of the root bridge of CIST. The identifier consists of the bridge priority and the base MAC address of the STP bridge.
Designated Cost	The path cost that is advertized by the designated port to the LAN. Note: Interfaces with a lower cost are less likely to be blocked if STP detects loops.
Root Priority	The priority of the CST root. The default root priority is 32768.
Designated Bridge	The identifier of the bridge with the designated port. The identifier consists of the bridge priority and the base MAC address of the STP bridge.
Designated Port	The port identifier on the designated bridge that offers the lowest cost to the LAN. The identifier consists of the port priority and the interface number. Note: If the port is the designated port, the identifiers in the Port ID and Designated Port fields are identical. If the port is not the designated port, that is, there is a root port and an alternate port, the identifiers in the Port ID and Designated Port fields are different.
Edge Port	 The edge port status of the interface: Enabled: The interface is an edge port. Disabled: The interface is not an edge port.
Point-to-Point MAC	 Connection types: True: The connection is a point-to-point connection. False: The connection is a shared LAN connection.
CST Regional Root	The identifier of the regional root bridge of CIST. The identifier consists of the bridge priority and the base MAC address of the STP bridge.
Regional Root Priority	The priority of the regional root. The default regional root priority is 32768.
Regional Path Cost	The path cost to the regional root.
CST Path Cost	The path cost to the CST tree regional root.

3.3.1.5 MST Configuration

MST Configuration

M	MST Configuration									
	MST ID	Priority	Bridge Identifier	VLAN List	Time Since Topology Change	Topology Change Count	Designated Root	Root Path Cost	Root Port Identifier	
	1	4096	10:00:00:18:23:01:20:61	1	0 day 0 hr 0 min 0 sec	0	10:00:00:18:23:01:20:61	0	00:00	
	1	4096	10:00:00:18:23:01:20:61	1	0 day 0 hr 0 min 0 sec	0	10:00:00:18:23:01:20:61	0	00	

Add Delete **Refresh** Cancel Apply

MST Configuration settings

Description	Factory default
MST ID	
Enter an identifier for the MST instance. Enter a number in the range of 1 to 16.	None
Priority	
Enter the bridge priority. Enter a number between 0 and 61440 which is a multiple of	32768
4096.	52700
VLAN List	
Enter the vlan id list. Enter a number in the range of 1 to 4094	None

MST Configuration Table Information

Item	Description
MST ID	The identifier of the MST instance.
Priority	The bridge priority value for the MST instance.
Dridge Identifier	The bridge identifier for the MST instance. The bridge identifier is made up of the
bridge identilier	bridge priority and the base MAC address of the bridge.

VLAN List	The VLAN or VLANs to which the MST instance is mapped. You can enter a single VLAN ID or a number of VLAN IDs.				
Time Since Topology	The time in seconds since the topology of the selected MST instance last				
Change	changed.				
Topology Change Count	The number of times the topology has changed the MST instance				
Design stad Dest	The bridge identifier of the root bridge for the MST instance. The bridge identifier				
Designated Root	is made up of the bridge priority and the base MAC address of the root bridge.				
Root Path Cost	The path cost to the designated root for the MST instance.				
Root Port Identifier	The port identifier to access the designated root for the MST instance.				

3.3.1.6 MST Port Status

The MST Port Status will show up after you finished the MST configuration settings. MST Port Status

	Mor Fort Status									
M	MST Port Status									
Select MST 1 🔻										
M	MST Port Status									
	Interface	Port Priority	Port Cost	Port Mode	Auto Calculated Port Path Cost	Port ID	Port Forwarding State	Port Role	Designated Root	
				-						
	0/1	128	20000	Enabled	Disabled	80:01	Discarding	Disabled	80:00:00:18:23:01:20:61	
	0/2	128	20000	Enabled	Disabled	80:02	Discarding	Disabled	80:00:00:18:23:01:20:61	
	0/3	128	20000	Enabled	Disabled	80:03	Discarding	Disabled	80:00:00:18:23:01:20:61	
	0/4	128	200000	Enabled	Disabled	80:04	Discarding	Disabled	80:00:00:18:23:01:20:61	
	0/5	128	200000	Enabled	Disabled	80:05	Forwarding	Master	80:00:00:18:23:01:20:61	
	0/6	128	200000	Enabled	Disabled	80:06	Forwarding	Designated	80:00:00:18:23:01:20:61	
	0/7	128	20000	Enabled	Disabled	80:07	Discarding	Disabled	80:00:00:18:23:01:20:61	
	0/8	128	20000	Enabled	Disabled	80:08	Discarding	Disabled	80:00:00:18:23:01:20:61	
	po1	128	10000	Enabled	Disabled	80:09	Discarding	Disabled	80:00:00:18:23:01:20:61	
	po2	128	10000	Enabled	Disabled	80:0a	Discarding	Disabled	80:00:00:18:23:01:20:61	
	po3	128	10000	Enabled	Disabled	80:0b	Discarding	Disabled	80:00:00:18:23:01:20:61	

Apply Refresh

Designated Cost	Designated Bridge	Designated Port	Forward Transitions	Received BPDUs	Transmitted BPDUs	Invalid Received BPDUs
0	80:00:00:18:23:01:20:61	80:01	0	0	0	0
0	80:00:00:18:23:01:20:61	80:02	0	0	0	0
0	80:00:00:18:23:01:20:61	80:03	0	0	0	0
0	80:00:00:18:23:01:20:61	80:04	0	0	0	0
0	80:00:00:18:23:01:20:61	80:05	1	0	4	0
0	80:00:00:18:23:01:20:61	80:06	1	0	12	0
0	80:00:00:18:23:01:20:61	80:07	0	0	0	0
0	80:00:00:18:23:01:20:61	80:08	0	0	0	0
0	80:00:00:18:23:01:20:61	80:09	0	0	0	0
0	80:00:00:18:23:01:20:61	80:0a	0	0	0	0
0	80:00:00:18:23:01:20:61	80:0b	0	0	0	0

MST Port Status

Item	Description
Interface	This field shows the interface number or port channel number.
	Enter the priority for the interface in the MST instance. Enter a value between 0
Port Priority	and 240 that is a multiple of 16. The default priority is 128.
	Leave the default path cost, or entering a new path cost that is used for the
	interface in the MST instance. Enter a number in the range of 1 to 200,000,000.
Port Cost	Enter zero (0) to reset the path cost.
	Note:
	The default path cost is 20,000 for a Gigabit Ethernet interface
	Specify the administrative mode for the interface in the MST instance.
Port Mode	• Enable: Enables STP for the interface. This is the default setting.
	Disable: Disables STP for the interface.
Auto Calculated Port	This field displays whether you have globally enabled or you can disable the
Path Cost	dynamic path cost on the CST Configuration page.
Port Id	The port identifier, which consists of the port priority and the interface number
	The forwarding state of the interface in the MST instance. One of the following
	options is displayed:
	• Discarding: The interface is in the discarding mode; it can not forward
Port Forwarding State	traffic and can not learn new MAC addresses.
i en i en analig etate	• Learning: The interface is in the learning mode; it can not forward
	traffic, but it can learn new MAC addresses.
	• Forwarding: The interface is in the forwarding mode; it can forward
	traffic and learn new MAC addresses.
	The role types of the interface in the MST instance: One of the following options
	is displayed:
	Root
Port Role	Master Designated
	Backup
	Disabled
	The identifier of the root bridge in the MST instance. The identifier consists of the
Designated Root	bridge priority and the base MAC address of the MST root bridge.
	The path cost that is advertized by the designated port to the LAN.
	Note:
Designated Cost	Interfaces with a lower cost are less likely to be blocked if MST
	detects loops.
Designated Dridge	The identifier of the bridge with the designated port. The identifier consists of the
Designated Bridge	bridge priority and the base MAC address of the MST bridge.
	Note:
	The port identifier on the designated bridge that offers the lowest cost
	to the LAN. The identifier consists of the port priority and the interface
	number.
Designated Port	Note:
	If the port is the designated port, the identifiers in the Port ID and
	Designated Port fields are identical. If the port is not the designated
	port, that is, there is a root port and an alternate port, the identifiers in
	the Port ID and Designated Port fields are different.
Forward Transitions	The number of forwarding transitions to other interfaces.
Received BPDUs	The number of BPDUs that were received on the interface for the MST instance.
Transmitted BPDUs	ine number of BPDUs that were transmitted on the interface for the MSI
Involid Dessived	Instance.
	instance
0,003	וווסנמוועס.

3.3.1.7 STP Statistics

STP Statistics

STP Statistics								
Interface	Received MST BPDUs	Received RST BPDUs	Received Config BPDUs	Received TCN BPDUs	Transmitted MST BPDUs	Transmitted RST BPDUs	Transmitted Config BPDUs	Transmitted TCN BPDUs
0/1	0	0	0	0	0	0	0	0
0/2	0	0	0	0	0	0	0	0
0/3	604	0	0	0	3	0	0	0
0/4	0	0	0	0	5044	0	0	0
0/5	0	0	0	0	0	0	0	0
0/6	5886	0	0	0	11	0	0	0
0/7	0	0	0	0	0	0	0	0
0/8	0	0	0	0	0	0	0	0
po1	0	0	0	0	0	0	0	0
po2	0	0	0	0	0	0	0	0
po3	0	0	0	0	0	0	0	0

Refresh Clear

Received Invalid MST BPDUs	Received Invalid RST BPDUs	Received Invalid Config BPDUs	Received Invalid TCN BPDUs	Protocol Migration Count
0	0	0	0	0
0	0	0	0	0
0	0	0	0	0
0	0	0	0	0
0	0	0	0	0
0	0	0	0	0
0	0	0	0	0
0	0	0	0	0
0	0	0	0	0
0	0	0	0	0
0	0	0	0	0

STP Statistics

ltem	Description
Interface	This field shows the interface number.
Received MST BPDUs	The number of MSTP BPDUs that were received on the interface.
Received RST BPDUs	The number of RSTP BPDUs that were received on the interface.
Reastived Config RDD In	The number of configuration BPDUs that were received on the
Received Coning BPDOS	interface.
Reasived TCN RDDUs	The number of topology change notification (TCN) BPDUs that
Received ICN BFD0s	were received on the interface.
Transmitted MST RDDL	The number of MSTP BPDUs that were transmitted on the
	interface.
	The number of RSTP BPDUs that were transmitted on the
	interface.
Transmitted Config BPDUs	The number of configuration BPDUs that were transmitted on the

Item	Description
	interface.
Transmitted TCN BPDUs	The number of TCN BPDUs that were transmitted on the interface.
Passived Invalid MST RPDI Is	The number of invalid MSTP BPDUs that were received on the
	interface.
Passived Invalid PST RPDUs	The number of invalid RSTP BPDUs that were received on the
	interface.
Received Invalid Config BPDI Is	The number of invalid configuration BPDUs that were received on
	the interface.
Received Invalid TCN BPDUs	The number of invalid TCN BPDUs that were received on the
	interface.
	The number of times the interface received traffic from or
Protocol Migration Count	transmitted traffic to a device that does not support RSTP or MSTP
	but STP only.

3.3.2 Redundancy

To keep the industrial network run non-stop, the Ethernet redundancy network is an essential feature in the industrial ethernet network. The Delta managed switch provides three topologies: ONE RING, ONE CHAIN and ONE COUPLING. These redundancy topology operating theories look like STP, but when a connection failure was caused in the network, it can quickly recover the connection and work normally.

3.3.2.1 ONE RING Configuration

The ONE RING topology consists of nodes having two ports participating in ONE RING. There are two types of nodes, which namely master nodes and slave nodes. There can be only one master and up to 250 slave nodes.



The ports and LAGs which are the members of ONE RING should disable the STP mode and the Loopback-Detection mode.

ONE RING Configuration

ONE	ONE RING Configuration							
	Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	Ring Status	Admin Status
		- •	- T		- •			

Refresh Add Delete Cancel Apply

ONE RING Configuration

ltem	Description					
Instance ID	The ONE RING instance index. The range is 1 to 1000.					
	Defines the node role. The possible field values are:					
	• Master: The master node manages the ring network, and there can					
Mode	only be one master node in a ring network.					
	• Slave: The slave nodes forward the hello packets along the ring, and					
	there are up to 250 slave nodes.					
Dort1	On the master node, it is the primary port.					
FUILI	On the slave node, it is just one of the member ports.					
Dort?	On the master node, it is the backup port.					
FUILZ	On the slave node, it is just one of the member ports.					
	Defines the current ring status of the node.					
	Master state:					
	• Discover : The ring is not completed yet					
Bing Status	• Monitor: The ring is completed and healthy.					
King Status	• Fault: The ring failed. The backup path is activated.					
	Slave State:					
	• Forwarding: After the instance is created, it will stay at this state.					
	• Hold: It is a middle state of the slave when 2 member ports are linked					

Item	Description
	down->up.
Admin Status	The ONE RING instance entry status, including active, inactive, and etc.

3.3.2.2 ONE CHAIN Configuration

ONE CHAIN will connect a series of nodes to a LAN network. It consists of a head node, a tail node and a series of member nodes. The head node hosts the head port that is forwarded by default. The tail node hosts the tail port that is blocked by default. Any link failure caused in the ONE CHAIN will make the tail port as a forwarding port. The topology will be restored after the recovery from failure.

Note:

The ports and LAGs which are the members of ONE CHAIN should disable the STP mode and the Loopback-Detection mode.

ONE CHAIN Configuration

ONE CHAIN Configuration								
	Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	Chain Status	Admin Status
		- 🔻	· •		- v			

Refresh Add Delete Cancel Apply

ONE CHAIN Configuration

ltem	Description			
Instance ID	The ONE CHAIN instance index. The range is 1 to 1000.			
	Defines the node role. The possible field values are:			
	• Head: A Head node has one head port and one member port.			
Mode	• Tail: A Tail node has one tail port and one member port. The tail has			
	two statuses: block and forwarding.			
	Member: A Member node has two member ports.			
	On the head node, it is the head port.			
Port1	On the member node, it is just one of the member ports.			
	On the tail node, it is the tail port.			
	On the head node, it is the member port.			
Port2	On the member node, it is just one of the member ports.			
	On the tail node, it is the member port.			
	Defines the current ring status of the node.			
	On the Head node:			
	Discover: The chain is not completed yet.			
	• Monitor: The chain is completed and healthy. The Head port is linked			
	up, and no node is disconnected.			
	• Fault: The chain is disconnected because the member node is linked			
	down or the head port is linked down.			
	Hold: The Head port is linked down->up.			
Chain Status	On the Member node:			
	• Forwarding: After the instance is created, it will stay at this state.			
	• Hold: It is a middle state of the slave when 2 member ports are linked			
	down->up. It changes to the Forwarding state when it receives the			
	clear-FDB message or HOLD timer timeout.			
	On the Tail node:			
	Discover: The chain is not completed yet.			
	Monitor: The chain is completed and healthy.			
	• Fault: The chain failed. The backup path is activated.			
Admin Status	The ONE CHAIN instance entry status, including active, inactive, and etc.			

3.3.2.3 ONE COUPLING Configuration

ONE COUPLING is used to connect two redundant ring networks. There is a main path and a backup path, and two types of nodes which namely head nodes and tail nodes. The head node hosts the main path and the tail node hosts the backup path. The backup path will be blocked by default. When there is a failure in the main path, the backup path will get

unblocked.

Only ONE RING will be configured with the head coupling node and the tail coupling node



Note:

The ports and LAGs which are the members of ONE COUPLING should disable the STP mode and the Loopback-Detection mode.

ONE COUPLING Configuration



Refresh	dd Delete	Cancel	Apply
---------	-----------	--------	-------

ONE COUPLING Configuration

ltem	Description					
Instance ID	The ONE COUPLING instance index. The range is 1 to 1000.					
Mode	 Defines the node role. The possible field values are: Head: The Head node sends periodic status packets to the ring on both the ring ports. If the main path is disrupted, the head node will send a status message indicating the linking down. After the main path is restored, the main path ports will be initially set to the blocked state. Tail: The tail node receives status messages from the head. The backup path is blocked by default. On detecting the main path failure, it will allow the forwarding in the backup path. On detecting the main path recovery, it will change the state of the backup path to the blockup path. 					
Port	On the head node, it is the head port. On the tail node, it is tail port.					
Coupling Status	 Defines the current ring status of the node. Head state: Monitor: The head port is linked up. Fault: The head port is linked down. It will notify the tail node to activate the backup path. Link-Up: The head port is linked up. If the head port is linked down at this state, it will change to Fault again. Hold: After the Link-Up timer timeout occurs, the node will change to the HOLD state. Tail State: Discover: The coupling is not completed yet. It waits for the head port link status message from the head node. Monitor: The coupling is completed and healthy. Fault: The coupling is disconnected. 					
Admin Status	The ONE COUPLING instance entry status, including active, inactive, and etc.					

3.3.2.4 Redundancy Cruiser

Redundancy Cruiser is used to monitoring the ONE RING / ONE CHAIN / ONE COUPLING link status. The administrator can get the redundancy network information immediately if there is any link down or unknow situation happened.



Note:

This feature is only activated on the master node of ONE RING, the head node / tail node of ONE CHAIN, and the tail node of ONE COUPLING.

Redundancy Cruiser	
Instance ID	1
Topology	Ring
Status	MONITOR
Master IP	192.168.1.142
Master MAC	00:18:23:01:20:61
Faults Detected	4 Clear
Last Active Node on Port 1	None
Last Active Node on Port 2	None

Redundancy Cruiser

Redundancy Cruiser

Item	Description
Instance ID	The redundancy network instance index. The range is 1 to 1000.
	This field shows the topology type which is monitoring.
Tapalagy	 Ring: It is cruising in ONE RING topology.
ropology	Chain: It is cruising in ONE CHAIN topology.
	Coupling: It is cruising in ONE COUPLING topology.
	This field shows the network status which is under monitoring.
Statua	 DISCOVER: The topology is not completed yet.
Status	 MONITOR: The topology is completed and healthy.
	FAULT: The topology failed. The backup path is activated.
Master IP	This field shows the IP address of master node.
Master MAC	This field shows the MAC address of master node.
Foulto Dotostad	This field shows the detection times which the status is change from DISCOVER
Faults Detected	state or FAULT state to MONITOR state.
Last Active Node on	This field shows the IP address and MAC address of the node which is on the
Port 1	path from the port1.
Last Active Node on	This field shows the IP address and MAC address of the node which is on the
Port 2	path from the port2.

3.3.3 Redundancy Application Setting

Introduce how to set up a basic example of Delta One Ring/One Chain.

ONE Ring



1. In the CST Port configuration, set the network port mode corresponding to one ring/chain to disable.

🗄 🌆 Basic Setting	CS	Port Co	nfigura	tion								
🗄 🖢 SNMP Manager	CS	ST Port Cor	figuratio	n								
🖻 📄 Network Redundancy						Auto					1	
🖯 📄 STP			Port	Admin	Port Path	Calculated	Halle Time	BPDU	And the second	Root	TON Course	Door Made
STP Configuration		Internace	Priority	Edge Port	Cost	Port Path	Heno Time	Forwarding	Auto Eage	Guard	TCN Guard	Port Plode
CST Configuration						Cost						
CST Port Configuration				- *				- *	- *	. ,	- *	- •
CST Port Status		0/1	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Disable
III MST Configuration	-	0/2	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Disable
mst Port Status		0/3	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Disable
STP Statistics		0/4	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Enable
ONE RING Plus Configuration		0/5	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Enable

2. Please follow the number and correspond to the following network maps to make the corresponding settings.

	ON	E RING Plus Configu	iration						
4		Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE RING Status	Admin Status
U			- •	- 7		- 7			
		1	Master	0/1	Head	0/2	Tail	DISCOVER	Active

	ON	E RING Plus Config	uration						
9		Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE RING Plus Status	Admin Status
9			- 7	- T		- •			
		1	Slave	0/1	Member	0/2	Member	FAULT	Active

	ON	ONE RING Plus Configuration													
0		Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE RING Plus Status	Admin Status						
3			- 7	- •		- •									
		1	Slave	0/1	Member	0/2	Member	FAULT	Active						

• ONE Chain



1. In the CST Port configuration, set the network port mode corresponding to one ring/chain to disable.

🖲 🌆 Basic Setting	CST	Port Co	nfigura	tion								
🗄 🆢 SNMP Manager	CS	ST Port Cor	figuratio	n								
🖻 📄 Network Redundancy				1		Auto						
🖯 🛅 STP		Sec. 1	Port	Admin	Port Path	Calculated		BPDU		Root	-	
STP Configuration		Internace	Priority	Edge Port	Cost	Port Path	Helto Time	Forwarding	Auto Eage	Guard	TCN Guard	Port Mode
CST Configuration						Cost				1.0		
CST Port Configuration				- *				- *	- •	• • •	- *	- *
CST Port Status		0/1	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Disable
mst Configuration		0/2	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Disable
mst Port Status		0/3	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Disable
STP Statistics		0/4	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Enable
ONE RING Plus Configuration		0/5	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Enable

2. Please follow the number and correspond to the following network maps to make the corresponding settings.

	ON	ONE CHAIN Plus Configuration														
1		Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE CHAIN Plus Status	Admin Status							
U			- 7	- •		- •										
		1	Head	0/1	Head	0/2	Member	IDLE	Active							

	ON	E CHAIN Plus Confi	guration						
0		Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE CHAIN Plus Status	Admin Status
0			- 7	- •		- •			
		1	Tail	0/1	Tail	0/2	Member	DISCOVER	Active

	ON	E CHAIN Plus Confi	guration						
6		Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE CHAIN Plus Status	Admin Status
3			- •	- •		- •			
		1	Member	0/1	Member	0/2	Member	FAULT	Active



1. In the CST Port configuration, set the network port mode corresponding to one ring/chain to disable.

🗄 🌆 Basic Setting	CS	Port Co	nfigura	tion								
🗄 🖢 SNMP Manager	C	ST Port Cor	figuratio	n								
🖻 📄 Network Redundancy				1		Auto						
🗟 📑 STP		Interface	Port	Admin	Port Path	Calculated	Helle Time	BPDU	Auto Edan	Root	TCN Guand	Bort Mode
STP Configuration		Internace	Priority	Edge Port	Cost	Port Path	Heno Time	Forwarding	Auto Euge	Guard	TCAT GULITU	Port Plode
CST Configuration						Cost						
CST Port Configuration				- *				- *	- *	• •	•	- •
CST Port Status		0/1	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Disable
mST Configuration		0/2	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Disable
mst Port Status		0/3	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Disable
STP Statistics		0/4	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Enable
ONE RING Plus Configuration	0	0/5	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Enable

2. Please follow the number and correspond to the following network maps to make the corresponding settings.

	ON	E RING Plus Configu	Iration						
4		Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE RING Status	Admin Status
U			- 7	- •		- •			
		1	Master	0/1	Head	0/2	Tail	DISCOVER	Active

	ON	E RING Plus Config	uration						
0		Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE RING Plus Status	Admin Status
9			- •	- •		- •			
		1	Slave	0/1	Member	0/2	Member	FAULT	Active

	ON	E RING Plus Config	uration						
9		Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE RING Plus Status	Admin Status
3			- 7	- •		- •			
		1	Slave	0/1	Member	0/2	Member	FAULT	Active

	ON	IE RING Plus Config	guration						
		Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE RING Plus Status	Admin Status
4			- •	- •		- 7			
		1	Slave	0/1	Member	0/2	Member	FAULT	Active
					·				
	ON	E CHAIN Plus Confi	guration						
		Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE CHAIN Plus Status	Admin Status
^			- •	- •		- •			
		1	Tail	0/1	Tail	0/2	Member	DISCOVER	Active
	ON	E CHAIN Plus Confi	guration	Dort1	Dort1 Dolo	Dort2	Dort2 Dolo	ONE CHAIN Blue Statue	Admin Status
	-	Instance ID	Mode		POILI KOIE		PUILZ RUIE	ONE CHAIN Plus Status	Autititi Status
		1	Lood	0/1	Hoad	0/2	Mombor	IDLE	Activo
L		1	neau	0/1	neau	0/2	Hember		Active
	ON	E CHAIN Plus Confi	quration						
		Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE CHAIN Plus Status	Admin Status
			- T	- •		- •			
		1	Member	0/1	Member	0/2	Member	FAULT	Active
Со	upli	ing RING							
		_		0				0	
			Port1					•	Port
			TOILI	1	Port3	F	Port3		Pon
		/	DV	S-G100			DVS	-G100 Port1	DVS-G1
	1		Port2					Port2	Port2
	1	Port1	1 OIL					/	
vs.	G100								
		ONE	RING					ONE F	RING
	T	Port2	RING						

1. In the CST Port configuration, set the network port mode corresponding to one ring/chain to disable.

🖲 🍺 Basic Setting	CST	Port Co	onfigura	tion								
🗄 🆢 SNMP Manager	CS	ST Port Con	nfiguratio	n								
🖻 📄 Network Redundancy				1		Auto						
🖯 📄 STP			Port	Admin	Port Path	Calculated		BPDU		Root	-	
STP Configuration		Internace	Priority	Edge Port	Cost	Port Path	Hello Time	Forwarding	Auto Eage	Guard	TCN Guard	Port Mode
CST Configuration						Cost				-		
CST Port Configuration				- *				- *	· ·	• •	•	• •
CST Port Status		0/1	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Disable
mst Configuration	-	0/2	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Disable
mst Port Status		0/3	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Disable
STP Statistics		0/4	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Enable
ONE RING Plus Configuration		0/5	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Enable

2. Please follow the number and correspond to the following network maps to make the corresponding settings.

ON	ONE RING Plus Configuration								
	Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE RING Plus Statu	ıs Admin Status	
		- •	- •		- •	'			
	1	Slave	0/1	Member	0/2	Member	FAULT	Active	
0	NE COUPLING P	us Config	uration						
	Instance ID	Mode	Port	Port	Role	ONE COUPL	ING Plus Status	Admin Status	
		- •	-	•					
	1	Head	0/3	Head		FAULT		Active	

O	ONE RING Plus Configuration								
	Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE RING Statu	s Admin Status	
		- *	- *		- *				
	1	Master	0/1	Head	0/2	Tail	DISCOVER	Active	
O	NE COUPLING Plu	ıs Configu	ration						
	Instance ID	Mode	Port	Port Ro	le ONE	COUPLING	G Plus Status	Admin Status	
		- •	- 🔻						
	1	Tail	0/3	Tail	DISC	OVER		Active	

	ON	IE RING Plus Config	uration									
		Instance ID	Mode	Port1	Por	t1 Role	Port2		Port2 Role	ONE RING Plus Sta	tus	Admin Status
			- 1	- Y			-	•				
•		1	Slave	0/1	Mer	nber	0/2		Member	FAULT		Active
3	ON	IE COUPLING Plu	us Configu	uration								
		Instance ID	Mode	Port		Port F	lole	O	NE COUPLI	NG Plus Status	Ad	min Status
			- •	-	۲							
		1	Head	0/3		Head		FA	ULT		Ac	tive

	ON	E RING Plus Configu	Iration						
		Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE RING Statu	s Admin Status
			- •	- •		- T			
		1	Master	0/1	Head	0/2	Tail	DISCOVER	Active
4	10	NE COUPLING Plu	ıs Configu	ration					
		Instance ID	Mode	Port	Port Ro	le ONE	COUPLING	Plus Status	Admin Status
			- •	- 🔻					
		1	Tail	0/3	Tail	DISC	OVER	A	Active

1

2

• Dual Homing



1. In the CST Port configuration, set the network port mode corresponding to one ring/chain to disable.

🖲 🆢 Basic Setting	CST	Port Co	onfigura	tion								
🗄 🖢 SNMP Manager	CS	T Port Co	figuratio	n								
🖻 📄 Network Redundancy						Auto						
🗄 🛅 STP		Interface	Port	Admin	Port Path	Calculated	Hollo Timo	BPDU	Auto Edeo	Root	TCN Guard	Dort Mode
STP Configuration		Interace	Priority	Edge Port	Cost	Port Path	Heno Time	Forwarding	Auto Euge	Guard	TCN GUARD	Port Plote
CST Configuration						Cost						
CST Port Configuration				- *				- *	- •	• •	- *	- •
CST Port Status		0/1	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Disable
MST Configuration	-	0/2	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Disable
m MST Port Status		0/3	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Disable
STP Statistics		0/4	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Enable
ONE RING Plus Configuration	0	0/5	128	Disable	20000	Disabled	2	Disable	Enable	Disable	Disable	Enable

2. Please follow the number and correspond to the following network maps to make the corresponding settings.

ON	ONE RING Plus Configuration								
	Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE RING Plus Statu	s Admin Status	
		- 7	- •		- •				
	1	Slave	0/1	Member	0/2	Member	FAULT	Active	
0	NE COUPLING P	lus Config	uration	1					
	Instance ID	Mode	Port	Port	Role	ONE COUP	ING Plus Status	Admin Status	
		- •	-	•					
	1	Head	0/3	Head	1	FAULT		Active	

ON	ONE RING Plus Configuration								
	Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE RING Statu	s Admin Status	
		- *	- 7		- *				
	1	Master	0/1	Head	0/2	Tail	DISCOVER	Active	
10	NE COUPLING Plu	ıs Configu	ration						
	Instance ID	Mode	Port	Port Ro	le ONE	COUPLING	FPlus Status	Admin Status	
		- •	- •						
	1	Tail	0/3	Tail	DISC	OVER		Active	

	ON	E RING Plus Config	uration						
2		Instance ID	Mode	Port1	Port1 Role	Port2	Port2 Role	ONE RING Plus Status	Admin Status
U			- 7	- T		- •			
		1	Slave	0/1	Member	0/2	Member	FAULT	Active

3.4 Virtual LANs

Virtual LAN (VLAN) is a logical group network. VLANs electronically separate interfaces on the same switch into different broadcast domains so that broadcast packets are not sent to all the interfaces on a single switch. VLAN allows the switch manager to isolate network traffic so that only members of the VLAN can receive traffic from the same VLAN members. VLAN also allows a user to access the network from a different place or switch. So VLAN provide security and flexibility. For example: Configure department A, B, C to VLAN 1, 2, 3. Users can only access the resource which belongs to their department, so the resource in their department can be protected. And they can access the resource in a different floor, even though in a different place. So they do not need to stay in a fixed place to access the resource which belongs to their department.

IMPORTANT:

Make sure that you save the configuration in the Save Configuration page after you have applied the configuration changes. (Save Config \rightarrow Save Configuration) If you do not save the configuration, then the configuration will be cleared after the switch is rebooted.

ิก

2



3.4.1 VLAN Mode Configuration

There are two VLAN modes can be chosen: 802.1Q and VLAN Unware.You can choose the properly VLAN mode on the Delta managed switch so that it can increase the efficiency of your network.

VLAN Mode Configuration

VLAN Mode Configuratio	n
VLAN Mode	● 802.1Q 🔿 VLAN Unaware
	Cancel Apply
Mode Configuration	

VLAN Mode Configuration

Status	Description
	It logically segment the shared media LAN, forming virtual workgroup. They are
	redefine and optimize the basic Transparent Bridging functionalties like
802.1Q	learning, forwarding, filtering and flooding, etc. The advantages of VLANs are:
	enhanced network security, controlled broadcast activity, members of the VLAN
	need not to be connected to the same LAN segment.
	It doesn't check the VLAN tags of input Ethernet frame. In other words, VLAN
VLAN Unaware	Unaware mode can pass all VLAN tags from one customer domain to another
	no matter it is VLAN tagged or VLAN untagged.

3.4.2 VLAN Configuration

VLAN Configuration is used to define VLAN groups and the VLAN information will be stored in the VLAN membership table. The Delta switch supports up to 256 VLANs. VLAN 1 is the default VLAN, and all interfaces are untagged members by the default setting.



2

Note:

The interfaces that you make members of link aggregation groups (that is, physical interfaces that function as trunk members) lose their membership of the default VLAN.

VLAN Configuration

VLAN Configuration				
	VLAN ID	VLAN Name	VLAN Type	
	1	Default	Default	
	2	VLAN2	Static	
	3	VLAN3 Static		
		Add Delete Cancel Apply		

VLAN Configuration

Description	Factory default
VLAN ID	
Enter the identifier for the new VLAN. The range can be set in the range of 1 to 4094.	None
VLAN Name	
Enter a name for the VLAN. The name can be up to 32 alphanumeric characters long,	Nono
including blanks.	None
VLAN Type	
When you create VLAN, the VLAN type always displays Static.	Static

3.4.3 VLAN Membership

You cannot change the VLAN Type of VLAN 1, because VLAN 1 is the default VLAN and the type is always Default. When you create a VLAN on this page, its type will always be Static. An interface or LAG can be a tagged (T) or untagged (U) VLAN member.



Note:

If you need to access the switch via the port, we suggest that you make sure that the port you use is the untagged port of VLAN 1 (the default VLAN).

VLAN Mer	nbership								
VLAN ID		1 🔻		Gro	up Opera	tion	-	-	
VLAN Name	e	Default		ТИО	AGGED PO	RT MEMBER	as		
VLAN Type		Default		ТА	GGED POR	T MEMBERS			
Port	1	2	3	4	5	6	7	8	
	U	Т	Т	Х	U	U	U	U	
LAG			1		2		3		
			U		U		U		

VLAN Membership

Cancel Apply

VLAN Square Status

Status	Description	
	If the interface or LAG is not a member of VLAN, the square must keep blank.	
blank square (Auto)	The port currently is not the static member of the VLAN, but it can be added	
	dynamically by other protocols, for example by GVRP.	
T (Tagged)	If the square status of the interface or LAG is T, frames transmitted from the	

Status	Description		
	interface or LAG are tagged with the port VLAN ID.		
	Click Tagged Port Members to view the interfaces and LAGs which are tagged.		
	If the square status of the interface or LAG is U, frames transmitted from this		
	interface or LAG is untagged. Each interface or LAG can be an untagged		
	member of any VLAN. That is, an interface or LAG can be an untagged member		
U (Untagged)	of multiple VLANs. All interfaces and LAGs are untagged members of VLAN 1		
	by the default setting.		
	Click Untagged Port Members to view the interfaces and LAGs which are		
	untagged.		
X (Earbiddon)	This port can not be the member of this VLAN permanently. (It also can not be		
	added dynamically by other protocols.)		

Add and configure the interface or LAG:

- Click once to add the interface or LAG as a tagged member to the VLAN.
- Click twice to add the interface or LAG as an untagged member to the VLAN.
- Click three times to remove the interface or LAG from the VLAN.

Add and configure all interfaces:

•

- Untag All: Adds all interfaces or LAGs as untagged members to the VLAN.
- **Tag All:** Adds all interfaces or LAGs as tagged members to the VLAN.
- **Remove All:** Removes all interfaces or LAGs from the VLAN.

3.4.4 VLAN Status

You can click **Refresh** button to update the information.

VLAN Status

VLAN Status				
VLAN ID	VLAN Name	VLAN Type	Member Ports	Untagged Ports
1	Default	Default	0/1-8,po1,po2,po3	0/1-8,po1,po2,po3
2	Test	Static	0/1-2,po1	0/1-2,po1
3	Test2	Static	0/4-6,po2	0/4-6,po2

Refresh

VLAN Status

Item	Description
VLAN ID	The identifier of VLAN.
VLAN Name	The name of VLAN.
VLAN Type	The type of VLAN (Default or Static).
Member Ports	The interfaces that are members of VLAN.
Untagged Ports	The interfaces that are untagged members of VLAN.

3.4.5 Port PVID Configuration

VID (VLAN ID) is the tag of VLAN. It defines the interface which can **receive** the packets of the VLAN; PVID (Port VLAN ID) defines the untagged port which can **forward** the VLAN's packets.

For example: If port 1 belongs to VLAN 1, 2, 3, and its PVID is 1, port 1 can receive the packets from VLAN 1, 2, 3, but it can only forward the packets to VLAN 1.

The default port VLAN ID (PVID) is assigned to 1 on all interfaces, because they are assigned to default VLAN 1. If there is no other values specified, the default VLAN PVID is used for untagged or priority-tagged frames.



Note:

If you want to change the default PVID of an interface, create VLAN and then includes the interface as a member.

Po	Port PVID Configuration						
	Port	PVID	Acceptable Frame Types	Ingress Filtering	Port Priority		
			. 🔻	- •			
	0/1	1	All	Disabled	0		
	0/2	1	All	Disabled	0		
	0/3	1	All	Disabled	0		
	0/4	1	All	Disabled	0		
	0/5	1	All	Disabled	0		
	0/6	1	All	Disabled	0		
	0/7	1	All	Disabled	0		
	0/8	1	All	Disabled	0		
	po1	1	All	Disabled	0		
	po2	1	All	Disabled	0		
	po3	1	All	Disabled	0		

Apply

Port PVID Configuration

Port PVID Configuration

Description	Factory default			
Port				
This field displays the interface number or port channel number.	interface number			
PVID				
This field displays the current PVID.	1			
Acceptable Frame Types				
Specify the types of frames that can be received on the interface:				
 All: Accept tagged, untagged, and priority-tagged frames. Untagged or 				
priority-tagged frames are assigned the VLAN ID for this interface.				
VLAN-tagged frames are forwarded.	All			
 Tagged: Only forward VLAN-tagged frames, drop all other frames. 				
 UnTagged and Priority Tagged: Forward untagged and priority-tagged 				
frames, drop VLAN-tagged frames.				
Ingress Filtering				
Specify whether the ingress filtering is applied:				
• Enabled: The ingress filtering is enabled for the interface. If the interface is				
not a member of VLAN with which the frame is associated, an incoming				
frame is dropped. In a tagged frame, VLAN is identified by the VLAN ID in	Disabled			
the tag. In an untagged frame, VLAN is PVID.				
Disabled: The ingress filtering is disabled for the interface. All frames are				
forwarded.				
Port Priority				
Enter the default priority that is assigned to incoming untagged packets. Enter a				
number between 0 and 7. And 7 is the highest priority.				

3.4.6 GVRP Configuration

The GARP (Generic Attribute Registration Protocol) VLAN Registration Protocol defines a GARP application that provides the 802.1Q-compliant VLAN pruning and dynamic VLAN creation on 802.1Q trunk ports. With GVRP, the switch can exchange VLAN configuration information with other GVRP switches, prune unnecessary broadcast and unknown unicast traffic, and dynamically create and manage VLANs on switches connected through 802.1Q trunk ports.

Note:

If you need to configure Port Configuration, we suggest that you make sure that GVRP Configuration is enabled, or it can not work on Port Configuration.

GVRP Configuration

GVRP Configuration		
GVRP Mode	Disable Enable	

GVRP Port Configuration				
	Interface	Port GVRP Mode		
		- •		
	0/1	Enable		
	0/2	Enable		
	0/3	Enable		
	0/4	Enable		
	0/5	Enable		
	0/6	Enable		
	0/7	Enable		
	0/8	Enable		
	po1	Enable		
	po2	Enable		
	ро3	Enable		

Cancel Apply

GVRP Configuration

Description	Factory default
GVRP Mode	
Specify whether the GVRP mode is enabled.	
Disable: The GVRP mode is disabled.	Enable
Enable: The GVRP mode is enabled.	
GVRP Port Configuration	

Description	Factory default
Interface	
This field displays the interface number.	interface number
Port GVRP Mode	
Specify whether the GVRP mode is enabled on the interface.	Enable

3.4.7 QinQ VLAN Configuration

Double VLAN (Q-in-Q VLAN) is a way to pass VLAN traffic from one customer domain to another through a metro core. The function allows admin user to add an additional tag in one Ethernet frame.

QinQ VLAN Configuration

Global Configuration		
Global Status	Disable 🔻	
Global EtherType	Custom Tag 🔻	
Custom Value	0x8100	(0x0001 to 0xFFFF)

Global Configuration

Description	Factory default
Global Status	

Specify whether the status in global configuration is activated or not.	Disable
Global EtherType	
Specify which EtherType can be globally configured.	
802.1Q Tag: Set EtherType as 802.1Q mode.	
vMAN Tag: Set EtherType as vMAN mode.	802.1Q
• Custom Tag: Set EtherType as Custom mdoe.You can define the TPID of the	
VLAN, and the range is 0x0001 to 0xFFFF.	
Custom Value	
Specify the TPID when the Global EtherType is Custom Tag.The TPID will be	0,2100
effective on the provider port. The range is from 0x0001 to 0xFFFF	0100

Double VLAN Configuration		
	Interface	Admin Mode
		- 🗸
	0/1	Disable
	0/2	Disable
	0/3	Disable
	0/4	Disable
	0/5	Disable
	0/6	Disable
	0/7	Disable
	0/8	Disable
	0/9	Disable
	0/10	Disable
	0/11	Disable
	0/12	Disable

Double VLAN Configuration

Description	Factory default
Interface	
The interface number.	interface number
Admin Mode	
Enable/Disable the feature on the port.	
• Enable: Enable Double VLAN (Q-in-Q) function. The port will become provider	
port	Disable
• Disable: Disable the Double VLAN (Q-in-Q) function, and the port becomes a	
customer port.	

3.4.8 MAC Based VLAN

A MAC based VLAN feature allows incoming untagged and priority packets to be assigned to a VLAN, and thus classify the traffic based on the source MAC address. It can support 64 MAC based VLAN entries, and can be configured across all ports of the device.

MAC Based VLAN Configuration

M/	AC Based VLAN Configuration	
	MAC Address	VLAN ID
	Add Delete	Cancel

MAC Based VLAN

Description	Factory default
MAC Address	
Specify a unicast mac address.	None
VLAN ID	
Specify a vlan ID, and the range is 1 to 4094.	None

3.4.9 IP Subnet Based VLAN

An IP Subnet Based VLAN feature allows incoming untagged and priority packets to be assigned to a VLAN, and thus classify the traffic based on the IP subnet of the packet. It can support 16 IP Subnet Based VLAN entries, and can be configured across all ports of the device.

IP Subnet Based VLAN Configuration



Add Delete Cancel

IP Subnet Based VLAN

Description	Factory default
IP Address	
Specify an IP network address for the subnet.	None
Subnet Mask	
Specify a subnet mask for the IP subnet.	None
VLAN ID	
Specify a vlan ID and the range is 1 to 4094.	None

3.5 Multicast Filtering

Multicast IP traffic is traffic that is assigned to a host group. Host groups are identified by class D IP addresses, which range from 224.0.0.0 to 239.255.255.255. A multicast IP packet is only sent by one host to multiple hosts. Only those hosts that belong to a specific multicast group will receive the multicast. The Internet Group Management Protocol (IGMP) snooping enables the switch to forward multicast traffic intelligently to only the interface that requests the multicast traffic. So the network resource is not wasted too much.

If there is a network without the multicast filtering, and a host needs to send data to many hosts, then it needs to produce several copies in the network. It wastes too much network bandwidth. If there is a network with the multicast filtering, then it reduces the load of resources (ex. a server) and makes the network bandwidth efficient. The figures below show the difference between the network without Multicast Filtering and the network with Multicast Filtering.

IMPORTANT:

Make sure that you save the configuration in the Save Configuration page after you have applied the configuration changes. (Save Config \rightarrow Save Configuration) If you do not save the configuration, then the configuration will be cleared after the switch is rebooted.

Network without Multicast Filtering:



Network with Multicast Filtering:



(Only the host which belongs to the group can receive the traffic.)

IGMP Snooping manages multicast traffic by making use of switches, routers, and hosts that support IGMP. Enabling IGMP Snooping allows the ports to detect the IGMP queries, report packets, and manage multicast traffic through the switch. IGMP has three fundamental types of messages, as shown below:

Message Description	
Query	A message is sent from the querier (an IGMP router or a switch) which asks for a
Query	response from each host that belongs to the multicast group.
Depart	A message is sent by a host to the querier to indicate that the host wants to be or is a
Report	member of a given group indicated in the report message.
	A message is sent by a host to the querier to indicate that the host has quit as a
Leave Group	member of a specific multicast group.

3.5.1 IGMP Snooping Configuration

On this page, you can enable or disable IGMP Snooping. And it displays the VLAN which enables the IGMP Snooping function.

IGMP Snooping Configuration

IGMP

IGHP Shooping Configuratio	<i>л</i> і
Admin Mode	🖲 Disable 🔘 Enable
Unknown Multicast Filtering	🖲 Disable 🔘 Enable
Querier Version	2 💌
Querier Interval (secs)	125 (60 to 600)
1,3	
	Ketresn Cancel Apply
ing Configuration	

Description	Factory default
Admin Mode	
Specify the status of IGMP Snooping:	
Disable: The IGMP Snooping is disabled. The IGMP setting still can be	
configured, but the settings do not take effect after you have applied them.	Disable
Enable: The IGMP Snooping is enabled. The switch snoops all the IGMP	Diodolo
packets it receives to determine which segments should receive the	
packets directed to the group address.	
Unknown Multicast Filtering	1
Specify the status of the unknown multicast filtering:	
Disable: Unknown multicast traffic is not filtered and is forwarded.	Disable
Enable: Unknown multicast traffic is filtered and dropped.	
Querier Version	
Specify the IGMP protocol version used in periodic IGMP queries.	
 IGMP v1: Support the member query and the report function. 	
 IGMP v2: Support the general query (the same as IGMPv1), the 	2
group-specific query, the maximum response time, and the leave group	
message function.	
Querier Interval (secs)	
The Querier interval is the amount of time in seconds between IGMP General Query	
messages sent by the router (if the router is the querier on this subnet). Enter a period	125
between 60 and 600 seconds.	

VLAN IDs Enabled for IGMP Snooping

This field displays the VLANs that are enabled for IGMP Snooping. For information about how to configure a VLAN for IGMP Snooping, see the following section.

3.5.2 IGMP VLAN Configuration

This page can configure the IGMP Snooping and the querier status for each VLAN.

IGMP VLAN Configuration



IGMP VLAN Configuration

Description	Factory default
VLAN ID	
Select a VLAN ID for which you want to create an IGMP snooping configuration.	None
Admin Mode	
Specify the IGMP querying status for VLAN:	
• Disable: The query can not be forwarded to all multicast groups in VLAN.	Enable
• Enable: The query can be forwarded to all multicast groups in VLAN.	
Configured Querier Status	
Specify the configured querier status:	
• Disable: The IGMP querying is disabled for VLAN. You can still configure	
VLAN for the snooping, but the settings do not take effect after you have	Disable
applied them.	
• Enable: The IGMP querying is enabled for the VLAN.	
Current Querier Status	
The field displays the current querier status in the VLAN.	Disable

Description	Factory default
Maximum Response Time (tenths of a second)	
Enter the maximum response time for the IGMP query for VLAN. This field specifies	
the maximum period that the switch waits for a response from a host if the switch is	100
the querier for VLAN. Enter a period in tenths of seconds in the range of 0 to 255.	100
Enter 0 to disable the maximum response time.	

3.5.3 IGMP Snooping Multicast Forwarding Table

The multicast forwarding table displays how packets that arrive with a multicast destination MAC address are forwarded. The destination MAC address is combined with the VLAN ID when a packet is sent into the switch. And the multicast searching status and the multicast forwarding status are displayed in the multicast forwarding table. If there is no match found, the packet is flooded to all interfaces in VLAN or discarded. It depends on the configuration. If there is a match found, the packet is forwarded to the interfaces which are the members of the multicast group.

IGMP Snooping Multicast Forwarding Table

IGMP Snooping Multicast Forwarding Table		
VLAN ID	MAC Address	Forwarding Interfaces

Refresh

IGMP Snooping Multicast Forwarding Table

Item	Description
VLAN ID	The VLAN ID for the IGMP snooping configuration.
MAC address	The multicast MAC address from which multicast traffic is requested and sent.
Forwarding Interfaces	The interfaces that request the multicast traffic and to which incoming multicast traffic is forwarded.

3.5.4 Multicast MAC Address Configuration

If required, the Delta switch also supports adding multicast groups manually. You can add a multicast MAC address with a VLAN ID on this page. Before you add a multicast MAC address with a VLAN ID to switch, you have to make sure that the member ports have been assigned to the VLAN ID.

Multicast MAC Address Configuration



Multicast MAC Address Configuration

Description	Factory default
VLAN ID	
Specify the VLAN ID.	None

Description	Factory default
MAC Address	
Specify the multicast MAC address.	None
Member Ports	
Select the member port or LAGs for this multicast group.	None
Static Multicast MAC Address Table	

Item	Description
VLAN ID	The field displays the identifier of VLAN.
MAC Address	The field displays the multicast MAC address.
Member Ports	The field displays the multicast member ports.
Status	The field displays the status of the multicast MAC address.

3.5.5 GMRP Configuration

The GARP (Generic Attribute Registration Protocol) Multicast Registration Protocol helps control the flooding of multicast packets. The GMRP-enabled switches dynamically register and de-register group membership information with the MAC networking devices attached to the same segment.



Note:

If you need to configure the GMRP Port Configuration, we suggest that you make sure that GMRP Configuration is enabled, or the function can not be actived on Port Configuration.

GMRP Configuration

GMRP Configuration	
GMRP Mode	🔘 Disable 🔘 Enable

GMRP Port Configuration		
	Interface	Port GMRP Mode
		- •
	0/1	Enable
	0/2	Enable
	0/3	Enable
	0/4	Enable
	0/5	Enable
	0/6	Enable
	0/7	Enable
	0/8	Enable
	po1	Enable
	ро2	Enable
	ро3	Enable



GMRP Configuration

Description	Factory default
Specify whether the GMRP mode is enabled.	
Disable: The GMRP mode is disabled.	Enable
Enable: The GMRP mode is enabled.	

GMRP Port Configuration

Description	Factory default
Interface	
This field displays the interface number.	interface number
Port GMRP Mode	
Specify whether the GMRP mode is enabled on the interface.	
• Disable: The GMRP mode on the interface is disabled.	Enable
Enable: The GMRP mode on the interface is enabled.	

3.5.6 Multicast Forwarding Table

The multicast MAC address can be added manually, and it also can be added by the GMRP function. This multicast forwarding table can display the type of the MAC address.

Multicast Fo	orwarding Table		
Multicast For	warding Table		
Auto-refresh			
VLAN ID	MAC Address	Туре	Forwarding Interfaces
		Refresh	

Multicast Forwarding Table

ltem	Description
Auto-refresh	Checkmark this box, it will refresh the multicast forwarding table automatically.
VLAN ID	The field displays the identifier of VLAN.
MAC Address	The field displays the multicast MAC address.
Туре	The field displays that the learning type is static or dynamic.
Forwarding Interfaces	The field displays the forwarding interface number.

3.6 Traffic Prioritization

The traffic prioritization allows you to make sure that the time-sensitive and system-critical data can be transferred with the minimal delay. It uses four queues that are present in UI from the high priority to the low priority.

The Delta switch supports the DSCP trust mode, the 802.1p trust mode, the queue scheduling (Support Weighted Round Robin and Strict-Priority) and 4 level priority queues. The traffic prioritization depends on 2 methods:

- **IEEE 802.1P:** a layer 2 marking scheme.
- Differentiated Services (DiffServ): a layer 3 marking scheme.

IMPORTANT:

Make sure that you save the configuration in the Save Configuration page after you have applied the configuration changes. (Save Config \rightarrow Save Configuration) If you do not save the configuration, then the configuration will be cleared after the switch is rebooted.

3.6.1 QoS

Quality of Service (QoS) provides a traffic prioritization for you to alleviate the congestion problem, and ensure that high-priority traffic is delivered first. If the bandwidth of the network is limited, you can use QoS to schedule the priority of a different service packet flow.

3.6.1.1 QoS Setting

QoS Setting

QoS	Setting						
۲	Global	All 🗸	Global Trust Mode	trust dot1p	*	Global Schedule Scheme	wrr 💌
0	Interface	~	Interface Trust Mode	trust dot1p	~	Interface Schedule Scheme	wrr 🗸

QoS Setting

Cancel Apply

Global: Specify the trust mode settings for all interfaces and aggregation groups. Then, make a selection from the Global Trust Mode drop-down list.

Description	Factory default
Global Trust Mode	
Make a selection from the Global Trust Mode drop-down list that affects all	
interfaces or aggregation groups:	
• trust dot1p: All interfaces or aggregation groups are configured for the	truct dot1p
802.1p marking to classify traffic.	trust dot ip
• trust ip-dscp: All interfaces and aggregation groups are configured for	
the IP DSCP packet matching to classify traffic.	
Global Schedule Scheme	
Make a selection from the Global Schedule Scheme drop-down list that affects all	
interfaces:	
• sp: SP (Strict-Priority) classifies the queue from the high priority to the	
low priority. If the higher priority of the queue is empty, the lower priority	\A/rr
data of the queue starts to be sent.	VVII
• wrr: WRR (Weighted Round Robin) schedules the queue by turns, so	
each queue has a service time. Each queue can be allocated a weight	
value or percentage for the bandwidth.	

• Interface: Specify the trust mode settings for an individual interface and aggregation groups. Select an interface or aggregation groups from the Interface drop-down list, and then make a selection from the Interface Trust Mode drop-down list.

Description	Factory default
Interface Trust Mode	
Make a selection from the Interface Trust Mode drop-down list that affects an	
individual interfaces or aggregation groups:	
• trust dot1p: The interface or aggregation groups are configured for the	truct dot1p
802.1p marking to classify traffic.	liusi uoliip
• trust ip-dscp: The interface and aggregation groups are configured for	
the IP DSCP packet matching to classify traffic.	
Interface Schedule Scheme	
Make a selection from the Global Schedule Scheme drop-down list that affects all	
interfaces:	
• sp: SP (Strict-Priority) classifies the queue from the high priority to the	
low priority. If the higher priority of the queue is empty, the lower priority	\\/rr
data of the queue starts to be sent.	VVII
wrr: WRR (Weighted Round Robin) schedules the queue by turns, so	
each queue has a service time. Each queue can be allocated a weight	
value or percentage for the bandwidth.	

3.6.1.2 CoS Queue Mapping

This page allows you to configure the CoS value for the physical queue mapping table. The field specifies a priority value between 0 and 7, and the Delta switch provides 4 physical queues which can be used by Quality of Service (QoS) for differentiate network traffic.

Cos Queue Mapping

Interface Selection														
Interface 0/1 -														
Cos Queue Mapping														
CoS	0		1		2		3		4	5	6		7	
Queue	Normal	•	Low	•	Low	•	Normal	•	Medium 👻	Medium 👻	High	•	High	-
Cancel Apply														

Interface Selection

Specify one of the following selections:

- Select from 0/1 through 0/9: Specify an individual interface.
- Select from po1 through po3: Specify a link aggregation group.
- Select All: Specify all interfaces and link aggregation groups.

CoS Queue Mapping

Select a queue to which you want to map the priority. The traffic class is the selected queue (Low, Normal, Medium, or High) for an interface.

The default queues of the CoS are mapped in the way described below.

CoS	0	1	2	3	4	5	6	7
Queue	Normal	Low	Low	Normal	Medium	Medium	High	High

3.6.1.3 DSCP Queue Mapping

This page allows you to configure the DSCP value to the physical queue mapping table. The field specifies a priority value between 0 and 63, and the Delta switch provides 4 physical queues which can be used by Quality of Service (QoS) for differentiate network traffic. Users can configure the mapping table to follow the upper layer 3 switch or the routers' DSCP setting.

DSCP Queue Mapping

Interface Selection	
Interface	0/1 🗸

DSCP	DSCP Queue Mapping										
IP DSCP	Queue	IP DSCP	Queue	IP DSCP	Queue	IP DSCP	Queue				
0	Normal 💌	16	Low 💌	32	Medium 💌	48	High 🔽				
1	Normal 💌	17	Low 💌	33	Medium 🛩	49	High 🗸				
2	Normal 💌	18	Low 💌	34	Medium 💌	50	High 🔽				
3	Normal 💌	19	Low 💌	35	Medium 🐱	51	High 🗸				
4	Normal 💌	20	Low 💙	36	Medium 💌	52	High 🔽				
5	Normal 💌	21	Low 🗸	37	Medium 💌	53	High 🗸				
6	Normal 💌	22	Low 💌	38	Medium 💌	54	High 🔽				
7	Normal 💌	23	Low 💌	39	Medium 💌	55	High 🗸				
8	Low 🗸	24	Normal 💌	40	Medium 💌	56	High 🔽				
9	Low 🗸	25	Normal 💌	41	Medium 💌	57	High 🗸				
10	Low 🗸	26	Normal 💌	42	Medium 💌	58	High 🔽				
11	Low 🗸	27	Normal 💌	43	Medium 💌	59	High 🗸				
12	Low 🗸	28	Normal 💌	44	Medium 💌	60	High 🔽				
13	Low 🗸	29	Normal 💌	45	Medium 💌	61	High 🗸				
14	Low 🗸	30	Normal 💌	46	Medium 💌	62	High 💌				
15	Low 🗸	31	Normal 💌	47	Medium 🛩	63	High 🗸				

Cancel Apply

Interface Selection

Specify one of the following selections:

- Select from 0/1 through 0/9: Specify an individual interface.
- Select from po1 through po3: Specify a link aggregation group.
- Select All: Specify all interfaces and link aggregation groups.

DSCP Queue Mapping

Select a queue to which you want to map the priority. The traffic class is the selected queue (Low, Normal, Medium, or High).

The previous figure shows the default queues for each IP DSCP value:

- IP DSCP values 0 through 7 and 24 through 31 at queue Normal
- IP DSCP values 8 through 23 at queue Low
- IP DSCP values 32 through 47 at queue Medium
- IP DSCP values 48 through 63 at queue High

3.7 Traffic Control

You can see the MAC addresses which the Delta switch had learned, and configure a port which is to be protected or unprotected in this group.

IMPORTANT:

Make sure that you save the configuration in the Save Configuration page after you have applied the configuration changes. (Save Config-Save Configuration) If you do not save the configuration, then the configuration will be cleared after the switch is rebooted.

3.7.1 Port Isolation Configuration

This function supports two mode group which are isolated or community. When enabled, the member port in the group cannot forward its engress traffic to any other members in the same group. The ingress traffic from a port in isolated group can be forwarded to anyone in the same VLAN that are not in an isolated group.

Port Isolation Configuration



Port Isolation Configuration

Description	Factory default
Group Name	
Specify the Port Isolation group name, and the name string can be up to 24 bytes of	None
non-blank characters.	
Group ID	
Specify the Port Isolation group ID, and the range of group is 1 to 24.	None
Group Mode	
Specify the Port Isolaion group mode.	None
• Isolated: The members in the group cannot forward its engress traffic to	
any other member ports in the same group.	
Community: Each member port can forward traffic to other mebers in the	
same group, but not to member ports in other group.	

Port Isolation Membership

Description	Factory default
Group ID	
Display the Group IDs which added in the Port isolation configuration.	Fixed
Group Name	
Display the Group Name and it's related to the Group ID.	Fixed
Group Mode	
Display the Group mode and it's related to the Group ID	Fixed
Port Number	
Select the member port which you want to add in the specific group.	None

3.8 Port Bandwidth

A Delta switch allows you to configure bandwidth for each port to avoid a network traffic storm.

IMPORTANT:

Make sure that you save the configuration in the Save Configuration page after you have applied the configuration changes. (Save Config \rightarrow Save Configuration) If you do not save the configuration, then the configuration will be cleared after the switch is rebooted.

3.8.1 Storm Control

A traffic storm occurs when incoming packets flood the LAN, which causes the decreasing of the network performance. The storm control can prevent flooding packets from affecting the network performance. The Delta switch allows you to configure both storm control for each interface and rate limiting of each interface for incoming and outgoing traffic.

3.8.1.1 Storm Control Setting

A broadcast storm occurs when a large number of broadcast messages are transmitted from a single interface across a network at the same time. Forwarding these messages can overload too much network resources or cause the network timeout.

The Delta switch can measure the incoming packet rate of the broadcast, multicast, and unknown unicast packets for each interface and discards packets when the rate exceeds the defined value. You can enable storm control for each interface by a different packet type and define the threshold of the traffic flow.



Note:

We strongly recommend using Recovery time 1000pps for optimal performance of this feature.

Storm Control	Setting
---------------	---------

Global Configuration		
	Recovery Mode	Recovery Level
Broadcast Storm	Enable 🔻	1000pps 🔻
Multicast Storm	Disable 🔻	1000pps 🔻
Unicast Storm	Disable 🔻	1000pps 🔻

Refresh Apply

Storm Control Setting

Description	Factory default
Port	
The interface number.	interface number
Recovery Mode	
Specify the recovery mode by making a selection from the drop-down list:	Enable
• Disable: The recovery mode is disabled. No traffic is discarded.	
• Enable: When traffic on the port exceeds the threshold that is configured in	
the Recovery Level field, the switch discards the traffic.	
Recovery Level Type	
Specify the link speed recovery level type.	Mbps
Recovery Level	
Specify the threshold at which storm control is activated. If the value is 5, it indicates 5	
Mbps. By default, when the traffic exceeds 5 Mbps of the link speed, the switch	5
discards the traffic.	
Note:	



For each interface and each of the three types of traffic, you can set the recovery mode and recovery level. The drop-down lists and the fields functions the same for each of the three types of traffic.
3.8.1.2 Rate Limiting

You can configure the traffic rate for each interface in both directions on this page.

Rate Limiting

Rate Limiting							
	Port	Egress RateLimit (kbps)	Ingress RateLimit (kbps)				
	0/1	0	0				
	0/2	0	0				
	0/3	0	0				
	0/4	0	0				
	0/5	0	0				
	0/6	0	0				
	0/7	0	0				
	0/8	0	0				

Refresh Apply

Rate Limiting

Description	Factory default
Port	
The interface number	interface number
Egress RateLimit (kbps)	
Enter the egress port rate limit as a value in the range of 1 to 1,000,000 kbits per	
second (kbits/s). The value that you enter is actually applied in increments of 64	0
kbits/s. If the value is 0, it effectively disables the rate limit.	
Ingress RateLimit (kbps)	
Enter the ingress port rate limit as a value in the range of 1 to 1,000,000 kbits per	
second (kbits/s). The value that you enter is actually applied in increments of 64	0
kbits/s. If the value is 0, it effectively disables the rate limit.	

3.9 Port Trunking

Port Trunking can help you aggregate more links to form one link group. The LAG function of Delta DVS series switch supports 3 trunk groups, and you can assign 8 ports to one group. But there is a limit of 3 gigabit ports or 7 10/100Mbps ports for each lag ID. Link Aggregation (LA) increases the capacity and availability of the communication channel between devices (both switches and end stations) using existing Fast Ethernet and the Gigabit Ethernet technology. LA also provides load balancing where the processing activity and the communication activity are distributed across several links in a trunk.

If there are 4 ports in a trunk group, and one port fails, then the other seven ports will provide backups and share the traffic automatically. LA also can be used to combine 4 ports between Delta DVS series switches. If all ports on these two switches are configured as 100BaseTX and full duplex, then the potential bandwidth of the connection can be 400Mbps. The function theory is shown in the figure below.



IMPORTANT:

Make sure that you save the configuration in the Save Configuration page after you have applied the configuration changes. (Save Config \rightarrow Save Configuration) If you do not save the configuration, then the configuration will be cleared after the switch is rebooted.

3.9.1 LAG

Link aggregation groups (LAGs) let you combine multiple full-duplex Ethernet links into a single logical link. LAG increases fault tolerance and provide traffic sharing. You can assign LAG VLAN membership after you have added interfaces as members of a LAG.

After you have added interfaces to a LAG and enabled the LAG, Link Aggregation Control Protocol (LACP) can automatically configure a port channel link between the switch and another device.

3.9.1.1 LAG Membership

When the static mode of the port-channel is enabled, it does not transmit or receive LACPDUs. For example, the member ports do not transmit LACPDUs and all the LACPDUs which are received may be dropped. The factory default is disabled, which means the port-channel is dynamic.

If you want to enable the static mode of a LAG on the Delta switch, make sure that the static mode of a LAG of the other switch which connects to the Delta switch is enabled, too.

LAG Membership

LAG Membership									
LAG ID		Lag 1 🔻		Sta	tic Mode		Disable	-	
Port	1	2	3	4	5	6	7	8	

Cancel Apply

LAG Membership

ltem	Description
LAG ID	Select the LAG ID from the drop-down list.
Static Mode	Specify whether the static mode of the LAG ID is enabled.
Port	Select one or more interfaces by clicking the square or click for the second time to clear the interface.

3.9.1.2 LAG Information

The LAG information is displayed on this page.

LAG Information

LAG Information						
LAG ID	Static Mode	Configured Ports	Active Ports	LAG State		
lag 1	Disable			DOWN		
lag 2	Disable			DOWN		
lag 3	Disable			DOWN		

Refresh

LAG Information

Item	Description
LAG ID	This field displays the LAG identifier.
Static Mode	The field displays whether the static mode is enabled.
Configured Ports	The field displays the ports which have been configured to the LAG ID.
Active Ports	The field displays the active ports.
LAG State	The field displays whether the LAG state is link up or link down.

3.10 Access Control List

Access control lists (ACLs) can make sure that only authorized devices have access to specific resources when any unauthorized devices which are blocked attempt to access network resources. ACLs provide security for the network, traffic flow control, and determine which types of traffic can be forwarded or blocked.

The Delta switch supports ACLs based on the MAC addresses of the source and destination devices (MAC ACLs).

The steps of configuring an ACL:

- 1. Create a MAC-based ACL name.
- 2. Create a rule and assign it to an ACL.
- 3. Assign an ACL to an interface.

IMPORTANT:

Make sure that you save the configuration in the Save Configuration page after you have applied the configuration changes. (Save Config \rightarrow Save Configuration) If you do not save the configuration, then the configuration will be cleared after the switch is rebooted.

3.10.1 MAC ACL

A MAC ACL consists of a set of rules that are matched sequentially to compare the packets. With a MAC ACL, you can specify the MAC address of the source device, destination device, or both. When a packet matches the criteria with a rule, and the specified rule action(permit or deny) is applied, then any additional rules will not be checked whether the packet is matched or not.

MAC ACL

MAC ACL	
Current Number of ACLs	1
Maximum ACLs	100

MAC ACL Table						
	Name	Rules	Direction			
	Marketing	2	In Bound			



MAC ACL

Setting	Description
Current Number of ACLs	The field displays the sum of the configured ACLs.
Maximum ACLs	The field displays the maximum number of MAC ACLs that can be configured (100).

MAC ACL Table

Setting	Description
Name	Specify a name for an ACL. The name can include alphabetic, numeric, dash, underscore, or space characters. It must start with an alphabetic character.
Rules	The number of rules that are configured for the MAC ACL.
Direction	The direction of the packet traffic that is affected by the MAC ACL. This is a fixed entry that always shows In Bound; only inbound traffic is subject to the MAC ACL.

3.10.1.1 MAC Rules

After creating an ACL name, you can configure the action, match, destination MAC, source MAC and VLAN on this page. It can determine whether the packet is forwarded normally or discarded.

Note:

You need to create an implicit *deny all* rule at the end of an ACL rule table to make sure that a packet is dropped if an ACL is applied to the packet and none of the explicit rules match.

MAC Rules

Rul	Rules							
ACL	ACL Name Marketing 🛩							
Rul	e Table							
	ID	Action	Match Every	Destination MAC	Destination MAC Mask	EtherType Key		
		- 🗸	- 🗸			- 🗸		
	1	Permit	False	00:11:22:aa:bb:cc	ff:ff:ff:ff:ff			
	2	Deny	True					

Add Delete Cancel Apply

EtherType User Value	Source MAC	Source MAC Mask	VLAN
	00:22:44:22:44:66	ff:ff:ff:ff:ff	2

Rule Table

Description	Factory default
ID	-
Enter an ID for the rule. Enter a number between 1 and 10. This means that you can	N
create up to 10 rules for a single MAC ACL name.	None
Action	
Specify the action for the rule:	
Permit: Packets that meet the ACL criteria are forwarded.	None
• Deny: Packets that meet the ACL criteria are dropped.	
Match Every	
Specify whether all packets need to match the rule:	
• True: All packets need to match the rule. Other rules are not considered,	
and the fields to the right of the Match Every field are disabled.	True
False: Not all packets need to match the rule. Other rules are also	
considered.	
Destination MAC	
Specify the MAC address of the destination device that needs to be compared with	
the information in a packet. Enter a MAC address in the xx:xx:xx:xx:xx:xx format.	None
Destination MAC Mask	
Specify the MAC mask that is associated with the destination MAC address. The MAC	
mask specifies the bits in the destination MAC address which need to be compared	
with the information in a packet.	
Note:	
Use zeros and Es in the MAC mask. An E means that the bit is not	None
checked and a zero in a bit position means that the data needs to be equal	
to the value given to that bit. For example, if the MAC address is	
aa b cc: dd ee ff and the mask is 00:00 ff ff ff all MAC addresses with	
aa:bb:cc:dd:cc:n, and the mack is cc:cc:n.i.i.in, an invite addrected with	
EtherTyne Key	
Specify the EtherType that needs to be compared with the information in a packet:	
Appletalk, IBM SNA, IPX, MPI S multicast, MPI S unicast, NetBIOS, Novell.	
PPPoE EthernCAT Profinet-RT SERCOS III CC-link IE Powerlink User Value	None
If you select User Value, enter the value in the EtherType User Value field	
FtherType User Value	
If you select User Value from the EtherType Key drop-down list, enter the value, which	
is a number in the range of 1536 to 65535	None
Source MAC	
Specify the MAC address of the source device that needs to be compared with the	
information in a packet. Enter a MAC address in the xx:xx:xx:xx:xx format.	None
Source MAC Mask	
As an option, specify the MAC mask that is associated with the source MAC address.	
The MAC mask specifies the bits in the source MAC address which need to be	
compared with the information in a packet.	
Note:	None
Use zeros and Es in the MAC mask An E means that the bit is not checked	
and a zero in a bit position means that the data needs to be equal to the	
value given to that bit. For example, if the MAC address is aa:bb:cc:dd:ee:ff.	

Description	Factory default
and the mask is 00:00:ff:ff:ff:ff, all MAC addresses with aa:bb:xx:xx:xx: result in a match (where x is any hexadecimal number).	
VLAN	1
Specify the VLAN ID that needs to be compared with the information in a packet.	
Enter a number in the range of 0 to 4095. You can not enter a VLAN range.	
Note:	None
Most VLAN configurations on the switch are in the range of 1 to 4093.	
However, an ACL can detect a VLAN in the range of 0 to 4095.	

3.10.1.2 MAC Binding Configuration

When you bind a MAC ACL to an interface, all rules that you have defined for the MAC ACL are applied to the interface. **MAC Binding Configuration**

MAC Binding Configuration									
ACL ID		-		Dir	ection			▼	
Sequence	e Number	0		(1	∾ 42949	67295)			
Port	1	2	3	4	5	6	7	8	
LAG			1		2		3		

Interface Binding Status					
Interface	Direction	ACL Type	ACL ID	Seq No	

Cancel Apply

MAC Binding Configuration

Setting	Description
ACL ID	Select an ACL ID to bind MAC.
Direction	The Direction drop-down list is fixed at Inbound. Only incoming packets can be
Direction	filtered.
Sequence Number	Enter a number in the range of 1 to 4,294,967,295.
Dort	Select one interface or more interfaces by clicking the square or click for the
Poll	second time to clear the interface.
1.00	Select one LAG or more LAGs by clicking the square or click for the second time
	to clear the interface.

Interface Binding Status

Setting	Description
Interface	The interface to which the MAC ACL is bound
	The packet filtering direction for the MAC ACL. The only valid direction is
Direction	Inbound, which means the MAC ACL rules are applied to traffic entering the
	interface.
	The type of ACL to which the interface is bound. This is a fixed field that always
ACL Type	shows MAC ACL.
ACL ID	The name of the ACL to which the interface is bound
	The sequence number that signifies the order of the ACL to which the interface is
	bound. The number should be configured from 1 to 4,294,967,295.
Seq No	The sequence number specifies the order of the ACL relative to the existing
	ACLs that are bound to the same interface or interfaces. A lower number
	specifies a higher precedence order. If a sequence number is already in use for

3

Setting	Description
	the interface or interfaces, the ACL replaces the existing ACL that uses the same
	sequence number.

3.10.1.3 MAC Binding Table

The MAC binding information is displayed on this page.

MAC Binding Table

MAC Binding Table						
	Interface	Direction	ACL Type	ACL ID	Seq No	
	0/2	In Bound	MAC ACL	Marketing	1	
	0/5	In Bound	MAC ACL	Marketing	1	
	po1	In Bound	MAC ACL	Marketing	1	

Delete Cancel

MAC Binding Table

Setting	Description
Interface	The interface to which the MAC ACL is bound
	The packet filtering direction for the MAC ACL. The only valid direction is
Direction	Inbound, which means the MAC ACL rules are applied to traffic entering the
	interface.
	The type of ACL to which the interface is bound. This is a fixed field that always
ACL Type	shows MAC ACL.
ACL ID	The name of the ACL to which the interface is bound
Sea No	The sequence number that signifies the order of the ACL to which the interface is
	bound.

3.10.2 ARP ACL

ARP ACL consists of a set of rules that are matched sequentially to compare the packets. With a ARP ACL, you can specify the IP address of the source device, destination device, or both. When a packet matches the criteria with a rule, and the specified rule action(permit or deny) is applied, then any additional rules will not be checked whether the packet is matched or not.

ARP ACL

ARP	ACL			
Curren	t Number of ACLs	2		
Maxim	um ACLs	100		
ARP	ACI Table			
ARP	ACL Table Name		Rules	Direction
ARP	ACL Table Name		Rules	Direction

Add Delete Cancel Apply

ARP ACL

Setting	Description
Current Number of ACLs	The field displays the sum of the configured ACLs.
Maximum ACLs	The field displays the maximum number of ARP ACLs that can be configured (100).

ARP ACL Table

Setting	Description
Neme	Specify a name for an ACL. The name can include alphabetic, numeric,
Name	dash, underscore, or space characters. It must start with an alphabetic
	character.
Rules	The number of rules that are configured for the ARP ACL.
	The direction of the packet traffic that is affected by the ARP ACL. This
Direction	is a fixed entry that always shows In Bound; only inbound traffic is
	subject to the ARP ACL.

3.10.2.1 ARP Rules

After creating an ACL name, you can configure the action, match, Sender IP address, Target IP address and Target IP Mask on this page. It can determine whether the packet is forwarded normally or discarded.

Note:

You need to create an implicit *deny all* rule at the end of an ACL rule table to make sure that a packet is dropped if an ACL is applied to the packet and none of the explicit rules match.

ARP Rules Rules ACL Name Rule Table

10	Action	Match Every	Opcode Type	Sender IP Address	Sender IP Mas
	- •		- •		
				Add Delete Canc	el Apply

SSSS V

Rule Table

Description	Factory default		
ID			
Enter an ID for the rule. Enter a number between 1 and 10. This means that you can	None		
Action			
Action			
Specify the action for the rule:			
 Permit: Packets that meet the ACL criteria are forwarded. 	None		
 Deny: Packets that meet the ACL criteria are dropped. 			
Match Every			
Specify whether all packets need to match the rule:			
• True: All packets need to match the rule. Other rules are not considered,			
and the fields to the right of the Match Every field are disabled.	True		
• False: Not all packets need to match the rule. Other rules are also			
considered.			
Sender IP Address			
Specify the Sender IP Address of the destination device that needs to be compared			
with the information in a packet. Enter a IP address in the XXX.XXX.XXX.XXX(EX.	None		
192.168.1.1) format.			
Sender IP Mask			
Specify the Send IP mask that is associated with the Send IP address. None			
Opcode Type	-		
Specify the EtherType that needs to be compared with the information in a packet:	Nono		
ARP Request, ARP Reply, RARP Reply	none		

Description	Factory default
Target IP Address	
Specify the Sender IP Address of the destination device that needs to be compared	
with the information in a packet. Enter a IP address in the XXX.XXX.XXX.XXX(EX.	None
192.168.1.1) format.	
Target IP Mask	
Specify the Send IP mask that is associated with the Send IP address.	None

3.10.2.2 ARP Binding Configuration

When you bind a ARP ACL to an interface, all rules that you have defined for the ARP ACL are applied to the interface. **ARP Binding Configuration**

ARP Binding Configuration												
ACL II)		SSSS	•		Di	rection				•	
Seque	nce Nur	nber	0			(1 ~ 42	94967	295)			
Port	1	2	3	4	5	6	7	8	9	10	11	12
LAG				1			2			3		
Inter	face Bin	ding S	Status									
Interf	ace	[Directio	on		ACL Ty	ре		ACL ID		Seq N	lo

Cancel Apply

ARP Binding Configuration

Setting	Description
ACL ID	Select an ACL ID to bind MAC.
Direction	The Direction drop-down list is fixed at Inbound. Only incoming packets can be filtered.
Sequence Number	Enter a number in the range of 1 to 4,294,967,295.
Port	Select one interface or more interfaces by clicking the square or click for the second time to clear the interface.
LAG	Select one LAG or more LAGs by clicking the square or click for the second time to clear the interface.

Interface Binding Status

Setting	Description
Interface	The interface to which the ARP ACL is bound
	The packet filtering direction for the ARP ACL. The only valid direction is
Direction	Inbound, which means the MAC ACL rules are applied to traffic entering the
	interface.
	The type of ACL to which the interface is bound. This is a fixed field that always
ACL Type	shows ARP ACL.
ACL ID	The name of the ACL to which the interface is bound
	The sequence number that signifies the order of the ACL to which the interface is
	bound. The number should be configured from 1 to 4,294,967,295.
	The sequence number specifies the order of the ACL relative to the existing
Seq No	ACLs that are bound to the same interface or interfaces. A lower number
	specifies a higher precedence order. If a sequence number is already in use for
	the interface or interfaces, the ACL replaces the existing ACL that uses the same
	sequence number.

3.10.2.3 ARP Binding Table

The MAC binding information is displayed on this page.

ARP Binding Table

ARP Binding Table						
	Interface	Direction	ACL Type	ACL ID	Seq No	
	0/4	In Bound	ARP ACL	SSSS	456	

Delete Cancel

MAC Binding Table

Setting	Description
Interface	The interface to which the ARP ACL is bound
	The packet filtering direction for the ARP ACL. The only valid direction is
Direction	Inbound, which means the ARP ACL rules are applied to traffic entering the
	interface.
	The type of ACL to which the interface is bound. This is a fixed field that always
ACL Type	shows ARP ACL.
ACL ID	The name of the ACL to which the interface is bound
Seg No	The sequence number that signifies the order of the ACL to which the interface is
Seq No	bound.

3.11 Security Settings

The Delta DVS series switch provides many ways to verify the packets, authenticate users or block the attack traffic. You can choose and configure these security settings according to your network environment.

IMPORTANT:

Make sure that you save the configuration in the Save Configuration page after you have applied the configuration changes. (Save Config-→Save Configuration) If you do not save the configuration, then the configuration will be cleared after the switch is rebooted.

3.11.1 Security

This group allows you to configure a MAC address, an IP address or the Port authentication to reach the security purpose.

3.11.1.1 Port Security

The port security lets you lock the interface. If the port security of the interface is enabled, then it can only forward the traffic from the MAC addresses that you specified.

The Port Security feature allows you to stop the MAC address learning for a specific port. After you stop the MAC learning (enable Port Security), only the source MAC address of the packet listed in the Static MAC address table with the binding port can access the switch through the port, and other packets will be discarded.

Port Security Configuration

You can specify the interface and enable or disable the port security on this page.

Interface Configuration			
	Port	Port Security	
	0/1	Disable	
	0/2	Disable	
	0/3	Disable	
	0/4	Disable	
	0/5	Disable	
	0/6	Disable	
	0/7	Disable	
	0/8	Disable	

Port Security Configuration



Interface Configuration

Description	Factory default
Port	
The interface number	interface number
Port Security	
Specify whether the port security is enabled:	
• Enable: The port security is enabled for the individual interface. The port	
security also needs to be globally enabled for it to be effective.	Disable
• Disable: The port security is disabled for the individual interface. This	
setting overrides the global port security setting.	

Security MAC Address

The security MAC address table shows the static MAC addresses which is associated with the VLANs. Select the interface for which you want to display the static MAC addresses and their associated VLANs.

Security MAC Address

Port List 0/1 VLAN ID MAC Address	Security MAC Address Table	
VLAN ID MAC Address	ort List	0/1
	LAN ID	MAC Address
1 00:11:22:11:22:33		00:11:22:11:22:33

Refresh

Add Static MAC Address

You can specify the MAC address for a port with a VLAN ID on this page.

Add Static Unicast MAC Address

Add Static Unicast MAC A	ddress
Vlan Id	- 💌
Destination Port	-
Mac Address	

Cancel Add

Static Unicast Mac Address Table					
	Vlan Id	Mac Address	Destination Port	Status	
	1	00:11:22:11:22:33	0/1		
	1	00,11,22,11,22,33	0/1		

Cancel Delete

Add Static Unicast MAC Address

Setting	Description		
VLAN ID	Specify the VLAN ID to which the unicast traffic is assigned.		
Destination Port	Specify the switch interface or link aggregation group to which the unicast traffic is directed. Note: Make sure that the destination port you choose is the member of VLAN ID that you select		
MAC Address	Enter the MAC address of the device that is the source of the unicast traffic.		

Static Unicast Mac Address Table

Setting	Description		
VLAN ID	Display the VLAN ID to which the unicast traffic is assigned.		
MAC Address	Display the MAC address of the device that is the source of the unicast traffic.		
Destinction Dart	Display the switch interface or link aggregation group to which the unicast traffic		
Destination Port	is directed.		
Status	Display the timeout status. It is fixed in the Permanent status.		

3.11.1.2 IP Source

You can configure a specific IP address to access the Delta switch. Only the IP addresses which is added to this list can access and configure the Delta switch.



IP Source

Setting	Description		
IP Address			
Enter the source IP address for security.	None		
Subnet Mask			
Enter the subnet mask of the IP address.	None		

3.11.1.3 802.1X

The Delta switch can act as an authenticator in the 802.1X environment. You can either use an external authentication server, or implement the authentication server in the Delta switch by using a Local User Database.

There are three components used to create a port-based authentication mechanism based on 802.1X:

Supplicant: The end of the station that requests the access to the LAN resource and switch services.

Authentication Server: The external server that performs the actual authentication of the supplicant, for example, a RADIUS server. It performs the authentication to indicate whether the user is authorized to access services. Authenticator: It acts as a proxy between the supplicant and the authentication server. This kind of role is usually the edge switch or the wireless AP. It requests identity information from the supplicant, verifies the information with the

authentication server, and relay a response to the supplicant.

The function theory is shown in the figure below.



802.1X Basic Settings

IEEE 802.1X is an IEEE Standard for port-based Network Access Control (PNAC). It is a part of the IEEE 802.1 group of networking protocols. It provides an authentication mechanism for devices which attempt to connect with a LAN or WLAN. IEEE 802.1X defines the encapsulation of the Extensible Authentication Protocol (EAP) over IEEE 802 which is known as "EAP over LAN" or EAPOL.

802.1X Basic Settings

802.1X Configuration		
System Control	Shutdown	Start
802.1X Authentication	Disable	Enable
Authentication Mode	Local	Remote
Remote Authentication Server Type	TACACS+	RADIUS
Network Access Server ID	fsNas1	



802.1X Basic Settings

Description	Factory default			
System Control				
Specify whether the 802.1X authentication module on the switch is running or shut				
down.				
• Shutdown: The 802.1X authentication is shut down. You can not configure	Start			
or enable the 802.1X authentication.	Oldit			
• Start: The 802.1X authentication is running, and you can configure and				
enable it.				
802.1X Authentication				
Specify the status of the 802.1X authentication on the switch.				
• Disable: The 802.1X authentication is disabled. You can still configure the				
802.1X authentication, but the settings do not take effect after you have				
applied them. The switch does not check the 802.1X authentication before				
allowing traffic on any interfaces, even if the interfaces are configured to	Enable			
allow only authenticated users.				
• Enable: The 802.1X authentication is enabled. You can configure the				
802.1x authentication, and the settings take effect after you have applied				
them.				
Authentication Mode				
Specify the 802.1X authentication mode.				
Local: A locally stored user ID and password are used for port				
authentication. You need to set up a user account on the Local				
Authentication Server page. This is the default setting.	Local			
• Remote: A RADIUS or TACACS+ server is used for the port authentication.				
With this selection, the Remote Authentication Server Type radio buttons				
and Network Access Server ID become available.				
Remote Authentication Server Type				
If you select the Remote mode of Authentication Mode, specify whether a RADIUS or				
IACACS+ server should be used.				
TACACS+: The user ID and the password are authenticated through a	RADIUS			
TACACS+ server.				
RADIUS: The user ID and the password are authenticated through a				
Network Access Server ID				
IT you select the Remote radio button next to Authentication Mode, enter the network	Fixed			
access server (INAS) ID, or use the default ID (ISNas1).				

Port Authentication

You can configure the authentication settings for each interface. Port Authentication

Po	Port Authentication					
	Port	Control Mode	Periodic Reauthentication	Reauthentication Period	EAPOL Packets Flood	
		-	- •		- 🔻	
	0/1	ForceAuthorized	Disabled	3600	Disabled	
	0/2	ForceAuthorized	Disabled	3600	Disabled	
	0/3	ForceAuthorized	Disabled	3600	Disabled	
	0/4	ForceAuthorized	Disabled	3600	Disabled	
	0/5	ForceAuthorized	Disabled	3600	Disabled	
	0/6	ForceAuthorized	Disabled	3600	Disabled	
	0/7	ForceAuthorized	Disabled	3600	Disabled	
	0/8	ForceAuthorized	Disabled	3600	Disabled	

Apply Cancel Refresh

Port Authentication

Description	Factory default			
Port				
This field displays the port number.	Port number			
Control Mode				
Specify the control mode for the port authorization. The control mode is active only if				
the link status of the interface is up.				
ForceUnauthorized: Places the interface in the unauthorized state. The				
switch can not provide authentication services for a client through the				
interface.				
Auto: After any supplicant completes the authentication successfully on the	ForceAuthorized			
interface, others can access the network service through the same interface				
without the authentication.				
ForceAuthorized: Places the interface in the authorized state. The				
interface sends and receives normal traffic without the client port-based				
authentication.				
Periodic Reauthentication				
Specify whether the supplicant is periodically reauthenticated for the interface:				
Enabled: The supplicant is reauthenticated according to the	Disable			
reauthentication period.	Disable			
Disabled: The supplicant is not reauthenticated.				
Reauthentication Period				
Specify the reauthentication period for the interface. The reauthentication period				
determines when the supplicant is reauthenticated when period reauthentication is	3600			
enabled. Enter a period in the range of 1 to 65535 seconds.				
EAPOL Packets Flood				
Specify whether the EAPOL packet flood mode is enabled for the interface:				
Enabled: The EAPOL packet flood mode is enabled. Enabling this mode				
does not provide any protection from an EAPOL packet flood denial of	Disable			
service (DoS) attack. If the switch is used as a hub, you might want to	Disable			
enable the EAPOL packet flood mode.				
Disabled: The EAPOL packet flood mode is disabled.				

Local Authentication Server

The user list on this page and the user list on the Local Users Management page of Management Security are independent. The user list on this page is for 802.1X authentication. So you can configure a different user name with the user on the Local Management page of Management Security.

Local Authentication Server Configuration

Add Local Authentication Server						
	User Name	Password	Permission	Auth-TimeOut (secs)	Port List	
			- •			

Add Delete Cancel Apply

Local Authentication Server Configuration

Description	Factory default		
User Name			
Enter a user name.	None		
Password			
Enter a password. Passwords should consist of 1 through 20 alphanumeric characters	None		
and are case-sensitive. The password is displayed as asterisks (*).	None		
Permission			
Specify whether the user is allowed or denied interface access:	None		

Description	Factory default
Allow: Allows the user access to the interface.	
• Deny: Denies the user access to the interface.	
Auth-TimeOut (secs)	
Specify the period in seconds after which the server authentication timeout occurs and	
the user needs to be reauthenticated by the local authentication server. Enter a period	
between 1 and 7200 seconds. After the supplicant is authorized, the server	
authentication timeout period overrides the reauthentication period that is configured	
for the individual interface (see the Port Authentication page). Leave the	
Auth-TimeOut field blank to use the reauthenticaiton period that is configured for the	
individual interface.	
Note:	
If you enable the server reauthentication after a user has already been	None
authenticated by the server, the server authentication timeout period does	
not take effect, and the reauthentication period value that is configured for	
the individual interface is used.	
Note:	
If the server reauthentication is enabled, a user is authenticated by the	
server. If you change the authentication timeout period, the new	
authentication timeout period takes effect after the next reauthentication by	
the server is complete.	
Port List	
Specify the interfaces from which the authentication needs to be obtained. Leave the	
field blank to include all interfaces.	
Note:	None
The range of port list is dependent on what type of DVS managed switch	
you used.	

Port Summary

This page allows you to view the information about the access control of each interface; you can initialize or reauthenticate the interface manually.

Port Summary

Po	Port Summary						
	Port	Control Mode	Reauthentication Enabled	Port Status	User Name		
		- · · · · · · · · · · · · · · · · · · ·	- •	- •			
	0/1	ForceAuthorized	Disabled	UnAuthorized	No User		
	0/2	ForceAuthorized	Disabled	UnAuthorized	No User		
	0/3	ForceAuthorized	Disabled	UnAuthorized	No User		
	0/4	ForceAuthorized	Disabled	UnAuthorized	No User		
	0/5	ForceAuthorized	Disabled	Authorized	No User		
	0/6	ForceAuthorized	Disabled	Authorized	No User		
	0/7	ForceAuthorized	Disabled	UnAuthorized	No User		
	0/8	ForceAuthorized	Disabled	UnAuthorized	No User		

Initialize Reauthenticate

Refresh

Port Summary

Description	Factory default		
Port			
This field displays the port number.	Port number		
Control Mode			
The port authorization state that you have configured on the Port Authentication page			
(see Port Authentication on page 189). One of the following options is displayed:			
• ForceUnauthorized: The interface functions in the unauthorized state. The			
switch can not provide authentication services for a client through the			
interface.			
Auto: The interface automatically detects the control mode through	ForceAuthorized		
authentication exchanges among the supplicant, the authenticator, and the			
authentication server.			
• ForceAuthorized: The interface functions in the authorized state. The			
interface sends and receives normal traffic without the client port-based			
authentication.			
Reauthentication Enabled			
Indicates whether you have enabled or disabled the reauthentication on the interface.			
Port Status			
The authorization status of the interface (Authorized or Unauthorized)	UnAuthorized		
User Name			
The name of the user most recently authenticated on the port. The user name is for a	None		
user account that is defined on the Local Authentication Server page.			

EAP Statistics

This page allows you to view the EAP statistics. EAP Statistics

EA	EAP Statistics									
		EAPOL								
	Port	Frames Received	Frames Transmitted	Start Frames Received	Logoff Frames Received	Last Frame Version	Last Frame Source	Invalid Frames Received	Length Error Frames Received	
	0/1	0	0	0	0	0	00:00:00:00:00:00	0	0	
	0/2	0	0	0	0	0	00:00:00:00:00:00	0	0	
	0/3	0	0	0	0	0	00:00:00:00:00:00	0	0	
	0/4	0	0	0	0	0	00:00:00:00:00:00	0	0	
	0/5	0	0	0	0	0	00:00:00:00:00:00	0	0	
	0/6	0	0	0	0	0	00:00:00:00:00:00	0	0	
	0/7	0	0	0	0	0	00:00:00:00:00:00	0	0	
	0/8	0	0	0	0	0	00:00:00:00:00:00	0	0	

Refresh	Clear

ЕАР							
Response/ID Frames Received	Response Frames Received	Request/ID Frames Transmitted	Request Frames Transmitted				
0	0	0	0				
0	0	0	0				
0	0	0	0				
0	0	0	0				
0	0	0	0				
0	0	0	0				
0	0	0	0				
0	0	0	0				

EAP Statistics

ltem	Description		
Port	The interface number		
EAPOL (Extensible Authentication Prot	tocol over LAN)		
Frames Received	The total number of received valid EAPOL frames		
Frames Transmitted	The total number of transmitted EAPOL frames		
Start Frames Received	The total number of received EAPOL start frames		
Logoff Frames Received	The total number of received EAPOL logoff frames		
Last Frame Version	The protocol version number attached to the most recently received EAPOL frame		
Last Frame Source	The source MAC address attached to the most recently received EAPOL frame		
Invalid Frames Received	The total number of received unrecognized EAPOL frames		
Length Error Frames Received	The total number of received EAPOL frames with an invalid packet body length		
EAP (Extensible Authentication Protocol)			
Response/ID Frames Received	The total number of received EAP response ID frames		
Response Frames Received	The total number of received valid EAP response frames		
Request/ID Frames Transmitted	The total number of transmitted EAP requested ID frames		
Request Frames Transmitted	The total number of transmitted EAP request frames		

3.11.2 Management Security

In the Management Security group, you can manage local users, the Remote Authorization Dial-In User Service (RADIUS) settings, the Terminal Access Controller Access Control System (TACACS+) settings, and Login Authentication Mode, and monitor the sessions of login users.

3.11.2.1 Local Users Management

For information security, the Delta managed switch provides two access levels of the user to log on the Web management page. Beside the admin account, other user accounts can modify the basic feature which will display in the window when they login. The Web management pages contained in this manual are subject to the admin's login without any explanation.



Note:

If you need the record of the user's log, you can configure the log severity information in Log Configuration of SYSLOG.

Please refer to $\ensuremath{\mathsf{Show}}\xspace$ logs and $\ensuremath{\mathsf{Log}}\xspace$ Configuration.

User Management

User Name	Edit Password	Password	Confirm Password
	· ¥		
admin	Disabled	*****	*****
Add	Delete	Cancel Apoly	

User Management

Description	Factory default

User Name		
Enter a user name. It supports up to 20 users, and a user name consists of up to 20		
characters and is case sensitive. Only alphanumeric characters, dashes (-) and	None	
underscores (_) are accepted.		
Edit Password		
Select Enabled, and then edit the password.	None	
Password		
Enter a password. Passwords are 1–20 alphanumeric characters in length and are	Nono	
case sensitive. The password is displayed as eight asterisks (*).		
Confirm Password		
Enter the same password that you entered in the Password field.	None	

3.11.2.2 RADIUS Server Config

RADIUS (Remote Authentication Dial In User Service) is a networking protocol that provides the centralized Authentication, Authorization, and Accounting (AAA) management for computers to connect and use a network service. The system implements the RADIUS client and provides the authentication functionality. RADIUS uses UDP port 1812 by default.

RADIUS Server Configuration



RADIUS Server Configuration

Description	Factory default				
Server ID					
The identifier of the server	None				
Address Type					
Specify a type of address for the RADIUS server:					
IPv4: The RADIUS server has an IPv4 address.	None				
DNS: The RADIUS server has a DNS host name.					
Server Address					
Enter the IP address or the DNS host name of the RADIUS server. (It depends on	Nono				
whether the Address Type field is IPv4 or DNS.)	None				
Shared secret					
Enter the shared secret (only characters and numbers) that is used to authenticate					
and encrypt communications between the switch and the RADIUS server. This secret					
needs to match the one on the RADIUS server.					
Response Time (secs)					
Enter the response time in seconds. This is the maximum period that the switch waits					
for a response from the RADIUS server before retransmitting the authentication	10				
request. Enter a period in the range of 1 to 120 seconds.					
Retry Count					
Enter the maximum number of times an authentication request is retransmitted. Enter	2				
a number in the range of 1 to 254.	5				
Port					
Enter the UDP port number of the RADIUS server that is used for the authentication.	1812				

3.11.2.3 RADIUS Statistics

After you add a server to the RADIUS Server Configuration page, the statistics is displayed on this page.

RADIUS Statistics								
RADI	RADIUS Server Statistics							
Index	RADIUS Server	UDP Port Number	Round Trip Time	Access Requests	Access Retransmissions	Access Accepts	Access Rejects	Access Challenge
1	192.168.1.10	17	0	0	0	0	0	0

Refresh

Malformed Access Responses	Bad Authenticators	Pending Requests	Timeouts	Unknown Types	Packets Dropped
0	0	0	0	0	0

RADIUS Statistics

Item	Description
Index	The index number of the RADIUS server in the table
RADIUS Server	The IP address of the RADIUS server
UDP Port Number	The UDP port of the RADIUS server that is used for the authentication
	The period, in hundredths of a second, between the most recent access
Round Trip Time	reply/access challenge and the access request that matched it from the RADIUS
	server
Access Pequests	The number of access-request packets that were transmitted to the RADIUS
	server. This number does not include retransmissions.
Access	The number of access-request packets that were retransmitted to the RADIUS
Retransmissions	server
Access Accents	The number of access-accept packets, including both valid and invalid packets,
Access Accepts	which were received from the RADIUS server
Access Rejects	The number of access-reject packets, including both valid and invalid packets,
	which were received from the RADIUS server
Access Challenge	The number of access-challenge packets, including both valid and invalid
	packets, which were received from the RADIUS server
	The number of malformed access-response packets that were received from the
Malformed Access	RADIUS server. Malformed packets include packets with an invalid length. Bad
Responses	authenticators or signature attributes or unknown types are not included as
	malformed access responses.
Bad Authenticators	The number of access-response packets containing invalid authenticators or
	signature attributes that were received from the RADIUS server
Pending Pequests	The number of access-request packets destined for the RADIUS server that
	have not yet timed out or received a response
Timeouts	The number of authentication requests that were sent to the RADIUS server and
	that timed out
Linknown Types	The number of packets of an unknown type that were received from the RADIUS
	server
Packets Dronned	The number of packets that were received from the RADIUS server and that
	were dropped

3.11.2.4 TACACS+ Server

TACACS+ (Terminal Access Controller Access-Control System Plus) provides access control for routers, network access servers (NAS) and other networked computing devices. The system implements the TACACS+ client and provides authentication functionality.

TACACS+ uses TCP port 49 by default. You can configure it according to your TACACS+ server. The Delta switch supports multi TACACS+ servers' configuration and the number is up to 5.

TACACS+ Server Configuration

TACACS+ Server Configuration							
	Addr Type	ess : (*)	IP Address (*)	Shared Secret(*)	Single Connection	Server Port	Server Timeout (secs)
	-	*			- 🗸		
	IPv4		192.168.1.10	password	Yes	5432	10

Add Delete Cancel Apply

TACACS+ Server Configuration

Description	Factory default			
Address Type (*)				
Specify a type of address for the TACACS+ server.				
 IPv4: The TACACS+ server has an IPv4 address. 	None			
DNS: The TACACS+ server has a DNS host name.				
IP Address (*)				
Depending on the selection from the Address Type drop-down list, enter the IP	Nono			
address or the DNS host name of the TACACS+ server.	None			
Shared Secret (*)				
Enter the shared secret (up to 63 characters and numbers) that is used to				
authenticate and encrypt communications between the switch and the TACACS	None			
server. This secret needs to match the one on the TACACS server.				
Single Connection				
Specify a type of connection:				
• Yes: Allows only a single TCP connection with the TACACS server.	No			
No: Allows multiple TCP connections with the TACACS server.				
Server Port				
Enter the TCP port number of the TACACS server that is used for authentication. The	40			
port number should be in the range of 1 to 65535.	49			
Server Timeout (secs)				
Enter the period in seconds after which the connection between the client device and	E			
the TACACS server times out. Enter a period in the range of 1 to 255 seconds.	Э			

3.11.2.5 TACACS+ AS

If you do not specify a TACACS+ AS (TACACS+ Active Service), the switch uses one of the TACACS+ servers that you specify on the TACACS+ Server Configuration page. If you specify a TACACS+ Active Server (AS), the switch uses only that server as the active TACACS+ server. So you can only specify one active server on this page.

TACACS+ AS Configuration

TACACS+ AS Configuration					
ActiveServer Address Type	ActiveServer Address	Retransmit			
- V					

Add Delete Cancel

TACACS+ AS Configuration

Description	Factory default	
Active Server Address Type		
Specify a type of address for the TACACS+ AS.	None	

 IPv4: The TACACS+ AS server has an IPv4 address. 		
• DNS: The TACACS+ AS server has a DNS host name.		
Active Server Address		
Depending on the selection from the Active Server Address Type drop-down list, enter		
the IP address or the DNS host name of the TACACS+ AS. The IP address or the	None	
DNS host name needs to be already listed in the TACACS+ Server Configuration		
table.		
Retransmit		
The number of times the switch searches for the AS in the TACACS+ Server		
Configuration table if the switch can not establish a connection with the AS at the first		
attempt. Enter a number in the range of 1 to 100.		

3.11.2.6 Login Authentication

The Delta switch provides three authentication methods: Local, RADIUS, and TACACS+. If there is no RADIUS or TACACS+ server in your network environment, you can use the local authentication method for the login authentication.

Login Authentication

Authentication Configuration	
Login Authentication Mode	Local 🗸
Ca	ncel Apply

Login Authentication

Description	Factory default
Login Authentication Mode	
Specify the login authentication method:	
Local: A locally stored user ID and a password are used for the	
authentication. This is the default setting. You need to set up a user account	
on the Local User Management page.	Local
RADIUS: The user ID and the password are authenticated through a	LUCAI
RADIUS server.	
 TACACS+: The user ID and the password are authenticated through a 	
TACACS+ server.	

3.11.2.7 Login User Sessions

The login user session is displayed on this page. The Delta switch supports up to 20 users, including the default user admin.

Login User Sessions

Login User Sessions					
ID	Туре	User	Peer-Address		
w1	http	admin	192.168.1.202		

Refresh

Login User Sessions

ltem	Description		
ID	The unique session identifier		
Туре	The session types: console telnet ssh http		

User	The name of the user who log in.
Peer-Address	The IP address to which the user log in.

3.11.3 Denial of Service

The Delta switch provides six types of denial of service (DoS) attacks for you to block and monitor attacks. Please refer to the following table for description.

Denial of Service Configuration

Denial of Service Configuration	
Denial of Service SIP=DIP	Disable Disable
Denial of Service First Fragment	Disable Disable
Denial of Service Min TCP Hdr Size	20 (0 to 255)
Denial of Service TCP Fragment	Disable Disable
Denial of Service TCP Flag	Disable Disable
Denial of Service L4 Port	Disable Disable
Denial of Service ICMP	Disable Disable
Denial of Service Max ICMP Size	512 (0 to 1023)

Apply Cancel

Denial of Service Configuration

Description	Factory default
Denial of Service SIP=DIP	
Select one of the following radio buttons:	
Disable: This is the default setting.	Dicabla
Enable: Packets that have a source IP (SIP) address equal to the	Disable
destination IP (DIP) address are dropped.	
Denial of Service TCP Flag	
Select one of the following radio buttons:	
Disable: This is the default setting.	
Enable: All of the following packets are dropped:	Disable
- Packets that have a TCP flag SYN set and a TCP source port with a number	
lower than 1024	
- Packets that have TCP control flags set to 0 and the TCP sequence number set	
to 0	
- Packets that have TCP flags FIN, URG, and PSH set and TCP sequence number	
set to 0	
 Packets that have both the TCP flags SYN and FIN set 	
Denial of Service L4 Port	
Select one of the following radio buttons:	
Disable: This is the default setting.	
 Enable: Packets that have a TCP source port that is equal to the TCP 	Disable
destination port are dropped, and packets that have a UDP source port that	
is equal to the UDP destination port are dropped.	

3.12 Monitoring Settings

You can monitor the status of the Delta switch in real time via the functions in this group.

IMPORTANT:

Make sure that you save the configuration in the Save Configuration page after you have applied the configuration changes. (Save Config \rightarrow Save Configuration) If you do not save the configuration, then the configuration will be cleared after the switch is rebooted.

3.12.1 MAC Address Table

The MAC address table displays the MAC address which is learned and manually added. There is a search function which can be used to display the information about the entry in the table.

MAC Address Table

Address Aging Tim	e			
Address Aging Timeou	ut (seconds)	300 *	Sec. (10-10000	00)
	Ca	ncel Apply		
MAC Address Table	:			
Search By			·	GO
Total MAC Addresses		1		
Auto-refresh				
VLAN ID	MAC Address		Port	status
1	98:e7:f4:4f:8f:db		0/1	Learned

Clear Refresh

Address Aging Time

Description	Factory default
Address Aging Timeout (seconds)	
Enter the period in seconds. If a learned MAC address has not been updated during	
the address aging time, then it will be removed from the address table automatically.	300
Enter a period in the range of 10 to 1000000 seconds.	

MAC Address Table

Item	Description				
Auto-refresh	Checkmark the box,the MAC address Table will?? , 幾秒會更新一次??				
VLAN ID	The VLAN ID that is associated with the MAC address.				
MAC Address	The dynamically learned or manually added MAC address for which the switch				
	has forwarded or filtered information, or both.				
Port	This field displays the interface which was learned or added manually. It also				
T OIL	means the interface through which the MAC address can be reached.				
	The status of this entry:				
	Invalid: The MAC address is invalid. Normally, invalid MAC				
	addresses are deleted, so this is an error condition.				
Status	 Self: The MAC address is the address of a physical interface of the switch. 				
	 Learned: The MAC address was learned through incoming traffic and is being used. 				
	Static: The MAC address was manually added and can not be relearned.				
	Other: The MAC address does not fall into one of the other				

Item	Description
	categories.

3.12.2 SFP DDM (Only for SFP Module)

You can monitor the status of each SFP (small form-factor pluggable) port on this page.

SFP Status

Port Status							
Port	Ethernet Compliance Code	SFP Vendor	Wave Length	Distance			
0/7	unknown	unknown	unknown	unknown			
0/8	unknown	unknown	unknown	unknown			

ED	DDM	
	DUP	

- 31	F DDF	•										
		Temperature		Voltage		Bias		Tx Power		Rx Power		
	Port	Status	Current	Range	Current	Range	Current	Range	Current	Range	Current	Range
	0/7	Not Present	unknown	unknown	unknown	unknown	unknown	unknown	unknown	unknown	unknown	unknowr
	0/8	Not Present	unknown	unknown	unknown	unknown	unknown	unknown	unknown	unknown	unknown	unknowr
						Refresh	Ejeci					



Note:

Before you use the SFP DDM function, please make sure the SFP module you used are support SFP DDM function.

DDM function and SFP modules tramsissiom are fully compatible with Delta managed switches ONLY. If users are intending to use SFP modules of 3rd-party vendors, please do a proper evaluation of installation firstly.

3.12.3 System CPU Status

You can monitor the CPU status of the Delta switch on this page.

System CPU Status

CPU Memory Status	
Total System Memory	63428 KBytes
Available Memory	10984 KBytes

CPU Utilization					
Memory	Utilization Report				
status	bytes				
f	11047616				
alloc	53702656				
ailuc	JJ7020J0				
CPU Uti	lization:				
PID	Name	5 Sec	1 Min	5 Min	
	• • .		·····		
1	init	U.U %	U.U %	U.U %	
2	kthreadd	U.U %	U.U %	U.U %	
3	ksoft1rqd/U	0.0 %	0.0%	0.0 %	
4	watchdog/O	0.0 %	0.0 %	0.0 %	
5	events/0	0.0 %	0.0 %	0.0 %	
6	khelper	0.0 %	0.0 %	0.0 %	
16	kblockd/O	0.0 %	0.0 %	0.0 %	
32	pdflush	0.0 %	0.0 %	0.0 %	
33	pdflush	0.0 %	0.0 %	0.0 %	

Refresh

3.12.4 Interface Statistics

You can monitor the statistics of each interface of the Delta switch on this page. The data will be refreshed every second. Interface Statistics



Note:

Make sure that the port you want to monitor is connected to another device.

3.12.5 ARP Configure

ARP protocol is a process to mapping a MAC address to an IP address, and there are two types of ARP entries-static and dynamic. It will store these mapping entries to a database which called ARP cache. The Delta managed switches provide dynamic and manual ARP configuration

3.12.5.1 Basic

The ARP table includes dynamic ARP entries and static ARP entries.

ARP Table

ARP Table		
IP Address	Port	MAC Address
192.168.1.13	0/1	98:e7:f4:4f:8f:db

Refresh

ARP Table

Item	Description				
IP Address	The VLAN ID that is associated with the MAC address				
Dort	This field displays the interface which was learned or added manually. It also				
FUIL	means the interface through which the MAC address can be reached.				
	The status of this entry:				
	Invalid: The MAC address is invalid. Normally, invalid MAC				
	addresses are deleted, so this is an error condition.				
	 Self: The MAC address is the address of a physical interface of the switch. 				
MAC Address	 Learned: The MAC address was learned through incoming traffic and is being used. 				
	 Static: The MAC address was manually added and can not be relearned. 				
	Other: The MAC address does not fall into one of the other				
	categories.				

3.12.6 RMON

Remote network monitoring (RMON) mainly provides the statistics and the alarm functions for the remote monitoring and the management of the network management devices on the managed device. It is the functionality expansion for the simple network management protocol (SNMP), particularly useful for monitoring and managing a network. RMON specifically defines that any network monitoring system must be able to provide information (defined in RFC2819) about the MIB which is the base of seamless multi-vendor interoperability between the SNMP management station and the monitoring agent.

3.12.6.1 Basic Settings

The default setting of RMON is disabled. If RMON Status is disabled, the functions in RMON group will not work. **RMON Basic Settings**

Basic Settings		
RMON Status	◯ Enabled	
	Cancel Apply	

3.12.6.2 Alarms

RMON Alarm Configuration allows you to specify the threshold and generate the alarm. When the alarm occurs, an event can be generated. Before you configure alarms, you need to specify logs and the SNMP traps that can be generated when an alarm occurs by configuring entries on the **RMON Event Configuration** page.

RMON Alarm Configuration

R	10N Ala	rm Configuration				
	Index	Interval	Interface	Variable	Sample Type	Rising Threshold
	*	*	*	¥ *	- 🗸	*
	1	50	0/1	etherStatsBroadcastPkts	Absolute Value	30
	2	100	0/1	etherStatsOversizePkts	Absolute Value	20

Note :1.Before setting the threshold values, corresponding ethernet index and events has to be created. 2.Falling Threshold value has to be lesser than Rising Threshold value.

Add Cancel Delete

Falling Threshold	Rising Event Index	Falling Event Index	Owner
*	*	*	
20	1	1	Delta
15	2	2	Delta

RMON Alarm Configuration

Description	Factory default
Index	
Enter an index that uniquely identifies the entry in the RMON Alarm Configuration	None

Description	Factory default
table. Enter a number between 1 and 65535.	
Interval	
Specify the period in seconds over which the data is sampled and compared with the	None
rising and falling thresholds. Enter a number between 1 and 65535 seconds.	none
Interface	
Specify the interface number.	None
Variable	
Specify the SNMP event that you want to sample.	None
Sample Type	
Specify the sample type for the alarm, which defines how the variable is sampled, and	
how the value is calculated and compared with the thresholds that you configure.	
Make a selection from the drop-down list:	
Absolute Value: The value of the variable is compared directly with the	None
thresholds at the end of the sampling interval.	None
• Delta Value: The value of the variable that was obtained at the last sample	
is subtracted from the current value, and the difference is compared with	
the thresholds.	
Rising Threshold	
Specify the rising threshold for the sampled statistic. If the configured threshold value	
is reached, an alarm is raised. If the current sampled value is greater than or equal to	
this threshold, and the value at the last sampling interval was less than this threshold,	
a single event is generated. Enter a value between 0 and 2147483647.	None
Note:	
The rising threshold value needs to be greater than the falling threshold	
value.	
Falling Threshold	
Specify the falling threshold for the sampled statistic. If the configured threshold value	
is reached, an alarm is raised. If the current sampled value is less than or equal to this	
threshold, and the value at the last sampling interval was greater than this threshold, a	
single event is generated. Enter a value between 0 and 2147483647.	None
Note:	
The falling threshold value needs to be less than the rising threshold	
value.	
Rising Event Index	
Specify the index of the event that needs to be raised when a rising threshold is	
crossed. T he value is between 1 and 65535.	
Note:	None
The drop-down list is associated with the RMON Event	None
Configuration table. If there is no corresponding entry in the	
RMON Event Configuration table, no association can exist.	
Falling Event Index	
Specify the index of the event that needs to be raised when a falling threshold is	
crossed.	
Note:	None
The drop-down list is associated with the RMON Event	Nono
Configuration table. If there is no corresponding entry in the	
RMON Event Configuration table, no association can exist.	
Owner	
Specify the owner of the entry by entering a name.	None

3.12.6.3 Events

You can specify events that create log entries, the SNMP traps, or both. And assign these configurations to the alarms on the **RMON Alarm Configuration** page.

RMON Event Configuration

R	MON Eve	nt Configuration				
	Index	Description	Туре	Community	Owner	Last Time Sent
	*		- v	~		
	1	Broadcast	Log and Trap	SNMPTrap	Delta	0 day 0 hr 55 min 30 sec
	2	Packets	Log		David	0 day 0 hr 56 min 20 sec

Add Cancel Delete

RMON Event Configuration

Description	Factory default	
Index		
Enter an index that uniquely identifies the entry in the RMON Alarm Configuration table.	Nono	
Enter a number between 1 and 65535.	none	
Description		
Enter a brief description of the event. You can enter up to 127 characters.	None	
Туре		
Specify the type for this event:		
• None: No entry is made in the RMON Event Log table and no trap is sent.		
The community field is disabled.		
Log: An entry is made in the RMON Event Log table. The community field is	Nono	
disabled.	NONE	
• SNMP Trap: An SNMP trap is sent to one or more management stations.		
Log and Trap: An entry is made in the RMON Event Log table and an SNMP		
trap is sent to one or more management stations.		
Community		
If the Type setting is SNMP Trap or Log and Trap, enter an existing community name.	None	
Owner		
Specify the owner of the entry by entering a name. None		
Last Time Sent		
Specify the last time the entry created an event. None		

3.12.6.4 Event Log

The events that have been triggered are displayed on this page.

RMON Event Log

RMON Event Log				
Event	Log No.	Log Time	Description	
		Refresh		

RMON Event Log

Item	Description	
Event	The index that corresponds to the index value of the entry in the RMON Event	
Event	Configuration table	
Log No.	The entry in the RMON Event Log table	
Log Time	The time when the entry was created	
Description	The description that corresponds to the description of the index value of the	
Description	entry in the RMON Event Configuration table	

3.12.6.5 History

You can specify the polling period, the buckets (the number of samplings or how many times the polling occurs) and the source interface for the historical statistical data sampling for the individual interfaces on this page.

History Control Configuration

Hi	History Control Configuration					
	Index	Data Source	Buckets Requested	Interval	Owner	
	*	*				
	1	0/1	50	1800	Delta	

Add Cancel Delete

History Control Configuration

Description	Factory default
Index	
Enter an index that uniquely identifies the entry in the History Control Configuration	Nono
table. Enter a number between 1 and 65535.	None
Data Source	
Specify a source interface.	None
Buckets Requested	
Specify the number of buckets for collecting the RMON statistics. Enter the requested	
number of discrete time intervals over which data is to be collected and saved. Enter a	50
number between 1 and 50.	
Interval	
Specify the period in seconds between two successive pollings to collect the statistics.	1000
Enter a number between 1 to 3600 seconds.	1000
Owner	
Specify the owner of the entry by entering a name.	None

3.12.6.6 RMON Ethernet Statistics

The cumulative RMON Ethernet statistics information is displayed on this page.



Note:

The counters on the **RMON Ethernet Statistics** page provide cumulative statistical information from multiple pollings.

The counters on the RMON Ethernet History Statistics page provide statistical information from individual pollings.

Ethernet Statistics

Ethernet Statistics		
Interface	0/7 💌	

Ethernet Statistics	
Drop Events	0
Packets	58856
Broadcast Packets	3177
Multicast Packets	746
CRC Errors	0
Under Size Packets	0
Over Size Packtes	0
Fragments	8
Jabbers	0
Collisions	68
Packets 64 Octets	20863
Packets 65-127 Octets	11775
Packets 128-255 Octets	4237
Packets 256-511 Octets	5506
Packets 512-1023 Octets	3061
Packets 1024-1518 Octets	13414

Refresh

Ethernet Statistics

ltem	Description
Interface	Specify one interface for Ethernet Statistics.
	The cumulative number of events in which packets were dropped on the
Dron Events	interface because of lack of resources. This number does not specify the
	number of packets that were dropped but the number of times the packets were
	dropped.
Packets	The cumulative number of packets received on the interface.
Broadcast Packets	The cumulative number of broadcast packets received on the interface.
Multicast Packets	The cumulative number of multicast packets received on the interface.
	The cumulative number of packets which are received on the interface, have a
	length (excluding the framing bits, but including the FCS octets) between 64 and
CRC Errors	1518 octets, and have either a bad frame check sequence (FCS) with an
	integral number of octets (FCS error) or a bad FCS with a nonintegral number of
	octets (alignment error).
	The cumulative number of packets which are received on the interface, less
Under Size Packets	than 64 octets in length (excluding the framing bits, but including the FCS
	octets), and well formed.
	The cumulative number of packets which are received on the interface, more
Over Size Packets	than 1518 octets in length (excluding the framing bits, but including the FCS
	octets), and well formed.
	The cumulative number of packets which are received on the interface, are less
	than 64 octets in length (excluding the framing bits, but including the FCS
Fragments	octets), and have either a bad frame check sequence (FCS) with an integral
	number of octets (FCS error) or a bad FCS with a nonintegral number of octets
	(alignment error).
	The cumulative number of packets which are received on the interface, are
Jabbers	longer than 1518 octets in length (excluding the framing bits, but including the
	FCS octets), and have either a bad frame check sequence (FCS) with an
	integral number of octets (FCS error) or a bad FCS with a non integral number

ltem	Description
	of octets (alignment error).
Collisions	The best estimate of the cumulative number of collisions on the interface
	The cumulative number of packets (including bad packets) which are received
Packets 64 Octets	on the interface, and 64 octets in length (excluding the framing bits, but
	including the FCS octets).
	The cumulative number of packets (including bad packets) which are received
Packets 65-127 Octets	on the interface, and between 65 and 127 octets in length (excluding the
	framing bits, but including the FCS octets).
	The cumulative number of packets (including bad packets) which are received
Packets 128-255 Octets	on the interface, and between 128 and 255 octets in length (excluding the
	framing bits, but including the FCS octets).
	The cumulative number of packets (including bad packets) which are received
Packets 256-511 Octets	on the interface, and between 256 and 511 octets in length (excluding the
	framing bits, but including the FCS octets).
Packets 512-1023	The cumulative number of packets (including bad packets) which are received
Octets	on the interface, and between 512 and 1023 octets in length (excluding the
001013	framing bits, but including the FCS octets).
Packets 1024-1518	The cumulative number of packets (including bad packets) which are received
Octets	on the interface, and between 1024 and 1518 octets in length (excluding the
	framing bits, but including the FCS octets).

3.12.6.7 Ethernet History Statistics

The historical data for the interface is collected, and the statistics information for the interface is displayed on **RMON Ethernet History Statistics** page.



Note:

The counters on the RMON Ethernet Statistics page provide cumulative statistical information from multiple pollings.

The counters on the **RMON Ethernet History Statistics** page provide statistical information from individual pollings.

RMON Ethernet History Statistics

Ether	Ethernet History Statistics								
Index	Sample Index	Interval Start	Drop Events	Octets	Packets	Broadcast Packets	Multicast Packets		
1	0	Jan 1 00:00:00 1970	0	0	0	0	0		
2	1	Jan 1 01:27:48 1970	0	8204300	17753	835	221		
2	2	Jan 1 01:28:48 1970	0	4161973	11636	861	220		
2	3	Jan 1 01:29:49 1970	0	7998440	14127	767	145		

Refresh

CRC Errors	Under Size Packets	Over Size Packtes	Fragments	Jabbers	Collisions	Utilization
0	0	0	0	0	0	0
0	0	0	7	0	23	11
0	0	0	1	0	1	5
0	0	0	0	0	34	11

RMON Ethernet History Statistics

ltem	Description
Index	The index that uniquely identifies the entry in the History Control Configuration

ltem	Description			
	table.			
	An index that uniquely identifies the particular polling sample that this entry			
Sample Index	Listery Control Configuration table. This index starts at 1 and increases by and			
	History Control Conliguration table. This index starts at 1 and increases by one			
later vel Otert	as each new poiling sample is taken.			
Interval Start	The time when the polling (sampling) interval started.			
	I ne number of events during the sampling interval in which packets were			
Drop Events	dropped on the interface because of the lack of resources. This number does not			
	specify the number of packets that were dropped but the number of times the			
	packets were dropped.			
	The number of data octets (including those in bad packets) received on the			
Octets	interface (excluding the framing bits, but including the FCS octets) during the			
	sampling interval.			
Packets	The number of packets received on the interface (including the bad packets, the			
	broadcast packets, and the multicast packets) during the sampling interval.			
Broadcast Packets	The number of broadcast packets received on the interface during the sampling			
	interval. These packets were directed to the broadcast addresses.			
	The number of multicast packets received on the interface during the sampling			
Multicast Packets	interval. These packets were directed to the multicast addresses. (This number			
	does not include the packets addressed to a broadcast addresses.)			
	The number of packets which are received on the interface during the sampling			
	interval, have a length (excluding the framing bits, but including the FCS octets)			
CRC Errors	between 64 and 1518 octets, and have either a bad frame check sequence			
	(FCS) with an integral number of octets (FCS error) or a bad FCS with a non			
	integral number of octets (alignment error).			
	The number of packets which are received on the interface during the sampling			
Under Size Packets	interval, less than 64 octets in length (excluding the framing bits, but including			
	the FCS octets), and were well formed.			
	The number of packets which are received on the interface during the sampling			
Over Size Packets	interval, more than 1518 octets in length (excluding the framing bits, but			
	including the FCS octets) and that were well formed.			
	The number of packets which are received on the interface during the sampling			
	interval, are less than 64 octets in length (excluding the framing bits, but			
Fragments	including the FCS octets), and have either a bad frame check sequence (FCS)			
	with an integral number of octets (FCS error) or a bad FCS with a non integral			
	number of octets (alignment error).			
	The number of packets which are received on the interface during the sampling			
	interval, are longer than 1518 octets in length (excluding the framing bits, but			
Jabbers	including the FCS octets), and have either a bad frame check sequence (FCS)			
	with an integral number of octets (FCS error) or a bad FCS with a non integral			
	number of octets (alignment error).			
Collisions	The best estimate of the number of collisions on the interface during the			
	sampling interval.			
	The best estimate of the mean physical layer network utilization on the interface			
	during the sampling interval, in hundredths of a percent.			

3.12.7 SYSLOG

The SYSLOG function allows you to monitor the switch. When faults, errors, configuration changes or specified events happen, this function can generate messages, store the messages locally or forward the messages to one syslog server or more syslog servers. You can choose the severity level to filter the message according to your requirement.

3.12.7.1 Show Logs

The numbers of messages which can be shown on this page depend on the setting of the severity on the Logs Configuration page. The logs are cleared after the switch is rebooted. To save the logs after the switch is rebooted, you have to send them to a syslog server or use the email function.

Mes	Message Log					
Index	Severity	Date	Time	Model Name	Logs	
1	<134>	1970-01-01	04:37:05	DVS-108W02-2SFP	MSR configuration changed	
2	<134>	1970-01-01	04:37:06	DVS-108W02-2SFP	CLI User admin logged out	
3	<134>	1970-01-01	04:37:11	DVS-108W02-2SFP	CLI User admin logged in	

Refresh Clear

The log message format is described below:

Show System Logs

<134>1970-01-01 03:26:33 DVS-108W02-2SFP MSR configuration changed

Log message component	Description		
	The number contained in the angle brackets represents the message		
	priority, which is derived from the following values:		
-124-	Priority = facility value + severity level.		
<134>	In the example, the facility value is local0 (128). The severity value is		
	notification (5). For more information about the severity of a log		
	message, please see Logs Configuration.		
1970-01-01 03:26:33	The message was generated on 1970-01-01 00:02:50		
DVS-108W02-2SFP	The device name		
MSR	The module that generated the message		
configuration abanged	The major description of the message: The configuration has been		
configuration changed	changed.		

3.12.7.2 Logs Configuration

You can enable, disable and configure other system log settings on this page.

System Logs Configuration

System Logs Configuration	
Logging on	Enable 💌
Service timestamps	Enable 💌
Logging console	Enable 💌
Logging mail	Disable 💌
Logging auto-save-logs	Enable 💌
Logging buffered	50
Logging time-range(mins)	60
Logging manual-save-logs	ManualSave
Severity	critical 💌
Logging filesize	10240

Cancel

Apply

System Logs Configuration

Description	Factory default				
Logging on					
Specify whether the logging is enabled or disabled:					
Enable: The logging is enabled.					
Disable: The logging is disabled. Log messages are not displayed	Enable				
on the Show System Logs page and can not be saved in a log file or					
a syslog server, and the logging over the console port is disabled.					
Service timestamps					
Specify whether or not a time stamp is added to log messages:					
Enable: A time stamp is added.	Enable				
Disable: A time stamp is not added.					
Logging console					
Specify whether the logging over the console port is enabled or disabled:					
• Enable : The logging over the console port is enabled.	Enable				
Disable: The logging over the console port is disabled.					
Logging mail					
Specify whether log messages can be sent to a specified email address:					
Enable: The sending of log messages to a specified email is	5				
enabled.	Disable				
Disable: The sending of log messages to a specified email is					
Logging auto-save-logs					
 Specify whether log messages can be saved in a flash memory systematically 					
automatically:					
Enable: Log messages can be saved in a flash memory	Frable				
automatically. The saving time depends on the Logging time-range	Enable				
Disable: Log messages can not be saved in a flash memory					
automatically					
Logging buffered					
Specify the number of log messages that can be displayed on the Show					
System Logs page. Enter a number in the range of 1 to 200. The default setting	50				
is 50 log messages.					
Logging time-range (min)					
Specify the time-range to save the log automatically. It only works when the					
Logging auto-save-logs function is enabled. Enter a value in the range of 60 to	60				
43200. The default value is 60.					
Logging manual-save-logs					
Click the button to save logs in a flash memory manually.	None				
Severity					
Specify the level of the severity that determines which events are logged. A log					
records the messages equal to or above a configured severity threshold. For					
example, if you select an error, the logged messages include error (3), critical					
(2), alert (1), and emergency (0). The default level of the severity is critical (2).					
Make a selection from the drop-down list:					
• emergency: The highest warning level (level 0). An emergency					
message is saved if the switch is down or not functioning correctly.	aritical				
• alert: The second-highest warning level (level 1). An alert message	Chiicai				
is saved if there is a serious switch malfunction, for example, an					
important switch function goes down. Action needs to be taken					
immediately.					
• critical: The third-highest warning level (level 2). A critical message					
is saved if a critical switch malfunction occurs, for example, two					
interfaces stop functioning while the rest of the interfaces remain					

Description	Factory default
functional.	
• error: The level that indicates that a device error has occurred (level	
3), such as an interface going offline	
• warning: The lowest level of a device warning (level 4).	
• notice: Normal but significant conditions (level 5). Provides the	
network administrators with the switch information.	
• Informational: Provides the switch information (level 6).	
• debug: Provides the detailed information about the switch (level 7).	
This level generates a lot of messages.	
Logging filesize	
Specify the size of the system file in which the log files are saved. Enter a file	
size between 1024 and 102400 bytes.	
Note:	
The debug log file is not controlled by the size of the system file.	10010
The debug log file is a temporary file that is not stored in the flash	10240
memory. The file can always store the most recent 100 debug log	
messages, and each debug log message is less than 80 bytes in	
length.	

3.12.7.3 Syslog Fwd Table

You can add the syslog server IP address and configure the forward log severity on this page.

Syslog Fwd Table

Fo	Forward Files Table						
	Fwd Severity	Fwd Address Type	Server IP Address	Fwd Port	Fwd TransType		
	- •	- •			- •		
	informational	IPv4	192.168.1.5	2	SYSLOG_TCP		



Syslog Fwd Table

Description	Factory default			
Fwd Severity				
From the drop-down list, select a level of the severity that determines which events are				
sent to the syslog server. The log records the messages equal to the configured	Nono			
severity threshold. For example, if you select an error, the logged messages include	NONE			
error (3) messages only.				
Fwd Address Type				
Specify a type of server address and enter the address or the host name in the Server				
IP Address field:				
 IPv4: The syslog server has an IPv4 address. 	None			
 IPv6: The syslog server has an IPv6 address. 				
DNS: The syslog server has a DNS host name.				
Server IP Address				
Enter the IP address or the host name of the syslog server.				
Note:	Nono			
For an IPv6 address, enter the address in the	None			
xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx format.				
Fwd Port				
Enter the port number to which syslog messages are sent on the syslog server. Enter a	E1 /			
number between 0 and 65535. Enter 0 to prevent the syslog messages from being	514			
Description	Factory default			
--	-----------------	--	--	--
sent.				
Fwd TransType				
Specify whether log messages are sent as UDP or TCP messages:				
 SYSLOG_UDP: Log messages are sent as UDP messages. 	None			
SYSLOG_TCP: Log messages are sent as TCP messages.				

3.12.7.4 Syslog Email Configuration

Email Server Configuration allows you to monitor the switch when you can not stay in front of the computer. For example, when the alarm event happens, you can use a smart phone to get an alarm event email anywhere. And then you can contact a related maintainer or engineer to check the device and solve the problem.

Email Server Configur	ation			
Email Server Settings				
Mail Server IP/Name: the Esmtp Authentication	on Choice			
Account Name:				
Change Account Passwo	rd			
Old Password:				
New Password:				
Retype Password:				
1st Email Address:				
2nd Email Address:				
3rd Email Address:				
4th Email Address:				
3rd Email Address: 4th Email Address:	Activate	Send Test E-ma	ail	

Email Server Configuration

Description	Factory default
Mail Server IP / Name	
Enter the IP address of the mail server.	None
The Esmtp Authentication Choice	
Specify whether the mail server needs the authentication. If the box is selected,	None
please enter the account name of the email.	None
Change Account Password	
Specify whether you want to change the account password.	
If the box is selected, please enter the old password and enter the new	None
password twice in New Password and Retype Password.	
Email Address	
Specify the email address for the email alarm. You can specify 1 to 4 email	None
addresses.	none

3.12.7.5 Syslog Email Alarm Table

The Email Alarm Events Settings page allows you to get an email message when the event you configured happened.

Sys	System Events								
~	Switch Cold Start	\checkmark	Switch Warm Start	\checkmark	Power Transition(Off->On)	\checkmark	Power Transition(On->Off)		
 Image: A start of the start of	DI-ON	\checkmark	DI-OFF	\checkmark	Authentication Failure	\checkmark	Dot1d Bridge New Root		
	Dot1d Bridge Topology Changed	\checkmark	LLDP Remote Tables Change	• 🗸	Configuration Changed	\checkmark	Firmware Update		
	IP Changed	\checkmark	Password Changed	\checkmark	Redundancy				

Email Alarm Events Settings

PC	Port Events										
			DDM Failure								
Port	Link-ON	Link-OFF	Temp Alarm	Voltage	Bias	TX Power	RX Power	Overload	Threshold(%)	Duration(s)	Loopback-Detection
0/1	\checkmark	✓							1	1	
0/2	\checkmark	\checkmark							1	1	
0/3	\checkmark	\checkmark							1	1	\checkmark
0/4	\checkmark	✓							1	1	
0/5	\checkmark	\checkmark							1	1	\checkmark
0/6	✓	\checkmark							1	1	
0/7	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark		1	1	\checkmark
0/8	\checkmark		\checkmark		✓	✓	✓		1	1	

Cancel Apply

System Events

Description	Factory default
Switch Cold Start	
Specify whether to send an alarm email when switch cold starts.	Checked
Switch Warm Start	
Specify whether to send an alarm email when switch warm starts.	Checked
Power Transition (Off->On)	
Specify whether to send an alarm email when there is a transition in power from Off to On.	Checked
Power Transition (On->Off)	
Specify whether to send an alarm email when there is a transition in power from On to Off.	Checked
DI-ON	
Specify whether to send an alarm email when DI is On.	Checked
DI-OFF	
Specify whether to send an alarm email when DI is Off.	Checked
Authentication Failure	
Specify whether to send an alarm email when there is authentication failure.	Checked
Dot1d Bridge New Root	
Specify whether to send an alarm email when a new node is added to the 802.1d network.	Checked
Dot1d Bridge Topology Changed	
Specify whether to send an alarm email when the 802.1d bridge topology is changed.	Checked
LLDP Remote Tables Change	
Specify whether to send an alarm email when the LLDP remote table is changed.	Checked
Configuration-Changed	
Specify whether to send an alarm email when the configuration is changed.	Checked
Firmware Update	
Specify whether to send an alarm email when the firmware has been updated.	Checked
IP Changed	
Specify whether to send alarm email when the IP address has changed.	Checked

Description	Factory default
Password Changed	
Specify whether to send alarm email when the password has changed.	Checked
Redundancy	
Specify whether to send alarm email when the redundancy has changed.	Checked
Port Events	
Description	Factory default
Port	
This field displays the interface number.	interface number
Link-ON	
Specify whether to send an alarm email when the Link is ON.	Checked
Link-OFF	
Specify whether to send an alarm email when the Link is OFF.	Checked
DDM Failure	
Specify whether to send an alarm email when the DDM failure event is detected.	Checked
Overload	
Specify whether to send an alarm email when the traffic of the port is overloaded.	Upphookod
If the box is selected, you can configure the Threshold (%) and Duration (s) fields.	Unchecked
Loopback-Detection	
Specify whether to send an alarm email when the Loopback-Detection event is detected.	Checked

3.13 Diagnostic Settings

The Delta switch provides LLDP function, Port mirror function, and Cable Diagnostics function so that administrator can use these functions to diagnose network or settings.

IMPORTANT:

Make sure that you save the configuration in the Save Configuration page after you have applied the configuration changes. (Save Config \rightarrow Save Configuration) If you do not save the configuration, then the configuration will be cleared after the switch is rebooted.

3.13.1 LLDP

LLDP (Link Layer Discover Protocol) provides a method for switches, routers and access points to advertise their identification, configuration and capabilities to the neighboring devices that store the data in a MIB, and to learn information about the neighboring devices.

LLDP-MED (Link Layer Discovery Protocol for Media Endpoint Devices) is an extension of LLDP in that it operates between endpoint devices such as IP phones or switches.

LLDP-Media Endpoint Discovery (LLDP-MED) is an enhancement of LLDP with the following features:

- Auto Discovery: Autodiscovery of LAN policies (such as VLAN, Layer 2 priority, and DiffServ settings) and capability to enable a plug and play networking
- **Device Location:** Device location discovery for the creation of location databases
- Power Management: Extended and automated power management of Power over Ethernet (PoE) endpoints
- Inventory Management: Inventory management, which lets network administrators track network devices and determine their characteristics such as the manufacturer, the software and hardware versions, and the serial and asset numbers

3.13.1.1 LLDP Basic Settings

The default of the LLDP status is enabling. If you want to configure other settings, please refer to the following table.

LLDP Basic Settings

LLDP Basic Settings	
LLDP Status	Enable -
Transmit Interval (8 to 32768)	30
Holdtime Multiplier	4
Reinitialization Delay	2
TX Delay	2
Notification Interval	5

Cancel Apply

LLDP Basic Settings

Description	Factory default			
LLDP Status				
Specify the status of LLDP on the switch:				
• Enable: LLDP is enabled. You can configure LLDP, and the settings take				
effect after you have applied them.	Enable			
• Disable: LLDP is disabled. You can still configure LLDP, but the settings do				
not take effect after you have applied them.				
Transmit Interval (8 to 32768)				
Enter the interval in seconds to transmit the LLDP frames. Enter a number in the	20			
range of 8 to 32768 seconds.	30			
Holdtime Multiplier				
Enter the hold time multiplier in seconds. The hold time multiplier multiplies the				
transmit interval to define the Time to Live (TTL) period. Enter a number in the range	4			
of 2 to 10 seconds.				
Reinitialization Delay				
Enter the delay in seconds before reinitialization. Enter a number in the range of 1 to	0			
10 seconds. A longer time prevents frequent reinitializations.	2			
TX Delay	2			
It is used to delay the tx_relay time and the value is fixed at 2 seconds.				
Notification Interval				
Enter the interval in seconds for the transmission of notifications. Enter a number in	F			
the range of 5 to 3600 seconds.	5			

3.13.1.2 LLDP Interface Configuration

You can configure the LLDP settings for an individual interface on this page.

Int	Interface Settings								
	Port	Link Status	Admin Status	Notification Status					
			- 🗸	- 🗸					
	0/1	Down	TX and RX	Disabled					
	0/2	Down	TX and RX	Disabled					
	0/3	Up	TX and RX	Disabled					
	0/4	Down	TX and RX	Disabled					
	0/5	Down	TX and RX	Disabled					
	0/6	Down	TX and RX	Disabled					
	0/7	Up	TX and RX	Disabled					
	0/8	Up	TX and RX	Disabled					

Interface Settings

Cancel Apply

Interface Settings

Description	Factory default
Port	
This field displays the interface number.	interface number
Link Status	
This field displays the status of the interface link.	Up or Down
Admin Status	
Specify the status and the direction of the interface:	
TX: The interface processes outgoing traffic only.	
RX: The interface processes incoming traffic only.	TX and RX
• TX and RX: The interface processes both incoming and outgoing traffic.	
Disabled: The interface is disabled.	
Notification Status	
Specify the notification status:	
Enabled: Notifications are sent.	Disabled
Disabled: Notifications are not sent.	

LLDP TLV Options 3.13.1.3

You can configure the LLDP type-length value (TLV) settings for each interface on this page. **LLDP TLV Options**

LL	LLDP TLV Options									
	Port	Port Description	System Name	System Description	System Capability	MAC PHY Config	Management Address			
		- 🗸	- 🗸	- 🗸	- 🗸	- 🗸	- 🗸			
	0/1	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled			
	0/2	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled			
	0/3	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled			
	0/4	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled			
	0/5	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled			
	0/6	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled			
	0/7	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled			
	0/8	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled			
	Cancel Apply									

LLDP TLV Option

Item	Description				
Port	Specify the interface number.				
Port Description					
System Name					
System Description	Specify whether to send the options in the LLDP trames.				
System Capability	Enable: The information is transmitted Disable: The information is not transmitted				
MAC PHY Config					
Management Address					

3.13.1.4 LLDP Local Information

You can view the LLDP local information about an individual interface on this page.

LLDP Local Information

LLDP Local Information	
Interface	0/1 🗸

LLDP Local Information					
Chassis ID Subtype	MAC Address				
Chassis ID	00:18:23:01:20:61				
System Name					
System Description	DVS108W02 - 8 Port with 2 SFP.				
System Capability Supported	Bridge ;				
System Capability Enabled	Bridge ;				
Port ID Subtype	Interface Alias				
Port ID	Slot0/1				
Port Description	Slot 0: Port 1: Fastethernet-Level				
Enabled Tx TLVs	Port Description, System Name, System Description, System Capability, Management Address, Mac Phy				
Management Addresses					
SubType	IPv4				
Address	192.168.1.142				
Extended 802.3 TLV Info					
MAC PHY Configuration & Status					
Auto-Neg Support & Status Not Supported ,Disabled					
Advertised Capability Bits	0000				
Operational MAU Type	0				

Refresh

LLDP Local Information

Item Description			
Chassis ID Subtype	This field displays the MAC Address to be identified for the LLDP		
Chassis ID Subtype	communication.		
Chassis ID	This field displays the MAC address to identify the switch.		
System Name	The system name that you specified on the System Information page		

Item	Description			
System Description	This is a fixed field that displays the model name and the description: DVS109W02-8 FE with 1 GE.			
System Capability	The device type. If th	e supported capabilities are identical to the enabled		
Supported	capabilities, the fields	s display the same information. The fields can display the		
System Capability	following information	: Router, Bridge, Telephone, DOCSIS Cable Device,		
Enabled	WLAN Access Point,	Repeater, Station, or Other.		
Port ID Subtype	The data type display	ved in the Port ID field.		
Port ID	The physical address	s of the interface.		
Port Description	The description of the	e port.		
	The Tx TLVs that are enabled, for example, if all TLVs are enabled: Port			
Enabled Tx TLVs	Description, System Name, System Description, System Capability,			
	Management Addres	s, and Mac Phy.		
Managamant Address	Sub Type	The address type that the management interface uses,		
Management Address	Addroso	The address that is used to manage the switch		
Extended 202.2 TIV/ Infe	Address	The address that is used to manage the switch		
Extended 802.3 TEV Into		Displays whether the interface symposize the part opened		
	Auto-Neg Support	Displays whether the interface supports the port speed		
	& Status	autonegotiation. For example: Supported, Enabled.		
	Advertised	The port speed autonegotiation capabilities		
MAC PHY Configuration &	Capability bits			
Status		The Medium Attachment Unit (MAU) type. The MAU		
	Operational MAU	performs physical layer functions, including the digital		
	Туре	data conversion from the Ethernet interface collision		
		detection and the bit injection into the network.		

3.13.1.5 LLDP Neighbor Information

You can view the LLDP neighbor statistics for an individual interface or all interfaces.

LLDP Neighbor Information

LLDP Neighbor Information	
Show Neighbor	All 🗸
Interface	- 🗸

LLDP Neighbor Statistics					
Chassis ID	Local Interface	Hold Time	Capability	Port ID	
00:18:23:01:20:58	0/8	120	в	Slot0/8	
00:18:23:01:1f:14	0/7	120	в	Slot0/7	
Total Entries Displayed :	2				

Refresh Clear

If you select **Detail** from the Show Neighbor item, the screen displays LLDP Neighbor Detail Statistics for the interface which you specified.

LLDP Neighbor Information

LLDP Neighbor Information	
Show Neighbor	Detail 🗸
Interface	0/7 🗸

LLDP Neighbor Information

Description	Factory default
Show Neighbor	
• All: The information is for all interfaces.	Δ.ΙΙ
• Detail: The information is for one single interface.	All
Interface	
Specify one interface for information.	None

LLDP Neighbor Detail Statistics	
Chassis ID Subtype	MAC Address
Chassis ID	00:18:23:01:1f:14
Port ID Subtype	Interface Alias
Port ID	Slot0/7
Port Description	Slot 0: Port 7: Gigabit-Level
Local Interface	0/7
Time Remaining	102
System Name	Not Advertised
System Description	DVS108W02 - 8 Port with 2 SFP.
System Capability Supported	Bridge ;
System Capability Enabled	Bridge ;
Management Addresses	
If ID	12
SubType	IPv4
Address	192.168.1.152
OID	1 3 6 1 2 1 2 2 1 1
Extended 802.1 Tlvs:	
Port VLAN ID	Not Advertised
Port & Protocol VLAN ID:	Not Advertised
VLAN Name:	Not Advertised
Extended 802.3 TLV:	
MAC PHY Configuration:	
Auto-Neg Support	Supported
Auto-Neg Status	Enabled
Advertised Capability Bits	6c01
	10base-T(HD)
	10base-T(FD) 100base-TX(HD)
	100base-TX(FD)
	1000base-T(FD)
Operational MAU Type	30
Link Aggregation:	Not Advertised
Maximum Frame Size	Not Advertised

Item	Description
Chassis ID	The chassis ID of the remote neighbor
Local Interface	The interface on the switch that receives the LLDP information from the remote
	neighbor
Hold Time	The period in seconds before an LLDP packet expires
	The system capabilities of the remote system. The fields can display the
Capability	following information: Router, Bridge, Telephone, DOCSIS Cable Device, WLAN
	Access Point, Repeater, Station, or Other.
Dout ID	The port identification of the interface on the remote neighbor from which the
FUILID	information was sent

LLDP Neighbor Detail Statistics

3.13.1.6 LLDP Traffic

LLDP Traffic Information

LLDP Traffic Information							
Interface	Frames out	Entries Aged	Frames In	Frames Rx in Error	Frames Discarded	Unrecognized TLVs	Discarded TLVs
0/1	0	0	0	0	0	0	0
0/2	0	0	0	0	0	0	0
0/3	42	0	0	0	0	0	0
0/4	0	0	0	0	0	0	0
0/5	0	1	1	0	0	0	0
0/6	0	0	0	0	0	0	0
0/7	5412	0	5412	0	0	0	0
0/8	5412	0	5412	0	0	0	0

LLDP Traffic Statistics	
Total Frames Out	10866
Total Entries Aged	1
Total Frames In	10825
Total Frames Received In Error	0
Total Frames Discarded	0
Total TLVs Unrecognized	0
Total TLVs Discarded	0

CLEAR

LLDP Traffic Information: The statistics of the fields are for each individual interface. **LLDP Traffic Statistics:** These statistics are total quantities of LLDP traffic for the switch.

3.13.1.7 LLDP-MED Global Configuration

LLDP MED Global Configuration

LLDP MED Global Configura	tion	
Fast Start Repeat Count Device Class	3 Network Connectivity	(1 to 10 Times)
	Cancol Apply	

LLDP MED Global Configuration

Description	Factory default
Fast Start Repeat Count	
Enter the number of LLDP protocol data units (PDUs) that are transmitted when	2
LLDP-MED is enabled for an interface. Enter a number in the range of 1 to 10.	3
Device Class	
This field displays the MED classification of the switch.	
There are four different kinds of devices, and the first three items represent the actual	
endpoints:	
Class I: Generic (for example, an IP communication controller)	Nono
Class II: Media (for example, a conference bridge)	None
Class III: Communication (for example, an IP phone)	
• Network Connectivity (device): Generally a LAN switch or a router, an	
IEEE 802.1 bridge, or an IEEE 802.11 wireless access point	

3.13.1.8 LLDP-MED Interface Configuration

You can configure the LLDP-MED settings for an individual interface on this page.

LLDP-MED Interface Configuration

LLDP-MED Interface Configuration						
	Interface	MED Status	Notification Status	MED Capabilities		
		- 🗸	- 🗸	- 🗸		
	0/1	Disable	Disable	none		
	0/2	Disable	Disable	none		
	0/3	Disable	Disable	none		
	0/4	Disable	Disable	none		
	0/5	Disable	Disable	none		
	0/6	Disable	Disable	none		
	0/7	Disable	Disable	none		
	0/8	Disable	Disable	none		
	Cancel Apply					

LLDP-MED Interface Configuration

Description	Factory default			
Interface				
This field displays the interface number or the port channel number.	interface number			
Med Status				
Specify the MED status:				
Enabled: MED is enabled for the interface.	Disabled			
Disabled: MED is disabled for the interface.				
Notification Status				
Specify the notification status:				
Enabled: MED notifications are sent for the interface.	Disabled			
Disabled: MED notifications are not sent for the interface.				
MED Capabilities				
Specify the MED TLVs which are transmitted:	Nono			
none: No MED TLVs are transmitted.	none			

	Description	Factory default
•	network-policy: The network policy information is transmitted.	
•	capabilities: The capabilities information is transmitted.	
•	both: Both the network policy information and the capabilities information	
	are transmitted.	

3.13.2 Port Mirroring

Port Mirror is used for monitoring the network traffic of the source port by the analyzer.

3.13.2.1 Multiple Port Mirroring

The Delta switch can select multiple interfaces as source ports and one interface as a destination or monitor port. The monitor port can monitor the source ports' incoming and outgoing packets. Port Mirroring supports the mirroring of the packets passing in, out the source port, or both at the same time. It supports N to 1 and up to 8 monitored ports per system. Ingress-mirrored packets are sent as unmodified packets (as the packets came in on the ingress port). Egress-mirrored packets are sent as modified packets with a VLAN tag. If the packet is not tagged, the packet will be tagged with tag 1. If the packet is tagged, the packet will not be modified. It does not support the use of the LAG port as a monitored port or a mirror port.

Multiple Port Mirroring

Multiple Port Mirroring			
Monitored Port	0/1 0/2 0/3 0/4 0/5 0/6 0/7 0/8		
Session Mode	V		
Watch Direction	V		
Mirror Port			
Cancel Apply			

Multiple Port Mirroring

Description	Factory default
Monitored Port	
Specify the monitored port or ports for the monitoring.	Unchecked
Session Mode	
Specify whether the port mirroring session mode is enabled:	
• Enable: The port mirroring is enabled. The setting applies to all interfaces.	
• Disable: The port mirroring is disabled. The setting applies to all interfaces.	
Note: When you configure the session mode for an individual interface, it is applied to all interfaces. You can select Enable from the Session Mode drop-down list and control the port mirroring for individual interfaces. If you want to disable the port mirroring, make sure that the direction is not configured for the interfaces. If the direction is configured for the interfaces and you want to disable the port mirroring, select the check box of the interface, and click Delete to remove the port mirroring configuration for the interface.	None
Watch Direction	
Specify the direction in which the port mirroring occurs:	
• Tx and Rx: Both outgoing traffic and incoming traffic are mirrored.	None
Tx Only: Only outgoing traffic is mirrored.	None
Rx Only: Only incoming traffic is mirrored.	
Mirror Port	1
Specify the port which is the mirror port.	None

DVS-G100 Series Managed Industrial Ethernet Switches User Manual

St	Status Table				
	Monitored Port Mirror Port Session Mode		Direction		
	0/1		Disable		
	0/2		Disable		
	0/3		Disable		
	0/4		Disable		
	0/5		Disable		
	0/6		Disable		
	0/7		Disable		
	0/8		Disable		

Cancel Delete

Status Table

Item	Description			
Monitored Port	This field displays the monitored port number.			
	This field displays the destination port or the monitored interface. Only one port			
Mirror Port	can be the mirror port. This port is used as the mirror port for all ports which you			
	configure for the port mirroring.			
	The port mirroring status of the port.			
Session Mode	Enable: The port mirroring is enabled.			
	Disable: The port mirroring is disabled.			
	The direction of the port mirroring.			
Direction	• Tx and Rx: Both outgoing traffic and incoming traffic are mirrored.			
Direction	• Tx Only: Only outgoing traffic is mirrored.			
	Rx Only: Only incoming traffic is mirrored.			

3.14 Auto Warning

Industrial Ethernet devices in an industrial environment are very important. These devices usually need to work for a long time and are usually located at the end of the system. So if the devices which connect to the industrial Ethernet switch need to be maintained, the switch must provide some messages for the maintainer. Even when the maintainers or the engineers do not stay in the control room, they still need to be informed of the status of the devices. The Delta switch provides different approaches that can warn engineers automatically. In this section, you can get the information about a relay alarm.

IMPORTANT:

Make sure that you save the configuration in the Save Configuration page after you have applied the configuration changes. (Save Config \rightarrow Save Configuration) If you do not save the configuration, then the configuration will be cleared after the switch is rebooted.

3.14.1 Relay Alarm

A relay alarm is used to monitor power, DI, the port status and redundancy. You can configure the power, DI, redundancy and the port link or the traffic overload alarm event to notice related engineers.

3.14.1.1 Relay Alarm Setting

The Delta switch provides flexible configuring items for you to configure events according to your requirement. If an event happens, it will trigger a relay alarm.

Relay Alarm I Events Settings

System Events				
Power1	Disabled 🗸	Power2	Disabled 🗸	
DI1	Disabled 🗸	DI2	Disabled 🗸	
Redundancy	Disabled 🗸			

PC	Port Events				
	Port	Link	Traffic-Overload	Traffic-Threshold(%)	Traffic-Duration(s
		- 🗸	- 🗸		
	0/1	Disabled	Disabled	1	1
	0/2	Disabled	Disabled	1	1
	0/3	Disabled	Disabled	1	1
	0/4	Disabled	Disabled	1	1
	0/5	Disabled	Disabled	1	1
	0/6	Disabled	Disabled	1	1
	0/7	Disabled	Disabled	1	1
	0/8	Disabled	Disabled	1	1

Cancel Apply

Relay Alarm II Events Settings

System Ev	/ents		
Power1	Disabled 🔽	Power2	Disabled 🔽
DI1	Disabled 🗸	DI2	Disabled 🗸
Redundancy	Disabled 🗸		

Po	Port Events				
	Port	Link	Traffic-Overload	Traffic-Threshold(%)	Traffic-Duration(s)
		- 🗸	- 🗸		
	0/1	Disabled	Disabled	1	1
	0/2	Disabled	Disabled	1	1
	0/3	Disabled	Disabled	1	1
	0/4	Disabled	Disabled	1	1
	0/5	Disabled	Disabled	1	1
	0/6	Disabled	Disabled	1	1
	0/7	Disabled	Disabled	1	1
	0/8	Disabled	Disabled	1	1

Cancel Apply

System Events

	Description	Factory default
Power 1		
Specify th	e power event status:	
•	Disable: Disable Power 1 to trigger relay alarm 1 or 2.	
•	On to Off: When the status of Power 1 changes from On to Off, relay alarm	Disable
	1 or 2 is triggered.	
•	Off to On: When the status of Power 1 changes from Off to On, relay alarm	

Description	Factory default			
1 or 2 is triggered.				
Power 2				
Specify the power event status:				
Disable: Disable Power 2 to trigger relay alarm 1 or 2.				
On to Off: When the status of Power 2 changes from On to Off, relay alarm	Disable			
1 or 2 is triggered.	Disable			
 Off to On: When the status of Power 2 changes from Off to On, relay alarm 				
1 or 2 is triggered.				
DI 1				
Specify the DI event status:				
• Disable: Disable DI 1 to trigger relay alarm 1.				
 On to Off: When the status of DI 1 changes from On to Off, relay alarm 1 is 	Disable			
triggered.	2.000.0			
• Off to On: When the status of DI 1 changes from Off to On, relay alarm 1 is				
triggered.				
Specify the DI event status:				
Disable: Disable DI 2 to trigger relay alarm 1 or 2.				
On to Off: When the status of DI 2 changes from On to Off, relay alarm 1 or	Disable			
2 is triggered.				
Off to On: When the status of DI 2 changes from Off to On, relay alarm 1 of				
Z IS triggered.				
Redundancy				
Specify the redundancy event status:				
Disable: Disable One Ring, One CHAin, or One COUPLing event to triager roles alore 1 or 2				
Ingger relay alarm 1 of 2.	Dischlo			
Enable One Ring, One Chain, of One Courting event to trigger relay alarm 1 or 2	Disable			
If the hardware version is too old this function will not be activated				
i the hardware version is too old, this function will not be activated.				

Port Events

Description	Factory default
Link	
Specify the port link event status:	
• Disable: Disable the port link to trigger relay alarm 1 or 2.	
On to Off: When the status of the port link changes from On to Off, relay	Dicabla
alarm 1 is triggered.	Disable
Off to On: When the status of the port link changes from Off to On, relay	
alarm 1 is triggered.	
Traffic-Overload	
Specify the traffic overload event status. The traffic overload is used to monitor the	
port's ingress traffic flow. It has two parameters: threshold and duration.	Dicabla
• Disable: Disable traffic-overload to trigger relay alarm 1 or 2.	Disable
Enabled: Enable traffic-overload to trigger relay alarm 1 or 2.	
Traffic-Threshold (%)	
Specify the traffic speed threshold percentage of the port. Enter the value between 1	1
and 100.	I
Traffic-Duration (s)	
Specify the traffic overload duration. If the average flow of the port overloads the	
threshold during this duration, it means the traffic is overloaded. Enter the value	1
between 1 and 300.	



Note:

If you want the Relay Alarm function to work properly, please make sure that the Delta switch has

one set of power at least.

For example:

- The Power 1 system event is configured to "Off to On", and Power 1 & 2 have no power. If you provide power for Power 1, then Relay Alarm will not be triggered. Because when the event happened, the Delta switch has no power at that moment.
- The Power 1 system event is configured to "On to Off", and Power 1 has power, but Power 2 has no power. If you turn off Power 1, then Relay Alarm will not be triggered. Even though the Delta switch has power at the moment when the event happens, it has no power after that moment, so Relay Alarm will not be triggered.

3.14.1.2 Relay Alarm Table

The status of Relay Alarm is displayed on this page. This table only displays the current alarm, so if the event is not triggered, it is not displayed either.

Current	Alarm	List

Current Alarm List		
Index Event Relay		Relay
1	Port 3 Link up	1
2	Port 6 traffic overload	1



Current Alarm List

ltem	Description
Index	The index number in the list
Event	This field displays the alarm event.
Relay	This field displays the relay number.

3.15 Dual Image

The Delta switch allows a user to maintain two image files. One image can function as an active image. The second image can function as a backup image, and you can put an older or the newest image in the second image. This function provides an efficient firmware upgrade or downgrade process, and reduces the time during the process.

IMPORTANT: Make sure that you save the configuration in the Save Configuration page after you have applied the configuration changes. (Save Config→Save Configuration) If you do not save the configuration, then the configuration will be cleared after the switch is rebooted.

3.15.1 Copy

After upgrading firmware and running it as active firmware, you can keep the older image to image2, or you can copy the current firmware to image2 for backup.

Сору

Сору		
Source Image	🔘 Image1 🛛 🔘 Ir	nage2
Destination Image	🔘 Image1 🛛 🔘 Ir	mage2
Transfer Status		
	Cancel Apply	

3.15.2 Configuration

If you have two firmware image files, you can specify the firmware which is the active firmware, and it is loaded when the switch starts or restarts. **Dual Image Configuration**

D	ual Image Config	uration			
	Image Name	Active Image	Next Active Image	Description (1-256)	Version
			- 🗸		
	image1	True	True		1.18
	image2	False	False		
Delete Cancel Apply					

Note:

Please make sure that you have saved the settings on the switch before you restart the switch.

3.16 Save Config

Save Config allows users to save configuration, and erase configuration and logs.

3.16.1 Save Configuration

After you select the box and click the **Apply** button, all the configuration will be saved in the **Startup Configuration** file. And if you reboot the switch, the configuration will be retained. If you do not save configuration before rebooting the switch, the configuration value that you have saved last time will be gone after you reboot the switch.

-	~ (-	
S D V O	CON	1/11/12	stion
Jave	COIII		1000

Save Configuration	
Saving all applied changes will cause all changes to configuration panels that were applied, but not saved, to be saved, thus retaining their new values across a system reboot.	

Apply

3.16.2 Auto-Save Configuration

When enable auto-save mode, all of the current configuration will be written to the Startup Configuration automatically. Users no need to check "Save Configuration" function when you are done configuring every time.

Auto-Save Configuration

Auto-Save Configuration			
Auto-Save Mode	Oisable	○ Enable	
	Apply Cancel		

3.16.3 Configuration Copy

This feature support user to backup the configuration file.

Configuration Copy		
Configuration Copy		
Source File Name	O Startup Configuration	O Backup Configuration
Destination File Name	O Startup Configuration	Backup Configuration



Note:

Before you use the function, creat a backup file first so that the function can be configured. You can refer to the Chapter 3.1.7.2 Upload file.

3.16.4 Restore

Restore Configuration

Restore Configuration			
Restore Option	🔘 No Restore	Startup Restore	
	Apply Cancel		

Restore Configuration

ltem	Description
No Restore	After the switch reboots, it will load default configuration.
Startup Restore	After the switch reboots, it will load startup configuration. Note: Please make sure that you have saved the settings on the switch before restart the switch.

3.16.5 Erase

Erase File		
Erase File		
File Type	Startup Configuration 💌	

Apply

There are three file types which can be erased:

- Startup Configuration
- Backup Configuration

Log

Note:

When you erase the startup configuration file (for example, because there are problems with the file) and then restart the switch, the factory default startup configuration is used. However, note that erasing the startup configuration file is not the same as resetting the switch to the factory default settings. Resetting the switch to the factory default deletes not only the startup configuration file but also all other configuration files such as the SSL key, the log files, the backup configuration, and so on.

3.17 Reset

The Reset function provides the function of rebooting a switch for users.

3.17.1 Device Reboot

After you select the box and click the **Apply** button, GUI will not be available until the switch completes the boot cycle. After the switch is reset, you need to re-login again.

Device Reboot	
Device Reboot	
Check this box and click APPLY below to reboot	
vlqqA (

3.17.2 Factory Default Settings

After you select the box and click the **Apply** button, the Delta switch will be reset to the factory default values. The IP address reverts to 192.168.1.5, the user login name reverts to the admin, and the password is blank.

Factory Default Settings	
Factory Default Settings	
Check this box and click APPLY below to reset	
Apply	

3.18 Troubleshooting

Sometimes there is disconnection or unstable connection in the network. So the Troubleshooting function provides the ping function which checks the connection situation between the Delta switch and the other devices or clients. It also provides the traceroute function which traces the packet's path to a remote destination.

3.18.1 Ping IPv4

Ping

Details			
IP Address/Hostname	192.168.1.30]	
Count	1	(1 to 10)	
Interval(secs)	3	(1 to 100)	
Datagram Size	32	(0 to 2080)	
Ping	Reply Received From : 1 192.168.1.30 Ping S 1 Packets Transmitted,	192.168.1.30, TimeTaken : 10 msecs tatistics 1 Packets Received, 0% Packets Loss	*

Apply

Ping

Description	Factory default
IP Address/Hostname	
Specify the IP address or the host name that you want to ping. Enter an IPv4 address	Nono
or a host name.	None
Count	
Specify the number of echo requests to be sent. Enter a number between 1 and 10.	3
Interval(secs)	
Specify the ping request interval between the ping packets if the IP address/Hostname	2
doesn't reply. Enter a number between 1 and 100 seconds.	3
Datagram Size	
Specify the size of the ping packet in bytes. Enter a payload size between 0 and 2080	22
bytes.	32

 An unsuccessful ping is displayed in the way described below: Reply Not Received From : <ipv4 address>, Timeout : <number> secs
 --- <ipv4 address> Ping Statistics --- <count> Packets Transmitted, 0 Packets Received, 100% Packets Loss

A successful ping is displayed in the way described below:

Reply Received From : <ipv4 address>, TimeTaken : <number> msecs --- 192.168.1.5 Ping Statistics ---

<count> Packets Transmitted, <number> Packets Received, 0% Packets Loss

Note:

1

•

Make sure that the IP Address/Hostname you want to ping really exists and normally works in the same segment as the switch.

3.18.2 Ping IPv6

Ping IPv6

Details	
Ping	Global 💌
IPv6 Address/Host Name	
Datagram Size	100 (48 to 2048)
Ping	

Apply

Ping IPv6

Description	Factory default
Ping	
Specify a type of IP address.	
Global: The global IP address	Clobal
• Link Local: The link local IP address. They are assigned with the fe80::/64	Giubai
prefix.	
IPv6 Address/Host Name	
Specify the IPv6 address or the host name that you want to ping. Enter an address in	Nono
the xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx format.	NOTE
Datagram Size	
Specify the size of the ping packet in bytes. Enter a payload size between 48 and	100
2048 bytes.	100

 An unsuccessful ping is displayed in the way described below: ping6 <IPv6 address> Destination Unreachable

 A successful ping is displayed in the way described below: count=3, Receive count=<number> from <IPv6 address>. Average round trip time = <number> ms

3.18.3 Traceroute IPv4

TraceRoute

TraceRoute	
IP Address/Hostname	172.16.0.1

Results				
Results	1 2 3 4 5 6	172.16.155.254 172.31.4.250 10.17.192.33 10.17.192.82 172.31.1.253 172.16.0.1	100 ms 110 ms 100 ms 100 ms 110 ms 100 ms 110 ms 100 ms 100 ms 110 ms 100 ms 110 ms 100 ms 100 ms 110 ms 100 ms 110 ms 100 ms	<

Apply

Traceroute IPv4

ltem	Description
IP Address/Hostname	Specify the IP address or the host name that you want to ping. Enter an IPv4
Il Address/Hostilaine	address or a host name.

After you click **Apply** to trace the route, the results are displayed in the Results field. If the switch can not trace the route, the Results field displays asterisk characters (***).

3.18.4 Traceroute IPv6

After you click **Apply** to trace the route, the results are displayed in the Results field. If the switch can not trace the route, the Results field displays asterisk characters (***) and the following text: "Destination unreachable Error in receiving the packet."

Traceroute IPV6	
TraceRoute IPv6	
IPv6 Address/Host Name	
Results	
Results	

Apply

Traceroute IPv6

ltem	Description
IBv6 Addross/Host Namo	Specify the IPv6 address or the host name that you want to ping. Enter an
IF VO AUGIESS/110St Naille	address in the xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx format.

3.19 Logout

Logout will disconnect the HTTP session. After you finish the configuration, we recommend that you log out for security reasons.

MEMO



Chapter 4 IEXplorer Utility Introduction

Table of Contents

4.1	Sta	rting the Configuration	4-3
4.2	Dev	rice	4-4
4.2	2.1	Search	. 4-4
4.2	2.2	Live Viewer	. 4-4
4.3	Set	tings	. 4-4
4.3	3.1	Device Configuration	. 4-5
4.3	3.2	Configuration Web Page	. 4-6
4.4	Тоо	ls	. 4-7
4.4	1.1	IP Setting	. 4-7
4.4	1.2	Ping Test	. 4-7
4.4	1.3	Parameter Import	. 4-8
4.4	1.4	Parameter Export	. 4-8
4.4	1.5	Device Reboot	. 4-9
4.4	1.6	Update Firmware	. 4-9
4.5	Hel	ρ4	l-10

Delta has many kinds of industrial products and network devices. If you have many Delta network products, the IEXplorer utility can help you search them via one interface. The IEXplorer utility can search for IES series products, DVP series products and some Delta products which have extension communication cards. It can help you know the IP address of a device, modify the configuration, and upgrade the firmware.

The IEXplorer utility supports the following models:

- DVS-G106W02-2GF
- DVS-G112W02-4GF
- DVS-G116W02-4GF
- DVS-108W02-2SFP
- DVS-109W02-1GE
- DVS-110W02-3SFP
- DVW-W02W2-E2 / DVW-W02W2-E2-CN / DVW-W02W2-E2-EU
- DVS-328R02-8SFP
- DVS-G512W01-4GF
- DVS-G928W01
- IFD9506
- IFD9507
- RTU-EN01
- DVPEN01-SL
- DVP12SE
- DVP-FEN01
- DVPSCM12-SL
- DVPSCM52-SL
- ASDA-M
- CMC-MOD01
- CMC-EIP01

More models are coming soon.

Compatible OS: Windows XP SP2, Windows 7 (32/64 bits), Windows 8(64 bits) or Windows 10 (32/64 bits)

4.1 Starting the Configuration

After you finish the installation, you can find the IEXplorer icon on the desktop. Double-click the icon to run the program.



1. After double-clicking the icon, you can see the IEXplorer interface shown below:

🌀 IEXplorer - [Login]		
Smarter. Greener. Toge	A ther.	Serial-to-Ethernet Device Server
UserName:		
Password:		
	Modify Login	
Found 4 devices		

- 2. Enter the username "admin" and the password is "admin1234", click Login button to start the configuration.
- 3. IEXPlorer also provides an admin user can be able to make modification of password. Passwords are 1–20 alphanumeric characters in length and are case sensitive. The password is displayed as asterisks (*).

4.2 Device

There are four items on the Devices menu: Search, Live Viewer, Virtual COM and Exit.



4.2.1 Search

If the utility can not find any devices, the message box will pop up.

<u>^</u>	Cannot find any devices on the local network
	ОК

The automatic search function performs every 1 minute. If the device does not exist anymore, it will be moved from the list view.

You can specify the refresh interval from the device search window

4.2.2 Live Viewer

IEXplorer provides the user monitor the connectivity. The default refresh interval is 72 hours, and the range is 1 to 720 hours. The status of RED is meaning disconnection and the status of GREEN is meaning connection.

If the user needs to check current on-line status, please click the Refresh Now button.

4.3 Settings

The IEXplorer utility provides two ways for users to configure the devices. You can configure the basic settings via **Device Configuration** or configure completely settings via **Open Configuration Web Page**. The **Settings** menu can be clicked only when you select DVS or DVW series products in the list view.



4.3.1 Device Configuration

The login ID and the password are the same as the web interface.

ỡ IEXplorer - [Login Administrator]	
É <u>D</u> evice <u>Settings</u> <u>T</u> ools <u>H</u> elp	
<u>। 🔍 🔯 । 🐣 😒 । 🔁 🗢 🧐 📥 🍞 </u>	
Smarter. Greener. Together.	
Administrator Name: admin	
Administrator <u>P</u> assword:	
OK Cancel	
找到3裝置	

🏈 IEXplorer - [DeviceConfig	;urationfrm]			
<u>Device Settings Tools H</u>	elp			
<mark>! Q 🔉 & 🕄 Ð Ə 🤅</mark>) 📥 😧			
Smarter. Greener. Togethe Overview Basic Password	6			
Device Review				
Model	DVS-110W02-3SFP			
IP Address	192.168.1.15			
MAC Address	00-18-23-01-00-BB			
Firmware Version	0.09			
		OK	Cancel	
),;;

After the authentication progresses, the basic setting interface will display information, as shown below:

You can configure the device name and the IP information, modify the password, and reset the password to the factory default setting in this interface.

4.3.2 Configuration Web Page

If you click Open Configuration Web Page, the web interface will be displayed.

🏉 Please Login - Windows Internet Explorer			- • •
O ⊂ http://192.168.1.16/		🕶 🐓 🗙 🔎 Bing	• م
🚖 Favorites 🖉 Please Login			
			Englich
			Lingilari
	Login		
	Username		
	Password		
		Login	



You can double-click the device in the list view to open the configuration web page. If the device which you select is not a DVS or DVW series device, the utility will start **DCISoft** for you to configure the device.

4.4 Tools

🌀 IEXplor	er - [Login D	evice]
Device	Settings	Тоо	ls Help
🔍 🐁	🔊 🐣 🤶	IP	IP Setting
		F	Ping Test
		Ð	Parameter Import
		\ominus	Parameter Export
		6	Device Reboot
	er. Greener.		Update Firmware

Please select the device before using the functions on the **Tools** menu.

4.4.1 IP Setting

After IP Setting is clicked, it will display the device list and you can select one device to configure a static IP address, or entering the start IP address to configure multiple devices which you select from the device list.

Check	Device Name	Model	IP Address	MAC Address
	DVS-G512W01-4GF	DVS-G512W01-4GF	192.168.1.173	00-18-23-12-C0-11
	DVS-G928W01	DVS-G928W01	192.168.1.5	00-18-23-FF-FF-FF
	PPPP	DVS-108W02-2SFP	192.168.1.21	00-18-23-01-08-06



Note:

If you need to keep the IP address, please remember to save the configuration from any managed interface.

4.4.2 Ping Test

After Ping Test is clicked, you can specify the IP address that you want to ping.

IP: 192.168.1.20	Ping
Request Timeout(1-60): 3 🔿 sec.	
Ping 192.168.1.20: Success !!	

4.4.3 Parameter Import

After **Parameter Import** is clicked, the drop-down list of Product will display the product list, and you can select one device to import the parameter file.

When you select the product and the path is specified, entering administrator name and password to starting import the parameter file.

Product 🗸	FilePath	Searc h	administrator Name admin	administrator Password	Add	Delete Run
DVS-108W02-2SFP>192.168.1.21 DVS-G512W01-4GF>192.168.1.173 DVS-G928W01>192.168.1.5	IP Address	MAC Address	File Path		Admin Name	Admin Password



Note:

- 1. Make sure the parameter file and the product you selected is matched.
- 2. The login ID and the password are the same as the web interface.

4.4.4 Parameter Export

After **Parameter Export** is clicked, the drop-down list of Product will display the product list, and you can select one device to export the parameter file.

When you select the product and the path is specified, entering administrator name and password to starting export the parameter file.

Product	FilePath		administrator Name	administrator Password		
VS-G928W01>192.168.1.5		Searc h	admin		Add	Delete Run
VS-108W02-2SFP>192.168.1.21 VS-G512W01-4GF>192.168.1.173 VS-G928W01>192.168.1.5	IP Address	MAC Address	File Path		Admin Name	Admin Password



Ţ

4.4.5 Device Reboot

IEXplorer allows you to reboot the device via the utility.

Device Name	Model	IP Address	MAC Address	Firmware Version	Serial Number
	DVS-328R02-8SFP	192.168.1.16	00-18-23-01-3B-60	0.08	DVS328011637
	Oo you	want to reboot ?			
			and the second		

4.4.6 Update Firmware

After **Update Firmware** is clicked, the drop-down list of Product will display the product list, and you can select one device to update the firmware.

When you select the product and the path is specified, entering administrator name and password to starting update firmware.

Product	FilePath		administrator Name administra	tor Password	
DVS-G928W01>192.168.1.5		Searc h	admin	Add	Delete Run
DVS-G512W01-4GF>192.168.1.173	IP Address	MAC Address	File Path	Admin Name	Admin Password
DVS-108W02-2SFP>192.168.1.21		11110 11441000	110100	110,000	110,000,010



Note:

1. If it is update successfully, please wait for 3 minutes to login again.

2. The login ID and the password are the same as the web interface.

4-9

4

4.5 Help

4

After About on the Help menu is clicked, an information message window of IEXplorer will pop up.



MEMO

4



Appendix A Private MIB Group

Table of Contents

A.1	Private MIB GroupA	۱-:	2
	· · · · · · · · · · · · · · · · · · ·		

A.1 Private MIB Group

Delta switch not only supports standard MIBs, but also provides private MIBs. You can use the SNMP tool to configure or monitor the switch's configuration. The private MIBs are the same as standard MIBs. It is displayed like a web tree. It's easily to be understood and used, so you don't need to learn or find where the OIDs of the commands are.

A private MIB can be found in the product CD if you need to use it.



We also support standard MIB Groups. For example, Interfaces Group, IP Group, TCP Group, UDP Group, and SNMP Group.

MEMO


Appendix B MODBUS TCP Map

Table of Contents

B-2	DVS-G106W02-2GF	B.1
B-8	DVS-G112W02-4GF	B.2
B-14	DVS-G116W02-4GF	B.3

B.1 DVS-G106W02-2GF

Address Offset	Data Type	Format	Description	Note				
System Informati	System Information							
0x0001 0x0003	1 word 1 word	HEX	Product Code Firmware Version Hi byte = major Lo byte = minor	Product Code (8ABBH) Ex: V1.00 High byte = 0x01 Lo byte = 0x00				
0x0004	2 word	HEX	Firmware Release Date Word 0 Hi byte = day Word 0 Lo byte = clock Word 1 Hi byte = year Word 1 Lo byte = month	Ex: 20120918, PM9:00 Word 0 = 0x1215, Word 1 = 0x0C09				
0x0010	20 words	ASCII	Vendor Name	"Delta Electronics, Inc." Word 0 Hi byte = 'D' Word 0 Lo byte = 'e' Word 1 Hi byte = 'I' Word 1 Lo byte = 't' Word 2 Lo byte = 'a' Word 2 Lo byte = 'E' Word 3 Hi byte = 'E' Word 4 Hi byte = 'e' Word 4 Lo byte = 'c' Word 5 Hi byte = 't' Word 5 Lo byte = 'r' Word 6 Hi byte = 'o' Word 6 Lo byte = 'n' Word 7 Lo byte = 'c' Word 8 Hi byte = 's' Word 8 Hi byte = 's' Word 8 Lo byte = ', ' Word 9 Hi byte = '' Word 10 Hi byte = 'n' Word 11 Hi byte = '\0'				
0x0030	20 words	ASCII	Product Name	"DVS-G106W02-2GF" Word 0 Hi byte = 'D' Word 0 Lo byte = 'V' Word 1 Hi byte = 'S' Word 1 Lo byte = '-' Word 2 Hi byte = 'G' Word 2 Lo byte = '1' Word 3 Hi byte = '0' Word 3 Lo byte = '6' Word 4 Hi byte = 'W' Word 4 Lo byte = '0'				

				Word 5 Hi byte = '2' Word 5 Lo byte = '-' Word 6 Hi byte = '2' Word 6 Lo byte = 'G' Word 7 Hi byte = 'F' Word 7 Lo byte ='\0'
0x0050	20 words	ASCII	Serial No.	
0x0070	3 words	ASCII	Ethernet MAC Address	Ex: MAC = $00:11:22:33:44:55$ Word 0 Hi byte = $0x00$ Word 0 Lo byte = $0x11$ Word 1 Hi byte = $0x22$ Word 1 Lo byte = $0x33$ Word 2 Hi byte = $0x44$ Word 2 Lo byte = $0x55$
0x0073	2 words	HEX	Ethernet IP Address	Ex: IP = 192.168.1.5 Word 0 = 0xC0A8 Word 1 = 0x0105
0x0075	2 words	HEX	Ethernet Netmask	Ex: Mask = 255.255.255.0 Word 0 = 0xFFFF Word 1 = 0xFF00
0x0077	2 words	HEX	Ethernet Gateway IP Address	Ex: IP = 192.168.1.1 Word 0 = 0xC0A8 Word 1 = 0x0101
0x0080	1 word	HEX	Power 1 Status	0x0000: OFF 0x0001: ON
0x0081	1 word	HEX	Power 2 Status	0x0000: OFF 0x0001: ON
0x0090	1 word	HEX	DO 1 Status	0x0000: OFF 0x0001: ON
0x00A0	1 word	HEX	DI 1 Status	0x0000: OFF 0x0001: ON
Port Information				
0x1000 ~ 0x1005	1 word	HEX	Port 1 to 6 Status	0x0000: Link down 0x0001: Link up 0x0002: Disable
0x1100 ~ 0x1105	1 word	HEX	Port 1 to 6 Physical Status	0x0000: 10M,Half 0x0001: 10M,Full 0x0002: 100M,Half 0x0003: 100M,Full 0x0004: 1G,Full
0x1200 ~ 0x1205	1 word	HEX	Port 1 to 6 Flow Control	0x0000: OFF 0x0001: ON
0x1300 ~ 0x1305	1 word	HEX	Port 1 to 6 MDI/MDIX Setting	0x0000: Auto 0x0001: MDI 0x0002: MDIX
0x1500 ~ 0x1505	1 word	HEX	Port 1 to 6 bandwidth overload	0x0000: OFF 0x0001: Port X bandwidth overload

0x1600 ~ 0x1605	1 word	HEX	Port 1 to 6 loopback detection port status	0x0000: OFF 0x0001: loopback detected
0x1A00 ~ 0x1C30	20 words	HEX	Port 1 to 6 Description EX: $10/100/1000TX$,RJ45 Word 0 Hi byte = '1' Word 0 Lo byte = '0' Word 1 Hi byte = '/' Word 2 Hi byte = '0' Word 2 Lo byte = '0' Word 3 Hi byte = '/' Word 3 Lo byte = '1' Word 4 Lo byte = '0' Word 5 Lo byte = '0' Word 5 Lo byte = 'T' Word 6 Hi byte = 'X' Word 6 Lo byte = ',' Word 7 Hi byte = 'R' Word 7 Lo byte = 'J' Word 8 Hi byte = '4' Word 8 Lo byte = '5' Word 9 Lo byte = '\0'	Note: 10/100TX,RJ45 10/100/1000TX,RJ45 100/1000,SFP
Packet Information	n			
0x2000 ~ 0x200B	2 words	HEX	Port 1 to 6 Tx Packets	Ex: Port 1 Tx Packet Amount = 0x33221100 0x2000 = 0x3322 0x2001 = 0x1100
0x2100 ~ 0x210B	2 words	HEX	Port 1 to 6 Rx Packets	Ex: Port 1 Rx Packet Amount = 0x33221100 0x2100 = 0x3322 0x2101 = 0x1100
0x2200 ~ 0x220B	2 words	HEX	Port 1 to 6 Tx Error Packets	Ex: Port 1 Tx Packet Amount = 0x33221100 0x2200 = 0x3322 0x2201 = 0x1100
0x2300 ~ 0x230B	2 words	HEX	Port 1 to 6 Rx Error Packets	Ex: Port 1 Rx Packet Amount = 0x33221100 0x2300 = 0x3322 0x2301 = 0x1100
Redundancy Infor	mation (I	f the spec	for Proprietary Ring is comp	leted, we will add this function)
0x3000	1 word	HEX	Redundancy Protocol	0x0000: None 0x0001: RSTP/STP
0x3001	1 word	HEX	RSTP Root	0x0000: Not Root 0x0001: Root

0x3100 ~ 0x3105	1 word	HEX	RSTP Port 1 to 6 Status	0x0000: Port Disable 0x0001: Not RSTP Port 0x0002: Link Down 0x0003: Discarding 0x0004: Learning 0x0005: Forwarding
0x3200	1 word	HEX	RING mode	0x00: None (Disable) 0x01: Master 0x02: Slave
0x3201	1 word	HEX	RING State	RING function is disable: 0x00: None RING Mode is Master: 0x00: Discover 0x01: Monitor 0x02: Fault RING Mode is Slave: 0x00: Forwarding 0x01: Hold 0x02: Fault
0x3300	1 word	HEX	COUPING Mode	0x00: None (Disable) 0x01: Head 0x02: Tail
0x3301	1 word	HEX	COUPING State	COUPING mode is disable: 0x00: None COUPING mode is Head: 0x00: Monitor 0x01: Fault 0x02: Link-Up 0x03: Hold COUPING mode is Tail 0x00: Discover 0x01: Monitor 0x02: Fault
0x3400	1 word	HEX	CHAIN Mode	0x00: None (Disable) 0x01: Head 0x02: Tail 0x03: Member
0x3401	1 word	HEX	CHAIN State	CHAIN mode is disable: 00: None CHAIN mode is Head: 0x00: Discover 0x01: Monitor 0x02: Fault 0x03: Holde CHAIN mode is Member: 0x00: Forwarding 0x01: Hold CHAIN mode is Tail: 0x00: Discover 0x01: Monitor 0x02: Fault
SPF DDM Informa	ation			
UX4000 ~ 0X4001	1 word	HEX	Port 1 to Port 2 Port No.	

0x4100 ~ 0x4127	20 words	HEX	Port 1 to Port 2 Model Name	SFP DDM Memory Map EEPROM Serial Interface (2-Wire Address A0) Data Address: 40-55 Example: LCP-1250B4QDRH Word 0 Hi byte = 'L' Word 0 Lo byte = 'C' Word 1 Lo byte = 'P' Word 2 Hi byte = '1' Word 2 Lo byte = '2' Word 3 Hi byte = '5' Word 3 Lo byte = '0' Word 4 Hi byte = 'B' Word 4 Lo byte = 'A' Word 5 Hi byte = 'Q' Word 5 Lo byte = 'D' Word 6 Lo byte = 'H' Word 7 Hi byte = '\0'
0x4200 ~ 0x4203	2 words	HEX	Port 1 to Port 2 Temperature Word 0 = Temperature MSB Word 1 = Temperature LSB	Real Time Diagnostic (2-Wire Address A2h) Data Address: 96-97
0x4300 ~ 0x4303	2 words	HEX	Port 1 to Port 2 Voltage Word 0 = Vcc MSB Word 1 = Vcc LSB	Real Time Diagnostic (2-Wire Address A2h) Data Address: 99-99
0x4400 ~ 0x4403	2 words	HEX	Port 1 to Port 2 TX Power Word 0 = TX Power MSB Word 1 = TX Power LSB	Real Time Diagnostic (2-Wire Address A2h) Data Address: 102-103
0x4500 ~ 0x4503	2 words	HEX	Port 1 to Port 2 RX Power Word 0 = RX Power MSB Word 1 = RX Power LSB	Real Time Diagnostic (2-Wire Address A2h) Data Address: 104-105
0x4600 ~ 0x4601	1 words	HEX	Port 1 to Port 2 Link Status	0x0000: Link down 0x0001: Link up
Alarm				
0x5000	1 word	HEX	Switch colde start alarm	0x0000: OFF 0x0001: ON 0xFFFF: Disable
0x5001	1 word	HEX	Switch warm start alarm	0x0000: OFF 0x0001: ON
0x5004	1 word	HEX	Power state on alarm	0x0000: OFF 0x0001: ON
0x5005	1 word	HEX	Power state off alarm	0x0000: OFF 0x0001: ON
0x5006	1 word	HEX	DI on alarm	0x0000: OFF 0x0001: ON
0x5007	1 word	HEX	DI off alarm	0x0000: OFF 0x0001: ON

0x5008	1 word	HEX	authentication failure alarm	0x0000: OFF 0x0001: ON
0x5009	1 word	HEX	dot1d Bridge New Root alarm	0x0000: OFF 0x0001: ON
0x500A	1 word	HEX	dot1d Bridge Topology Changed alarm	0x0000: OFF 0x0001: ON
0x500B	1 word	HEX	LLDP Remote Tables Change alarm	0x0000: OFF 0x0001: ON
0x500C	1 word	HEX	Configuartion Changed alarm	0x0000: OFF 0x0001: ON
0x500D	1 word	HEX	Firmware update alarm	0x0000: OFF 0x0001: ON
0x500E	1 word	HEX	IP changed alarm	0x0000: OFF 0x0001: ON
0x500F	1 word	HEX	Passward changed alarm	0x0000: OFF 0x0001: ON
0x5010	1 word	HEX	RING failure	0x0000: OFF 0x0001: ON
0x5011	1 word	HEX	RING backup path is activated	0x0000: OFF 0x0001: ON
0x5012	1 word	HEX	RING returns to health status	0x0000: OFF 0x0001: ON
0x5013	1 word	HEX	CHAIN failure	0x0000: OFF 0x0001: ON
0x5014	1 word	HEX	CHAIN backup path is activated	0x0000: OFF 0x0001: ON
0x5015	1 word	HEX	CHAIN returns to HEALTH status	0x0000: OFF 0x0001: ON
0x5016	1 word	HEX	COUPLING failure	0x0000: OFF 0x0001: ON
0x5017	1 word	HEX	COUPLING backup path is activated	0x0000: OFF 0x0001: ON
0x5018	1 word	HEX	COUPLING returns to HEALTH status	0x0000: OFF 0x0001: ON
0x5100 ~ 0x5101	1 word	HEX	SFP Port 1 to Port 2 DDM Failure - Temp alarm	0x0000: OFF 0x0001: ON
0x5110 ~ 0x5111	1 word	HEX	SFP Port 1 to Port 2 DDM Failure - Voltage	0x0000: OFF 0x0001: ON
0x5120 ~ 0x5121	1 word	HEX	SFP Port 1 to Port 2 DDM Failure - Bias	0x0000: OFF 0x0001: ON
0x5130 ~ 0x5131	1 word	HEX	SFP Port 1 to Port 2 DDM Failure - TX Power	0x0000: OFF 0x0001: ON
0x5140 ~ 0x5141	1 word	HEX	SFP Port 1 to Port 2 DDM Failure - RX Power	0x0000: OFF 0x0001: ON
IABU Internal Dat	a (0x2B))	1	1
Device ID Code	Object ID	Length	Description	
0x01	0x00	23 bytes	Vendor Name "Delta Electronics, Inc."	

0x01	32 bytes	Product Name "DVS-G106W02-2GF"	
0x02		Firmware Version Major.Minor Example: Major = 1, Minor = 2, Length = 4 Data byte 0: "31" Data byte 1: "." Data byte 2: "30" Data byte 3: "32"	Length by Firmware Version context

B.2 DVS-G112W02-4GF

Address Offset	Data Type	Format	Description	Note
System Informati	ion	•		
0x0001	1 word	HEX	Product Code	Product Code (8A15H)
0x0003	1 word		Firmware Version Hi byte = major Lo byte = minor	Ex: V1.00 High byte = 0x01 Lo byte = 0x00
0x0004	2 word	HEX	Firmware Release Date Word 0 Hi byte = day Word 0 Lo byte = clock Word 1 Hi byte = year Word 1 Lo byte = month	Ex: 20120918, PM9:00 Word 0 = 0x1215, Word 1 = 0x0C09
0x0010	20 words	ASCII	Vendor Name	"Delta Electronics, Inc." Word 0 Hi byte = 'D' Word 0 Lo byte = 'e' Word 1 Hi byte = 'I' Word 1 Lo byte = 't' Word 2 Hi byte = 'a' Word 2 Lo byte = '' Word 3 Hi byte = 'E' Word 3 Lo byte = 'I' Word 4 Hi byte = 'e' Word 5 Hi byte = 'c' Word 5 Lo byte = 'r' Word 6 Hi byte = 'o' Word 6 Lo byte = 'n' Word 7 Lo byte = 'a' Word 7 Lo byte = 'c' Word 8 Lo byte = 's' Word 8 Lo byte = ', ' Word 9 Hi byte = 'I' Word 10 Hi byte = 'n' Word 10 Lo byte = 'c' Word 11 Hi byte = '\0'

		1	1	
0x0030	20 words	ASCII	Product Name	"DVS-G112W02-4GF" Word 0 Hi byte = 'D' Word 0 Lo byte = 'V' Word 1 Hi byte = 'S' Word 1 Lo byte = 'I' Word 2 Hi byte = 'G' Word 2 Lo byte = '1' Word 3 Hi byte = '1' Word 3 Lo byte = '2' Word 4 Hi byte = 'W' Word 4 Lo byte = 'O' Word 5 Hi byte = '2' Word 5 Lo byte = '-' Word 6 Hi byte = '4' Word 6 Lo byte = 'F' Word 7 Lo byte = '\0'
0x0050	20 words	ASCII	Serial No.	
0x0070	3 words	ASCII	Ethernet MAC Address	Ex: MAC = 00:11:22:33:44:55 Word 0 Hi byte = 0x00 Word 0 Lo byte = 0x11 Word 1 Hi byte = 0x22 Word 1 Lo byte = 0x33 Word 2 Hi byte = 0x44 Word 2 Lo byte = 0x55
0x0073	2 words	HEX	Ethernet IP Address	Ex: IP = 192.168.1.5 Word 0 = 0xC0A8 Word 1 = 0x0105
0x0075	2 words	HEX	Ethernet Netmask	Ex: Mask = 255.255.255.0 Word 0 = 0xFFFF Word 1 = 0xFF00
0x0077	2 words	HEX	Ethernet Gateway IP Address	Ex: IP = 192.168.1.1 Word 0 = 0xC0A8 Word 1 = 0x0101
0x0080	1 word	HEX	Power 1 Status	0x0000: OFF 0x0001: ON
0x0081	1 word	HEX	Power 2 Status	0x0000: OFF 0x0001: ON
0x0090	1 word	HEX	DO 1 Status	0x0000: OFF 0x0001: ON
0x00A0	1 word	HEX	DI 1 Status	0x0000: OFF 0x0001: ON
Port Information				
0x1000 ~ 0x100B	1 word	HEX	Port 1 to 12 Status	0x0000: Link down 0x0001: Link up 0x0002: Disable
0x1100 ~ 0x110B	1 word	HEX	Port 1 to 12 Physical Status	0x0000: 10M,Half 0x0001: 10M,Full 0x0002: 100M,Half 0x0003: 100M,Full 0x0004: 1G,Full

0x1200 ~ 0x120B	1 word	HEX	Port 1 to 12 Flow Control	0x0000: OFF 0x0001: ON
0x1300 ~ 0x130B	1 word	HEX	Port 1 to 12 MDI/MDIX Setting	0x0000: Auto 0x0001: MDI 0x0002: MDIX
0x1500 ~ 0x150B	1 word	HEX	Port 1 to 12 bandwidth overload	0x0000: OFF 0x0001: Port X bandwidth overload
0x1600 ~ 0x160B	1 word	HEX	Port 1 to 12 loopback detection port status	0x0000: OFF 0x0001: loopback detected
0x1A00 ~ 0x1C30	20 words	HEX	Port 1 to 12 Description EX: $10/100/1000TX$,RJ45 Word 0 Hi byte = '1' Word 0 Lo byte = '0' Word 1 Hi byte = '/' Word 2 Hi byte = '0' Word 2 Lo byte = '0' Word 3 Hi byte = '1' Word 3 Lo byte = '1' Word 4 Hi byte = '0' Word 5 Lo byte = '0' Word 5 Lo byte = '0' Word 5 Lo byte = '2' Word 6 Hi byte = 'X' Word 6 Lo byte = 'X' Word 7 Lo byte = 'A' Word 8 Hi byte = '4' Word 8 Lo byte = '5' Word 9 Hi byte = '\0'	Note: 10/100TX,RJ45 10/1000,SFP
Packet Information	n	<u></u> .		
0x2000 ~ 0x2017	2 words	HEX	Port 1 to 12 Tx Packets	Ex: Port 1 Tx Packet Amount = 0x33221100 0x2000 = 0x3322 0x2001 = 0x1100
0x2100 ~ 0x2117	2 words	HEX	Port 1 to 12 Rx Packets	Ex: Port 1 Rx Packet Amount = 0x33221100 0x2100 = 0x3322 0x2101 = 0x1100
0x2200 ~ 0x2217	2 words	HEX	Port 1 to 12 Tx Error Packets	Ex: Port 1 Tx Packet Amount = 0x33221100 0x2200 = 0x3322 0x2201 = 0x1100
0x2300 ~ 0x2317	2 words	HEX	Port 1 to 12 Rx Error Packets	Ex: Port 1 Rx Packet Amount = 0x33221100 0x2300 = 0x3322 0x2301 = 0x1100
Redundancy Infor	mation (If	the spec f	or Proprietary Ring is complete	ed, we will add this function)
0x3000	1 word	HEX	Redundancy Protocol	0x0000: None 0x0001: RSTP/STP

0x3001	1 word	HEX	RSTP Root	0x0000: Not Root 0x0001: Root
0x3100 ~ 0x310B	1 word	HEX	RSTP Port 1 to 12 Status	0x0000: Port Disable 0x0001: Not RSTP Port 0x0002: Link Down 0x0003: Discarding 0x0004: Learning 0x0005: Forwarding
0x3200	1 word	HEX	RING mode	0x00: None (Disable) 0x01: Master 0x02: Slave
0x3201	1 word	HEX	RING State	RING function is disable: 0x00: None RING Mode is Master: 0x00: Discover 0x01: Monitor 0x02: Fault RING Mode is Slave: 0x00: Forwarding 0x01: Hold 0x02: Fault
0x3300	1 word	HEX	COUPING Mode	0x00: None (Disable) 0x01: Head 0x02: Tail
0x3301	1 word	HEX	COUPING State	COUPING mode is disable: 0x00: None COUPING mode is Head: 0x00: Monitor 0x01: Fault 0x02: Link-Up 0x03: Hold COUPING mode is Tail 0x00: Discover 0x01: Monitor 0x02: Fault
0x3400	1 word	HEX	CHAIN Mode	0x00: None (Disable) 0x01: Head 0x02: Tail 0x03: Member
0x3401	1 word	HEX	CHAIN State	CHAIN mode is disable: 00: None CHAIN mode is Head: 0x00: Discover 0x01: Monitor 0x02: Fault 0x03: Holde CHAIN mode is Member: 0x00: Forwarding 0x01: Hold CHAIN mode is Tail: 0x00: Discover 0x01: Monitor 0x02: Fault

SPF DDM Information						
0x4000 ~ 0x4003	1 word	HEX	Port 1 to Port 4 Port No.			
0x4100 ~ 0x4127	20 words	HEX	Port 1 to Port 4 Model Name	SFP DDM Memory Map EEPROM Serial Interface (2-Wire Address A0) Data Address: 40-55 Example: LCP-1250B4QDRH Word 0 Hi byte = 'L' Word 0 Lo byte = 'C' Word 1 Lo byte = 'P' Word 2 Lo byte = '1' Word 2 Lo byte = '2' Word 3 Hi byte = '5' Word 3 Lo byte = '0' Word 4 Hi byte = 'B' Word 4 Lo byte = 'A' Word 5 Hi byte = 'Q' Word 5 Lo byte = 'Q' Word 6 Hi byte = 'R' Word 6 Lo byte = '\0' Word 7 Lo byte ='\0'		
0x4200 ~ 0x4207	2 words	HEX	Port 1 to Port 4 Temperature Word 0 = Temperature MSB Word 1 = Temperature LSB	Real Time Diagnostic (2-Wire Address A2h) Data Address: 96-97		
0x4300 ~ 0x4307	2 words	HEX	Port 1 to Port 4 Voltage Word 0 = Vcc MSB Word 1 = Vcc LSB	Real Time Diagnostic (2-Wire Address A2h) Data Address: 99-99		
0x4400 ~ 0x4407	2 words	HEX	Port 1 to Port 4 TX Power Word 0 = TX Power MSB Word 1 = TX Power LSB	Real Time Diagnostic (2-Wire Address A2h) Data Address: 102-103		
0x4500 ~ 0x4507	2 words	HEX	Port 1 to Port 4 RX Power Word 0 = RX Power MSB Word 1 = RX Power LSB	Real Time Diagnostic (2-Wire Address A2h) Data Address: 104-105		
0x4600 ~ 0x4607	1 words	HEX	Port 1 to Port 4 Link Status	0x0000: Link down 0x0001: Link up		
Alarm						
0x5000	1 word	HEX	Switch colde start alarm	0x0000: OFF 0x0001: ON 0xFFFF: Disable		
0x5001	1 word	HEX	Switch warm start alarm	0x0000: OFF 0x0001: ON		
0x5004	1 word	HEX	Power state on alarm	0x0000: OFF 0x0001: ON		
0x5005	1 word	HEX	Power state off alarm	0x0000: OFF 0x0001: ON		
0x5006	1 word	HEX	DI on alarm	0x0000: OFF 0x0001: ON		
0x5007	1 word	HEX	DI off alarm	0x0000: OFF 0x0001: ON		

0x5008	1 word	HEX	authentication failure alarm	0x0000: OFF 0x0001: ON
0x5009	1 word	HEX	dot1d Bridge New Root alarm	0x0000: OFF 0x0001: ON
0x500A	1 word	HEX	dot1d Bridge Topology Changed alarm	0x0000: OFF 0x0001: ON
0x500B	1 word	HEX	LLDP Remote Tables Change alarm	0x0000: OFF 0x0001: ON
0x500C	1 word	HEX	Configuartion Changed alarm	0x0000: OFF 0x0001: ON
0x500D	1 word	HEX	Firmware update alarm	0x0000: OFF 0x0001: ON
0x500E	1 word	HEX	IP changed alarm	0x0000: OFF 0x0001: ON
0x500F	1 word	HEX	Passward changed alarm	0x0000: OFF 0x0001: ON
0x5010	1 word	HEX	RING failure	0x0000: OFF 0x0001: ON
0x5011	1 word	HEX	RING backup path is activated	0x0000: OFF 0x0001: ON
0x5012	1 word	HEX	RING returns to health status	0x0000: OFF 0x0001: ON
0x5013	1 word	HEX	CHAIN failure	0x0000: OFF 0x0001: ON
0x5014	1 word	HEX	CHAIN backup path is activated	0x0000: OFF 0x0001: ON
0x5015	1 word	HEX	CHAIN returns to HEALTH status	0x0000: OFF 0x0001: ON
0x5016	1 word	HEX	COUPLING failure	0x0000: OFF 0x0001: ON
0x5017	1 word	HEX	COUPLING backup path is activated	0x0000: OFF 0x0001: ON
0x5018	1 word	HEX	COUPLING returns to HEALTH status	0x0000: OFF 0x0001: ON
0x5100 ~ 0x5103	1 word	HEX	SFP Port 1 to Port 4 DDM Failure - Temp alarm	0x0000: OFF 0x0001: ON
0x5110 ~ 0x5113	1 word	HEX	SFP Port 1 to Port 4 DDM Failure - Voltage	0x0000: OFF 0x0001: ON
0x5120 ~ 0x5123	1 word	HEX	SFP Port 1 to Port 4 DDM Failure – Bias	0x0000: OFF 0x0001: ON
0x5130 ~ 0x5133	1 word	HEX	SFP Port 1 to Port 4 DDM Failure - TX Power	0x0000: OFF 0x0001: ON
0x5140 ~ 0x5143	1 word	HEX	SFP Port 1 to Port 4 DDM Failure - RX Power	0x0000: OFF 0x0001: ON
IABU Internal Dat	a(0x2B)		·	
Device ID Code	Object ID	Length	Description	
0×01	0x00	23 bytes	Vendor Name "Delta Electronics, Inc."	
0,01	0x01	32 bytes	Product Name "DVS-G112W02-2GF"	

0x02	Firmware Version Major.Minor Example: Major = 1, Minor = 2, Length = 4 Data byte 0: "31" Data byte 1: "." Data byte 2: "30" Data byte 3: "32"	Length by Firmware Version context
------	--	------------------------------------

B.3 DVS-G116W02-4GF

Address Offset	Data Type	Format	Description	Note
System Information	on			-
0x0001	1 word	HEX	Product Code	Product Code (8A13H)
0x0003	1 word		Firmware Version Hi byte = major Lo byte = minor	Ex: V1.00 High byte = 0x01 Lo byte = 0x00
0x0004	2 word	HEX	Firmware Release Date Word 0 Hi byte = day Word 0 Lo byte = clock Word 1 Hi byte = year Word 1 Lo byte = month	Ex: 20120918, PM9:00 Word 0 = 0x1215, Word 1 = 0x0C09
0x0010	20 words	ASCII	Vendor Name	"Delta Electronics, Inc." Word 0 Hi byte = 'D' Word 0 Lo byte = 'e' Word 1 Hi byte = 'I' Word 1 Lo byte = 't' Word 2 Hi byte = 'a' Word 2 Lo byte = '' Word 3 Lo byte = 'E' Word 3 Lo byte = 'E' Word 4 Lo byte = 'c' Word 5 Hi byte = 'c' Word 5 Lo byte = 'r' Word 6 Hi byte = 'o' Word 6 Lo byte = 'n' Word 7 Lo byte = 'c' Word 7 Lo byte = 's' Word 8 Lo byte = ', ' Word 9 Hi byte = 'I' Word 10 Hi byte = 'n' Word 10 Lo byte = 'c' Word 11 Lo byte = '\0'

0x0030	20 words	ASCII	Product Name	"DVS-G116W02-4GF" Word 0 Hi byte = 'D' Word 0 Lo byte = 'V' Word 1 Hi byte = 'S' Word 1 Lo byte = 'S' Word 2 Hi byte = 'G' Word 2 Lo byte = '1' Word 3 Hi byte = '1' Word 3 Lo byte = '6' Word 4 Hi byte = 'W' Word 4 Lo byte = '0' Word 5 Hi byte = '2' Word 5 Lo byte = '2' Word 6 Hi byte = '4' Word 6 Lo byte = 'F' Word 7 Hi byte = 'N'
0x0050	20 words	ASCII	Serial No.	
0x0070	3 words	ASCII	Ethernet MAC Address	Ex: MAC = $00:11:22:33:44:55$ Word 0 Hi byte = $0x00$ Word 0 Lo byte = $0x11$ Word 1 Hi byte = $0x22$ Word 1 Lo byte = $0x33$ Word 2 Hi byte = $0x44$ Word 2 Lo byte = $0x55$
0x0073	2 words	HEX	Ethernet IP Address	Ex: IP = 192.168.1.5 Word 0 = 0xC0A8 Word 1 = 0x0105
0x0075	2 words	HEX	Ethernet Netmask	Ex: Mask = 255.255.255.0 Word 0 = 0xFFFF Word 1 = 0xFF00
0x0077	2 words	HEX	Ethernet Gateway IP Address	Ex: IP = 192.168.1.1 Word 0 = 0xC0A8 Word 1 = 0x0101
0x0080	1 word	HEX	Power 1 Status	0x0000: OFF 0x0001: ON
0x0081	1 word	HEX	Power 2 Status	0x0000: OFF 0x0001: ON
0x0090	1 word	HEX	DO 1 Status	0x0000: OFF 0x0001: ON
0x00A0	1 word	HEX	DI 1 Status	0x0000: OFF 0x0001: ON
Port Information				
0x1000 ~ 0x100B	1 word	HEX	Port 1 to 12 Status	0x0000: Link down 0x0001: Link up 0x0002: Disable
0x1100 ~ 0x110B	1 word	HEX	Port 1 to 12 Physical Status	0x0000: 10M,Half 0x0001: 10M,Full 0x0002: 100M,Half 0x0003: 100M,Full 0x0004: 1G,Full

0x1200 ~ 0x120B	1 word	HEX	Port 1 to 12 Flow Control	0x0000: OFF 0x0001: ON
0x1300 ~ 0x130B	1 word	HEX	Port 1 to 12 MDI/MDIX Setting	0x0000: Auto 0x0001: MDI 0x0002: MDIX
0x1500 ~ 0x150B	1 word	HEX	Port 1 to 12 bandwidth overload	0x0000: OFF 0x0001: Port X bandwidth overload
0x1600 ~ 0x160B	1 word	HEX	Port 1 to 12 loopback detection port status	0x0000: OFF 0x0001: loopback detected
0x1A00 ~ 0x1C30	20 words	HEX	Port 1 to 12 Description EX: 10/100/1000TX,RJ45 Word 0 Hi byte = '1' Word 0 Lo byte = '0' Word 1 Hi byte = '/' Word 2 Hi byte = '0' Word 2 Lo byte = '0' Word 3 Lo byte = '1' Word 3 Lo byte = '1' Word 4 Lo byte = '0' Word 5 Hi byte = '0' Word 5 Lo byte = '0' Word 5 Lo byte = 'T' Word 6 Hi byte = 'X' Word 6 Lo byte = 'X' Word 7 Lo byte = 'X' Word 8 Hi byte = '4' Word 8 Lo byte = '\0' Word 9 Lo byte = '\0'	Note: 10/100TX,RJ45 10/1000,SFP
Packet Information				
0x2000 ~ 0x2017	2 words	HEX	Port 1 to 12 Tx Packets	Ex: Port 1 Tx Packet Amount = 0x33221100 0x2000 = 0x3322 0x2001 = 0x1100
0x2100 ~ 0x2117	2 words	HEX	Port 1 to 12 Rx Packets	Ex: Port 1 Rx Packet Amount = 0x33221100 0x2100 = 0x3322 0x2101 = 0x1100
0x2200 ~ 0x2217	2 words	HEX	Port 1 to 12 Tx Error Packets	Ex: Port 1 Tx Packet Amount = 0x33221100 0x2200 = 0x3322 0x2201 = 0x1100
0x2300 ~ 0x2317	2 words	HEX	Port 1 to 12 Rx Error Packets	Ex: Port 1 Rx Packet Amount = 0x33221100 0x2300 = 0x3322 0x2301 = 0x1100
Redundancy Inform	nation (If	the spec	for Proprietary Ring is comp	leted, we will add this function)
0x3000	1 word	HEX	Redundancy Protocol	0x0000: None 0x0001: RSTP/STP

0x3001	1 word	HEX	RSTP Root	0x0000: Not Root 0x0001: Root
0x3100 ~ 0x310B	1 word	HEX	RSTP Port 1 to 12 Status	0x0000: Port Disable 0x0001: Not RSTP Port 0x0002: Link Down 0x0003: Discarding 0x0004: Learning 0x0005: Forwarding
0x3200	1 word	HEX	RING mode	0x00: None (Disable) 0x01: Master 0x02: Slave
0x3201	1 word	HEX	RING State	RING function is disable: 0x00: None RING Mode is Master: 0x00: Discover 0x01: Monitor 0x02: Fault RING Mode is Slave: 0x00: Forwarding 0x01: Hold 0x02: Fault
0x3300	1 word	HEX	COUPING Mode	0x00: None (Disable) 0x01: Head 0x02: Tail
0x3301	1 word	HEX	COUPING State	COUPING mode is disable: 0x00: None COUPING mode is Head: 0x00: Monitor 0x01: Fault 0x02: Link-Up 0x03: Hold COUPING mode is Tail 0x00: Discover 0x01: Monitor 0x02: Fault
0x3400	1 word	HEX	CHAIN Mode	0x00: None (Disable) 0x01: Head 0x02: Tail 0x03: Member
0x3401	1 word	HEX	CHAIN State	CHAIN mode is disable: 00: None CHAIN mode is Head: 0x00: Discover 0x01: Monitor 0x02: Fault 0x03: Holde CHAIN mode is Member: 0x00: Forwarding 0x01: Hold CHAIN mode is Tail: 0x00: Discover 0x01: Monitor 0x02: Fault

SPF DDM Information						
0x4000 ~ 0x4003	1 word	HEX	Port 1 to Port 4 Port No.			
0x4100 ~ 0x4127	20 words	HEX	Port 1 to Port 4 Model Name	SFP DDM Memory Map EEPROM Serial Interface (2-Wire Address A0) Data Address: 40-55 Example: LCP-1250B4QDRH Word 0 Hi byte = 'L' Word 1 Lo byte = 'C' Word 1 Lo byte = 'P' Word 2 Hi byte = '1' Word 2 Lo byte = '2' Word 3 Hi byte = '5' Word 3 Lo byte = '0' Word 4 Hi byte = 'B' Word 4 Lo byte = 'A' Word 5 Hi byte = 'Q' Word 5 Lo byte = 'Q' Word 6 Hi byte = 'R' Word 7 Hi byte = '\0' Word 7 Lo byte ='\0'		
0x4200 ~ 0x4203	2 words	HEX	Port 1 to Port 2 Temperature Word 0 = Temperature MSB Word 1 = Temperature LSB	Real Time Diagnostic (2-Wire Address A2h) Data Address: 96-97		
0x4300 ~ 0x4303	2 words	HEX	Port 1 to Port 2 Voltage Word 0 = Vcc MSB Word 1 = Vcc LSB	Real Time Diagnostic (2-Wire Address A2h) Data Address: 98-99		
0x4400 ~ 0x4403	2 words	HEX	Port 1 to Port 2 TX Power Word 0 = TX Power MSB Word 1 = TX Power LSB	Real Time Diagnostic (2-Wire Address A2h) Data Address: 102-103		
0x4500 ~ 0x4503	2 words	HEX	Port 1 to Port 2 RX Power Word 0 = RX Power MSB Word 1 = RX Power LSB	Real Time Diagnostic(2-Wire Address A2h) Data Address: 104-105		
0x4600 ~ 0x4601	1 words	HEX	Port 1 to Port 2 Link Status	0x0000: Link down 0x0001: Link up		
Alarm						
0x5000	1 word	HEX	Switch colde start alarm	0x0000: OFF 0x0001: ON 0xFFFF: Disable		
0x5001	1 word	HEX	Switch warm start alarm	0x0000: OFF 0x0001: ON		
0x5004	1 word	HEX	Power state on alarm	0x0000: OFF 0x0001: ON		
0x5005	1 word	HEX	Power state off alarm	0x0000: OFF 0x0001: ON		
0x5006	1 word	HEX	DI on alarm	0x0000: OFF 0x0001: ON		
0x5007	1 word	HEX	DI off alarm	0x0000: OFF 0x0001: ON		

0x5008	1 word	HEX	authentication failure alarm	0x0000: OFF 0x0001: ON
0x5009	1 word	HEX	dot1d Bridge New Root alarm	0x0000: OFF 0x0001: ON
0x500A	1 word	HEX	dot1d Bridge Topology Changed alarm	0x0000: OFF 0x0001: ON
0x500B	1 word	HEX	LLDP Remote Tables Change alarm	0x0000: OFF 0x0001: ON
0x500C	1 word	HEX	Configuartion Changed alarm	0x0000: OFF 0x0001: ON
0x500D	1 word	HEX	Firmware update alarm	0x0000: OFF 0x0001: ON
0x500E	1 word	HEX	IP changed alarm	0x0000: OFF 0x0001: ON
0x500F	1 word	HEX	Passward changed alarm	0x0000: OFF 0x0001: ON
0x5010	1 word	HEX	RING failure	0x0000: OFF 0x0001: ON
0x5011	1 word	HEX	RING backup path is activated	0x0000: OFF 0x0001: ON
0x5012	1 word	HEX	RING returns to health status	0x0000: OFF 0x0001: ON
0x5013	1 word	HEX	CHAIN failure	0x0000: OFF 0x0001: ON
0x5014	1 word	HEX	CHAIN backup path is activated	0x0000: OFF 0x0001: ON
0x5015	1 word	HEX	CHAIN returns to HEALTH status	0x0000: OFF 0x0001: ON
0x5016	1 word	HEX	COUPLING failure	0x0000: OFF 0x0001: ON
0x5017	1 word	HEX	COUPLING backup path is activated	0x0000: OFF 0x0001: ON
0x5018	1 word	HEX	COUPLING returns to HEALTH status	0x0000: OFF 0x0001: ON
0x5100 ~ 0x5101	1 word	HEX	SFP Port 1 to Port 2 DDM Failure - Temp alarm	0x0000: OFF 0x0001: ON
0x5110 ~ 0x5111	1 word	HEX	SFP Port 1 to Port 2 DDM Failure - Voltage	0x0000: OFF 0x0001: ON
0x5120 ~ 0x5121	1 word	HEX	SFP Port 1 to Port 2 DDM Failure - Bias	0x0000: OFF 0x0001: ON
0x5130 ~ 0x5131	1 word	HEX	SFP Port 1 to Port 2 DDM Failure - TX Power	0x0000: OFF 0x0001: ON
0x5140 ~ 0x5141	1 word	HEX	SFP Port 1 to Port 2 DDM Failure - RX Power	0x0000: OFF 0x0001: ON
IABU Internal Data	(0x2B)			
Device ID Code	Object ID	Length	Description	
0x01	0x00	23 bytes	Vendor Name "Delta Electronics, Inc."	
	0x01	32 bytes	Product Name "DVS-G116W02-2GF"	

0x02	Firmware Version Major.Minor Example: Major = 1, Min 2, Length = 4 Data byte 0: "31" Data byte 1: "." Data byte 2: "30" Data byte 3: "32"	nor = Length by Firmware Version context	
------	--	--	--



Appendix C EtherNet/IP

Table of Contents

C-2	DVS-G106W02-2GF	C.1
C-13	DVS-G112W02-4GF	C.2
C-23	DVS-G116W02-4GF	C.3

C.1 DVS-G106W02-2GF

Identity Object (0x01)							
Class Attributes							
Attr ID	Access Rule	Name	Data Type	Description of Attribute			
1	Get	Revision	UINT	Revision of this object			
2	Get	Max Instance	UINT	Maximum instance number of this object			
Instance A	Attributes						
Attr ID	Access Rule	Name	Data Type	Description of Attribute			
1	Get	Vendor ID	UINT	799, Vendor ID of "Delta Electronics, Inc.			
2	Get	Device Type	UINT	0x2C, " Managed Ethernet Switch Device".			
3	Get	Product Code	UINT	Product code of device (8ABBH)			
	Get	Revision	STRUCT of:	Revision of the Identity Object			
4		Major	USINT				
		Minor	USINT				
5	Get	Status	WORD	0, Not used			
6	Get	Serial Number	UDINT	Serial number of device			
7	Get	Product Name	STRING	"DVS-G106W02-2GF", Product name of device.			
Common	Services						
Service	Need in Ir	nplementation		Description of Convise			
Code	Class	Instance	Service Name	Description of Service			
0x01		V	Get_Attribute_All	Returns a predefined listing of this objects attributes.			
0x05		V	Reset	Invokes the reset service for the device.			
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.			

Message Router Object (0x02)				
Class Attr	ibutes			
Attr ID	Access Rule	Name	Data Type	Description of Attribute
1	Get	Revision	UINT	Revision of this object
Instance A	Attributes			
Attr ID	Access Rule	Name	Data Type	Description of Attribute
2	Get	Number Available	UINT	Maximum number of CIP connections supported
3	Get	Number Active	UINT	Number of CIP connections currently used by system components
Common Services				
Service Code	Need in Ir	nplementation		Description of Service
	Class	Instance		

0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.
Assembly	y Object (0x04)		
Class Att	ributes			
Attr ID	Access Rule	Name	Data Type	Description of Attribute
1	Get	Revision	UINT	Revision of this object
Instance	Attributes			
Attr ID	Access Rule	Name	Data Type	Description of Attribute
3	Get/Set	Data	ARRAY of BYTE	
4	Get	Size	UINT	
Instance				
Instance Number	Size (bytes)	Name	Туре	Description of Attribute
1	18	Power Source and Link Status	Inupt	Refer to Base Switch Object Attr ID 4 Byte 0: Power Source Status (Least Significant Byte) Byte 1: Power Source Status (Most Significant Byte) Refer to Base Switch Object Attr ID 8 Byte 2-5: Global Link Status DWORD 0 Byte 6-9: Global Link Status DWORD 1 Byte 10-13: Global Link Status DWORD 2 Byte 14-17: Global Link Status DWORD 3
2	16	Global Admin State	Input	Refer to Base Switch Object Attr ID 7 Byte 0-3: Global Admin Status DWORD 0 Byte 4-7: Global Admin Status DWORD 1 Byte 8-11: Global Admin Stauts DWORD 2 Byte 12-15: Global Admin Status DWORD 3
3	2	Contact Status	Input	Refer to Base Switch Object Attr ID 10 Byte 0: Contact Status (Least Signifcant Byte) Byte 1: Contact Status (Most Signifcant Byte)
50	16	TBD	Output	ТВО
64	76	Device Status	Input	Refer to I/O Assembly - Input
Common	Services			
Service	Need in I	mplementation		Description of Comission
Code	Class	Instance	Service Name	Description of Service
0x0E	V	v	Get_Attribute_Single	Returns the contents of the specified attribute.
0x10		v	Set_Attribute_Single	Modifies an attribute value.

I/O Assembly					
Direction	Name		Size	Description	
	Power Source Status		WORD	Refer to Base Switch Object Attr ID 4 Power Source Status (Least Significant Byte) Power Source Status (Most Significant Byte)	
	Global Link Status		ARRAY OF DWORD	Refer to Base Switch Object Attr ID 8 Global Link Status DWORD 0 Global Link Status DWORD 1 Global Link Stauts DWORD 2 Global Link Status DWORD 3	
	Global Admin State		ARRAY OF DWORD	Refer to Base Switch Object Attr ID 7 Global Admin Status DWORD 0 Global Admin Status DWORD 1 Global Admin Stauts DWORD 2 Global Admin Status DWORD 3	
Input	Contact S	tatus	WORD	Refer to Base Switch Object Attr ID 10	
	AlarmStau	uts	ULINT	Refer to Delta IES Object Attr 11	
	Bandwidth	n overload	ULINT	Refer to Delta IES Object Attr 12	
	Loopback status	detection port	ULINT	Refer to Delta IES Object Attr 13	
	SFP Failure		ARRAY OF USINT	Refer to Delta IES Object Attr 14	
	Redundancy Protocol		USINT	Refer to Delta IES Object Attr 15	
	RSTP Roo	ot	USINT	Refer to Delta IES Object Attr 16	
	Redundar	ncy - RING Mode	USINT	Refer to Delta IES Object Attr 17	
	Redundar	ncy - Ring State	USINT	Refer to Delta IES Object Attr 18	
	Redundancy - CHAIN Mode		USINT	Refer to Delta IES Object Attr 19	
	Redundancy - CHAIN Statue		USINT	Refer to Delta IES Object Attr 20	
	Redundancy - COUPING Mode		USINT	Refer to Delta IES Object Attr 21	
	Redundancy - COUPING State		USINT	Refer to Delta IES Object Attr 22	
Output	Port Admin State		ARRAY OF DWORD	Refer to Base Switch Object Attr ID 7 Global Admin Status DWORD 0 Global Admin Status DWORD 1 Global Admin Stauts DWORD 2 Global Admin Status DWORD 3	
Connectio	on Manage	er Object (0x06)			
Class Attr	ributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Revision	UINT	Revision of this object	
Instance A	Attributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
Common	Services				
Service	Need in In	nplementation	Service Name	Description of Service	

Code	Class	Instance		
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.
0x4E		V	Forward_Close	Closes a connection
0x54		V	Forward_Open	Open a connection

Port Object (0xF4)				
Class Attr	ibutes			
Attr ID	Access Rule	Name	Data Type	Description of Attribute
1	Get	Revision	UINT	Revision of this object
2	Get	Max Instance	UINT	Maximum instance number
3	Get	Num Instances	UINT	Number of port currently instantiated
8	Get	Entry Port	UINT	Returns the port through which this request entered the device
0		Port Instance Info	ARRAY of STRUCT of	
9	Get	Port Type	UINT	Enumerateds the type of port
		Port Number	UINT	CIP port number associated with this port
Instance /	Attributes			
Attr ID	Access Rule	Name	Data Type	Description of Attribute
1	Get	Port Type	UINT	Enumerates the type. (4 = EthetNet/IP)
2	Get	Port Number	UINT	CIP port number associated with this port
		Link Object	STRUCT of	
3	Get	Path Length	UINT	Number of 16 bit words in the following path
		Link Path	Padded EPATH	Logical path segments that identify the object for this port
4	Get	Port Name	SHORT_STRING	String which names the physical network port
7	Get	Node Address	Padded EPATH	Node number of this device on port
Common	Services			
Service	Need in Ir	nplementation	Sanviaa Nama	Description of Service
Code	Class	Instance	Service Name	Description of Service
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.

TCP/IP Interface Object (0xF5)					
Class Attr	ibutes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Revision	UINT	Revision of this object	
Instance Attributes					
Attr ID	Access Rule	Name	Data Type	Description of Attribute	

С

1	Get	Status	DWORD	Interface status 0 = The Interface Configuration attribute has not been configured. 1 = The Interface Configuration attribute contains configuration obtained from BOOTP, DHCP or non-volatile storage.
2	Get	Configuration Capability	DWORD	Interface capability Bit 0: BOOTP Clinet 1 (TRUE) shall indicate the device is capable of obtaining its network configuration via BOOTP. Bit 1: DNS Client 1 (TRUE) shall indicate the device is capable of resolving host names by querying a DNS server. Bit 2: DHCP Client 1 (TRUE) shall indicate the device is capable of obtaining its network configuration via DHCP. Bit 3: DHCP-DNS Update Shall be 0 Bit 4: Configuration Settable 1 (TRUE) shall indicate the Interface Configuration attribute is settable.
3	Get/Set	Configuration Control	DWORD	Interface control flags Bit 0-3: Configuraiton Method 0 = The device shall use statically-assigned IP configuration values. 1 = The device shall obtain its interface configuration values via BOOTP. 2 = The device shall obtain its interface configuration values via DHCP. 3-15 = Reserved for future use. Bit 4: DNS Enable If 1 (TRUE), the device shall resolve host names by querying a DNS server.
		Physical Link Object	STRUCT of	Path to physical link object
4	Get	Path size	UINT	Size of Path
		Path	Padded EPATH	Logical segments identifying the physical link object
		Interface Configuration	STRUCT of	TCP/IP network interface configuration.
		IP Address	UDINT	The device's IP address
5	Get/Set	Network Mask	UDINT	The device's network mask
Ĭ		Gateway Address	UDINT	Default gateway address
		Name Server	UDINT	Primary name server
		Namer Server 2	UDINT	Secondary name server

		Domain Name	STRING	Default domain name Note: ASCII characters. Maximum length is 48 characters. Shall be padded to an even number of characters (pad not included in length).
6	Get/Set	Host Name	STRING	Host Name (Note: ASCII characters. Maximum length is 64 characters. Shall be padded to an even number of characters (pad not included in length).
Common	Services			
Service	Need in Implementation		Service Norme	Description of Convise
Code	Class	Instance	Service Marile	Description of Service
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.
0x10		v	Set_Attribute_Single	Modifies an attribute value.

Ethernet Link Object (0xF6)					
Class Attr	ibutes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Revision	UINT	Revision of this object	
2	Get	Max Instance	UINT	Maximum instance number of an object currently created in this class level of the device.	
3	Get	Number of Instances	UINT	Number of object instances currently created at this class level of the device. (The value is mapping the number of ports in Switch device)	
Instance A	Attributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Interface Speed	UDINT	Interface speed currently in use Speed in Mbps (e.g., 0, 10, 100, 1000, etc.)	
2	Get	Interface Flags	DWORD	Interface status flags	
3	Get	Physical Address	ARRAY of 6 USINTs	MAC layer address	
		Interface Counters	STRUCT of:		
		In Octets	UDINT	Octets received on the interface	
4	Get	In Ucast Packets	UDINT	Unicast packets received on the interface	
		In Nucast Packets	UDINT	Non-unicast packets received on the interface	
		In Discards	UDINT	Inbound packets received on the interface but discarded	

С

		In Errors	UDINT	Inbound packets that contain errors (does not include In Discards)	
		In Unknown Protos	UDINT	Inbound packets with unknown protocol	
		Out Octets	UDINT	Octets sent on the interface	
		Out Ucast Packets	UDINT	Unicast packets sent on the interface	
		Out Nucast Packets	UDINT	Non-unicast packets sent on the interface	
		Out Discards	UDINT	Outbound packets discarded	
		Out Errors	UDINT	Outbound packets that contain errors	
		Media Counters	STRUCT of:	Media-specific counters	
		Alignmenet Errors	UDINT	Frames received that are not an integral number of octets in length	
		FCS Errors	UDINT	Frames received that do not pass the FCS check	
		Single Collisions	UDINT	Successfully transmitted frames which experienced exactly one collision	
		Multiple Collisons	UDINT	Successfully transmitted frames which experienced more than one collision	
		SQE Test Errors	UDINT	Number of times SQE test error message is generated	
		Deferred Transmissions	UDINT	Frames for which first transmission attempt is delayed because the medium is busy	
5	Get	Late Collisions	UDINT	Number of times a collision is detected later than 512 bit-times into the transmission of a packet	
		Excessive Collisions	UDINT	Frames for which transmission fails due to excessive collisions	
		MAC Transmit Errors	UDINT	Frames for which transmission fails due to an internal MAC sublayer transmit error	
		Carrier Sense Errors	UDINT	Times that the carrier sense condition was lost or never asserted when attempting to transmit a frame	
		Frame Too Long	UDINT	Frames received that exceed the maximum permitted frame size	
		MAC Receive Errors	UDINT	Frames for which reception on an interface fails due to an internal MAC sublayer receive error	
10	Get	Interface Label	SHORT_STRING	Human readable identification	
Common Services					
Service	Need in Ir	nplementation	Service Name	Description of Service	
Code	Class	Instance			
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.	

Base Switch Object (0x51)				
Class Attr	ibutes	-	-	
Attr ID	Access Rule	Name	Data Type	Description of Attribute
1	Get	Revision	UINT	Revision of this object. The current value assigned to this values is 1
Instance A	Attributes			
Attr ID	Access Rule	Name	Data Type	Description of Attribute
1	Get	Device Up Time	UDINT	Time since device was powered up (s) (Note: the value is 32-bit)
2	Get	Total port count	UDINT	Number of physical ports
3	Get	System Firmware Version	SHORT_STRING	Human readable representation of System Firmware Version (Note: ASCII characters, max length is 32 bytes)
4	Get	Power Source	WORD	Status of switch power source Bit 0-1: Power Source 1 Bit 2-3: Power Source 2 Bit 14-15: Power Source 8 00 = Not Present (power source not present in switch) 01 = Not Powered (power source present but not powered) 10 = Faulted (power source present but faulted) 11 = Powered and ok (power source present, powered and OK)
5	Get	Port Mask Size	UINT	Number of DWORDs in port array attributes (Minimum = 4, supporting 128 ports)
7	Get / Set	Global Port Admin State	ARRAY OF DWORD	Port Admin Status (Note: Size of array = attribute 5) DWORD[0]: Port 0 - 31 admin status DWORD[1]: Port 32 - 63 admin status DWORD[2]: Port 64 - 95 admin status DWORD[3]: Port 96 - 127 admin status 0 = Port (or Interface) Disabled 1 = Port (or Interface) Enabled
8	Get	Global Port Link Status	ARRAY OF DWORD	Port Link Status (Note: Size of array = attribute 5) DWORD[0]: Port 0 - 31 link status DWORD[1]: Port 32 - 63 link status DWORD[2]: Port 64 - 95 link status DWORD[3]: Port 96 - 127 link status 0 = Link inactive (Down) 1 = Link Active (UP)

10	Get	Constact Status	WORD	Switch Contact Closure (DI) Bit 0-1: Switch Contact 1 (DI 1) Bit 2-3: Switch Contact 2 (DI 2) Other Reserved (should be 0) 00 = Switch Contact not support/presed 01 = Switch Contact is OPEN (OFF) 10 = Switch Contact is CLOSED (ON) 11 = Reserved
Common	Services			
Service	Need in Ir	nplementation	Service Name	Description of Service
Code	Class	Instance		
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.
0x10		V	Set_Attribute_Single	Modifies an attribute value.

Delta IES Object (0x64)					
Class Att	ributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Revision	UINT	Revision of this object	
Instance	Attributes	<u> </u>	-		
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get/Set	Reboot Device	USINT	Reboot device Set 0x0001 to reboot device, and return to 0x0000 if reboot is completed.	
2	Get/Set	Reset Device	USINT	Reset to defualt Set 0x0001 to reset configuration, and return to 0x0000 if reset is completed.	
3	Get	Firmware Release Date	UDINT	Ex: 20120918, PM9:00 Word 0 = 0x1215, Word 1 = 0x0C09	
4	Get	Relay Output Status	WORD	Relay Output Status Bit 0-1: Relay Output 1 status Bit 2-3: Relay Output 2 status Other Reserved (should be 0) 00 = Digital output not support/presed 01 = Switch Contact is OPEN (OFF) 10 = Switch Contact is CLOSED (ON) 11 = Reserved	
11	Get	AlarmStauts	ULINT	Alarm Status (0 is ON, 1 is OFF) Bit 0: switch code start Bit 1: switch warm start Bit 2: power1 state on->off Bit 3: power1 state off->on Bit 4: power2 state on->off Bit 5: power2 state off->on Bit 6: power3 state on->off Bit 7: power3 state off->on Bit 8: DI1 state on->off	

				Bit 9: DI1 state off->on Bit 6: DI1 state off->on- Bit 7: DI1 state off->on- Bit 8: DI2 state off->on- Bit 9: DI2 state off->on- Bit 10: authentication failure Bit 11: dot1d Bridge New Root Bit 12: dot1d Bridge Topology Changed Bit 13: LLDP Remote Tables Changed Bit 14: configuration changed Bit 15: firmware update Bit 16: IP changed Bit 17: passward changed
12	Get	Bandwidth overload	ULINT	Bit 0: Port 0 state Bit 1: Port 1 state Bit 63: Port 63 state 0 = OFF or not support 1 = Bandwidth overload
13	Get	Loopback detection port status	ULINT	Bit 0: Port 0 state Bit 1: Port 1 state Bit 63: Port 63 state 0 = OFF or not support 1 = Loopback detected
14	Get	SFP Failure	ARRAY OF USINT	Support 8 port. Byte 0: SFP port 1 Failure state Byte 1: SFP port 2 Failure state Byte 7: SFP port 8 Failure state Bit 0: SFP port present 0 = Not present, 1 = present Bit 1: Temp alram state 0 = ON, 1 = OFF Bit 2: Voltage alarm state 0 = ON, 1 = OFF Bit 3: Bias alarm state 0 = ON, 1 = OFF Bit 4: TX Power state 0 = ON, 1 = OFF Bit 5: RX Power state 0 = ON, 1 = OFF Bit 5: RX Power state 0 = ON, 1 = OFF Bit 6-7: Reserved
15	Get	Redundancy Protocol	USINT	0x00: None 0x01: RSTP/STP
16	Get	RSTP Root	USINT	0x0000: Not Root 0x0001: Root
17	Get	Redundancy - RING Mode	USINT	0x00: None (Disable) 0x01: Master 0x02: Slave

18	Get	Redundancy - Ring State	USINT	RING function is disable: 0x00: None RING Mode is Master: 0x00: Discover 0x01: Monitor 0x02: Fault RING Mode is Slave: 0x00: Forwarding 0x01: Hold 0x02: Fault
19	Get	Redundancy - CHAIN Mode	USINT	0x00: None (Disable) 0x01: Head 0x02: Tail 0x03: Member
20	Get	Redundancy - CHAIN State	USINT	CHAIN mode is disable: 00: None CHAIN mode is Head: 0x00: Discover 0x01: Monitor 0x02: Fault 0x03: Holde CHAIN mode is Member: 0x00: Forwarding 0x01: Hold CHAIN mode is Tail: 0x00: Discover 0x01: Monitor 0x02: Fault
21	Get	Redundancy - COUPING Mode	USINT	0x00: None (Disable) 0x01: Head 0x02: Tail
22	Get	Redundancy - COUPING State	USINT	COUPING mode is disable: 0x00: None COUPING mode is Head: 0x00: Monitor 0x01: Fault 0x02: Link-Up 0x03: Hold COUPING mode is Tail 0x00: Discover 0x01: Monitor 0x02: Fault
Common	Services			
Service Code	Need in Ir	nplementation	Service Name	Description of Service
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.
0x10		V	Set_Attribute_Single	Modifies an attribute value.

C.2 DVS-G112W02-4GF

Identity Object (0x01)					
Class Attr	ibutes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Revision	UINT	Revision of this object	
2	Get	Max Instance	UINT	Maximum instance number of this object	
Instance A	Attributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Vendor ID	UINT	799, Vendor ID of "Delta Electronics, Inc.	
2	Get	Device Type	UINT	0x2C, " Managed Ethernet Switch Device".	
3	Get	Product Code	UINT	Product code of device (8A15H)	
	Get	Revision	STRUCT of:	Revision of the Identity Object	
4		Major	USINT		
		Minor	USINT		
5	Get	Status	WORD	0, Not used	
6	Get	Serial Number	UDINT	Serial number of device	
7	Get	Product Name	STRING	"DVS-G112W02-4GF", Product name of device.	
Common	Services				
Service	Need in Ir	nplementation		Description of Convise	
Code	Class	Instance	Service Name	Description of Service	
0x01		v	Get_Attribute_All	Returns a predefined listing of this objects attributes.	
0x05		V	Reset	Invokes the reset service for the device.	
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.	

Message Router Object (0x02)					
Class Attr	ibutes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Revision	UINT	Revision of this object	
Instance A	Attributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
2	Get	Number Available	UINT	Maximum number of CIP connections supported	
3	Get	Number Active	UINT	Number of CIP connections currently used by system components	
Common	Services				
Service	Need in Ir	nplementation	Sonvice Name	Departmention of Sorvice	
Code	Class	Instance	Service Marrie		
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.	

Assembly	Assembly Object(0x04)						
Class Attr	ributes						
Attr ID	Access Rule	Name	Data Type	Description of Attribute			
1	Get	Revision	UINT	Revision of this object			
Instance /	Instance Attributes						
Attr ID	Access Rule	Name	Data Type	Description of Attribute			
3	Get/Set	Data	ARRAY of BYTE				
4	Get	Size	UINT				
Instance							
Instance Number	Size (bytes)	Name	Туре	Description of Attribute			
1	18	Power Source and Link Status	Inupt	Refer to Base Switch Object Attr ID 4 Byte 0: Power Source Status (Least Significant Byte) Byte 1: Power Source Status (Most Significant Byte) Refer to Base Switch Object Attr ID 8 Byte 2-5: Global Link Status DWORD 0 Byte 6-9: Global Link Status DWORD 1 Byte 10-13: Global Link Status DWORD 2 Byte 14-17: Global Link Status DWORD 3			
2	16	Global Admin State	Input	Refer to Base Switch Object Attr ID 7 Byte 0-3: Global Admin Status DWORD 0 Byte 4-7: Global Admin Status DWORD 1 Byte 8-11: Global Admin Stauts DWORD 2 Byte 12-15: Global Admin Status DWORD 3			
3	2	Contact Status	Input	Refer to Base Switch Object Attr ID 10 Byte 0: Contact Status (Least Signifcant Byte) Byte 1: Contact Status (Most Signifcant Byte)			
50	16	TBD	Output	TBD			
64	76	Device Status	Input	Refer to I/O Assembly - Input			
Common	Services						
Service	Need in Ir	mplementation	Service Name	Description of Service			
Code	Class	Instance					
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.			
0x10		V	Set_Attribute_Single	Modifies an attribute value.			

I/O Assembly					
Direction	Name	Size	Description		

				Refer to Base Switch Object Attr ID 4 Power Source Status (Least Significant
	Power So	urce Status	WORD	Byte) Power Source Status (Most Significant
	Global Link Status		ARRAY OF DWORD	Byte) Refer to Base Switch Object Attr ID 8 Global Link Status DWORD 0 Global Link Status DWORD 1 Global Link Stauts DWORD 2 Global Link Status DWORD 3
	Global Admin State		ARRAY OF DWORD	Refer to Base Switch Object Attr ID 7 Global Admin Status DWORD 0 Global Admin Status DWORD 1 Global Admin Stauts DWORD 2 Global Admin Status DWORD 3
	Contact S	tatus	WORD	Refer to Base Switch Object Attr ID 10
loout	AlarmStau	uts	ULINT	Refer to Delta IES Object Attr 11
Input	Bandwidth	n overload	ULINT	Refer to Delta IES Object Attr 12
	Loopback status	detection port	ULINT	Refer to Delta IES Object Attr 13
	SFP Failu	re	ARRAY OF USINT	Refer to Delta IES Object Attr 14
	Redundar	ncy Protocol	USINT	Refer to Delta IES Object Attr 15
	RSTP Root		USINT	Refer to Delta IES Object Attr 16
	Redundar	ncy - RING Mode	USINT	Refer to Delta IES Object Attr 17
	Redundancy - Ring State		USINT	Refer to Delta IES Object Attr 18
	Redundancy - CHAIN Mode		USINT	Refer to Delta IES Object Attr 19
	Redundancy - CHAIN Statue		USINT	Refer to Delta IES Object Attr 20
	Redundancy - COUPING Mode		USINT	Refer to Delta IES Object Attr 21
	Redundancy - COUPING State		USINT	Refer to Delta IES Object Attr 22
Dutput	Port Admin State		ARRAY OF DWORD	Refer to Base Switch Object Attr ID 7 Global Admin Status DWORD 0 Global Admin Status DWORD 1 Global Admin Stauts DWORD 2 Global Admin Status DWORD 3
Connectic	on Manage	er Object (0x06)		
Class Attr	ibutes			
Attr ID	Access Rule	Name	Data Type	Description of Attribute
1	Get	Revision	UINT	Revision of this object
nstance A	Attributes			
Attr ID	Access Rule	Name	Data Type	Description of Attribute
Common	Services			
Service	Need in In	nplementation	Comico Norre	
Code	Class	Instance	Service Name	Description of Service

0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.
0x4E		V	Forward_Close	Closes a connection
0x54		V	Forward_Open	Open a connection

Port Object (0xF4)					
Class Attr	ibutes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Revision	UINT	Revision of this object	
2	Get	Max Instance	UINT	Maximum instance number	
3	Get	Num Instances	UINT	Number of port currently instantiated	
8	Get	Entry Port	UINT	Returns the port through which this request entered the device	
0	Cat	Port Instance Info	ARRAY of STRUCT of		
9	Get	Port Type	UINT	Enumerateds the type of port	
		Port Number	UINT	CIP port number associated with this port	
Instance /	Attributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Port Type	UINT	Enumerates the type. (4 = EthetNet/IP)	
2	Get	Port Number	UINT	CIP port number associated with this port	
		Link Object	STRUCT of		
3	Get	Path Length	UINT	Number of 16 bit words in the following path	
		Link Path	Padded EPATH	Logical path segments that identify the object for this port	
4	Get	Port Name	SHORT_STRING	String which names the physical network port	
7	Get	Node Address	Padded EPATH	Node number of this device on port	
Common	Services				
Service	Need in Ir	nplementation	Sonvico Namo	Description of Sonvice	
Code	Class	Instance			
0x0E	v	V	Get_Attribute_Single	Returns the contents of the specified attribute.	

TCP/IP Interface Object (0xF5)						
Class Attributes						
Attr ID	Access Rule	Name	Data Type	Description of Attribute		
1	Get	Revision	UINT	Revision of this object		
Instance Attributes						
Attr ID	Access Rule	Name	Data Type	Description of Attribute		
1	Get	Status	DWORD	Interface status 0 = The Interface Configuration attribute has not been configured. 1 = The Interface Configuration attribute contains configuration obtained from BOOTP, DHCP or non-volatile storage.		
---	---------	-----------------------------	--------------	---		
2	Get	Configuration Capability	DWORD	Interface capability Bit 0: BOOTP Clinet 1 (TRUE) shall indicate the device is capable of obtaining its network configuration via BOOTP. Bit 1: DNS Client 1 (TRUE) shall indicate the device is capable of resolving host names by querying a DNS server. Bit 2: DHCP Client 1 (TRUE) shall indicate the device is capable of obtaining its network configuration via DHCP. Bit 3: DHCP-DNS Update Shall be 0 Bit 4: Configuration Settable 1 (TRUE) shall indicate the Interface Configuration attribute is settable.		
3	Get/Set	Configuration Control	DWORD	Interface control flags Bit 0-3: Configuraiton Method 0 = The device shall use statically-assigned IP configuration values. 1 = The device shall obtain its interface configuration values via BOOTP. 2 = The device shall obtain its interface configuration values via DHCP. 3-15 = Reserved for future use. Bit 4: DNS Enable If 1 (TRUE), the device shall resolve host names by querying a DNS server.		
		Physical Link Object	STRUCT of	Path to physical link object		
4	Get	Path size	UINT	Size of Path		
		Path	Padded EPATH	Logical segments identifying the physical link object		
		Interface Configuration	STRUCT of	TCP/IP network interface configuration.		
		IP Address	UDINT	The device's IP address		
		Network Mask	UDINT	The device's network mask		
		Gateway Address	UDINT	Default gateway address		
5	Get/Set	Name Server	UDINT	Primary name server		
		Namer Server 2	UDINT	Secondary name server		
		Domain Name	STRING	Default domain name Note: ASCII characters. Maximum length is 48 characters. Shall be padded to an even number of characters (pad not included in length).		

6	Get/Set	Host Name	STRING	Host Name (Note: ASCII characters. Maximum length is 64 characters. Shall be padded to an even number of characters (pad not included in length).	
Common	Common Services				
Service	Need in Implementation		Sarvice Name	Department of Convice	
Code	Class	Instance	Service Name		
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.	
0x10		V	Set_Attribute_Single	Modifies an attribute value.	

Ethernet Link Object (0xF6)							
Class Attr	Class Attributes						
Attr ID	Access Rule	Name	Data Type	Description of Attribute			
1	Get	Revision	UINT	Revision of this object			
2	Get	Max Instance	UINT	Maximum instance number of an object currently created in this class level of the device.			
3	Get	Number of Instances	UINT	Number of object instances currently created at this class level of the device. (The value is mapping the number of ports in Switch device)			
Instance A	Attributes						
Attr ID	Access Rule	Name	Data Type	Description of Attribute			
1	Get	Interface Speed	UDINT	Interface speed currently in use Speed in Mbps (e.g., 0, 10, 100, 1000, etc.)			
2	Get	Interface Flags	DWORD	Interface status flags			
3	Get	Physical Address	ARRAY of 6 USINTs	MAC layer address			
		Interface Counters	STRUCT of:				
		In Octets	UDINT	Octets received on the interface			
		In Ucast Packets	UDINT	Unicast packets received on the interface			
		In Nucast Packets	UDINT	Non-unicast packets received on the interface			
4	Get	In Discards	UDINT	Inbound packets received on the interface but discarded			
		In Errors	UDINT	Inbound packets that contain errors (does not include In Discards)			
		In Unknown Protos	UDINT	Inbound packets with unknown protocol			
		Out Octets	UDINT	Octets sent on the interface			
		Out Ucast Packets	UDINT	Unicast packets sent on the interface			

		Out Nucast Packets	UDINT	Non-unicast packets sent on the interface		
		Out Discards	UDINT	Outbound packets discarded		
		Out Errors	UDINT	Outbound packets that contain errors		
		Media Counters	STRUCT of:	Media-specific counters		
		Alignmenet Errors	UDINT	Frames received that are not an integral number of octets in length		
		FCS Errors	UDINT	Frames received that do not pass the FCS check		
		Single Collisions	UDINT	Successfully transmitted frames which experienced exactly one collision		
		Multiple Collisons	UDINT	Successfully transmitted frames which experienced more than one collision		
		SQE Test Errors	UDINT	Number of times SQE test error message is generated		
		Deferred Transmissions	UDINT	Frames for which first transmission attempt is delayed because the medium is busy		
5	Get	Late Collisions	UDINT	Number of times a collision is detected later than 512 bit-times into the transmission of a packet		
		Excessive Collisions	UDINT	Frames for which transmission fails due to excessive collisions		
		MAC Transmit Errors	UDINT	Frames for which transmission fails due to an internal MAC sublayer transmit error		
		Carrier Sense Errors	UDINT	Times that the carrier sense condition was lost or never asserted when attempting to transmit a frame		
		Frame Too Long	UDINT	Frames received that exceed the maximum permitted frame size		
		MAC Receive Errors	UDINT	Frames for which reception on an interface fails due to an internal MAC sublayer receive error		
10	Get	Interface Label	SHORT_STRING	Human readable identification		
Common	Common Services					
Service	Need in Ir	nplementation	Service Name	Description of Service		
Code	Class	Instance				
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.		

Base Switch Object (0x51)				
Class Attr	ibutes			
Attr ID	Access Rule	Name	Data Type	Description of Attribute
1	Get	Revision	UINT	Revision of this object. The current value assigned to this values is 1
Instance Attributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute

-					
1	Get	Device Up Time	UDINT	Time since device was powered up (s) (Note: the value is 32-bit)	
2	Get	Total port count	UDINT	Number of physical ports	
3	Get	System Firmware Version	SHORT_STRING	Human readable representation of System Firmware Version (Note: ASCII characters, max length is 32 bytes)	
4	Get	Power Source	WORD	Status of switch power source Bit 0-1: Power Source 1 Bit 2-3: Power Source 2 Bit 14-15: Power Source 8 00 = Not Present (power source not present in switch) 01 = Not Powered (power source present but not powered) 10 = Faulted (power source present but faulted) 11 = Powered and ok (power source present, powered and OK)	
5	Get	Port Mask Size	UINT	Number of DWORDs in port array attributes (Minimum = 4, supporting 128 ports)	
7	Get / Set	Global Port Admin State	ARRAY OF DWORD	Port Admin Status (Note: Size of array = attribute 5) DWORD[0]: Port 0 - 31 admin status DWORD[1]: Port 32 - 63 admin status DWORD[2]: Port 64 - 95 admin status DWORD[3]: Port 96 - 127 admin status 0 = Port (or Interface) Disabled 1 = Port (or Interface) Enabled	
8	Get	Global Port Link Status	ARRAY OF DWORD	Port Link Status (Note: Size of array = attribute 5) DWORD[0]: Port 0 - 31 link status DWORD[1]: Port 32 - 63 link status DWORD[2]: Port 64 - 95 link status DWORD[3]: Port 96 - 127 link status 0 = Link inactive (Down) 1 = Link Active (UP)	
10	Get	Constact Status	WORD	Switch Contact Closure (DI) Bit 0-1: Switch Contact 1 (DI 1) Bit 2-3: Switch Contact 2 (DI 2) Other Reserved (should be 0) 00 = Switch Contact not support/presed 01 = Switch Contact is OPEN (OFF) 10 = Switch Contact is CLOSED (ON) 11 = Reserved	
Common Services					
Service	Need in Ir	nplementation	Service Name	Description of Service	
Code	Class	Instance			
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.	
0x10		V	Set_Attribute_Single	Modifies an attribute value.	

Delta IES	Delta IES Object(0x64)				
Class Att	ributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Revision	UINT	Revision of this object	
Instance A	Attributes	i			
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get/Set	Reboot Device	USINT	Reboot device Set 0x0001 to reboot device, and return to 0x0000 if reboot is completed.	
2	Get/Set	Reset Device	USINT	Reset to defualt Set 0x0001 to reset configuration, and return to 0x0000 if reset is completed.	
3	Get	Firmware Release Date	UDINT	Ex: 20120918, PM9:00 Word 0 = 0x1215, Word 1 = 0x0C09	
4	Get	Relay Output Status	WORD	Relay Output Status Bit 0-1: Relay Output 1 status Bit 2-3: Relay Output 2 status Other Reserved (should be 0) 00 = Digital output not support/presed 01 = Switch Contact is OPEN (OFF) 10 = Switch Contact is CLOSED (ON) 11 = Reserved	
11	Get	AlarmStauts	ULINT	Alarm Status (0 is ON, 1 is OFF) Bit 0: switch code start Bit 1: switch warm start Bit 2: power1 state on->off Bit 3: power1 state off->on Bit 4: power2 state off->on Bit 5: power3 state on->off Bit 5: power3 state on->off Bit 7: power3 state off->on Bit 8: DI1 state off->on Bit 6: DI1 state off->on Bit 6: DI1 state off->on Bit 7: DI1 state off->on Bit 8: DI2 state off->on Bit 8: DI2 state off->on Bit 8: DI2 state off->on Bit 9: DI2 state off->on Bit 10: authentication failure Bit 11: dot1d Bridge New Root Bit 12: dot1d Bridge Topology Changed Bit 13: LLDP Remote Tables Changed Bit 15: firmware update Bit 16: IP changed Bit 17: passward changed	
12	Get	Bandwidth overload	ULINT	Bit 0: Port 0 state Bit 1: Port 1 state Bit 63: Port 63 state 0 = OFF or not support 1 = Bandwidth overload	

13	Get	Loopback detection port status	ULINT	Bit 0: Port 0 state Bit 1: Port 1 state Bit 63: Port 63 state 0 = OFF or not support 1 = Loopback detected
14	Get	SFP Failure	ARRAY OF USINT	Support 8 port. Byte 0: SFP port 1 Failure state Byte 1: SFP port 2 Failure state Byte 7: SFP port 8 Failure state Bit 0: SFP port present 0 = Not present, 1 = present Bit 1: Temp alram state 0 = ON, 1 = OFF Bit 2: Voltage alarm state 0 = ON, 1 = OFF Bit 3: Bias alarm state 0 = ON, 1 = OFF Bit 4: TX Power state 0 = ON, 1 = OFF Bit 5: RX Power state 0 = ON, 1 = OFF Bit 5: RX Power state 0 = ON, 1 = OFF Bit 6-7: Reserved
15	Get	Redundancy Protocol	USINT	0x00: None 0x01: RSTP/STP
16	Get	RSTP Root	USINT	0x0000: Not Root 0x0001: Root
17	Get	Redundancy - RING Mode	USINT	0x00: None (Disable) 0x01: Master 0x02: Slave
18	Get	Redundancy - Ring State	USINT	RING function is disable: 0x00: None RING Mode is Master: 0x00: Discover 0x01: Monitor 0x02: Fault RING Mode is Slave: 0x00: Forwarding 0x01: Hold 0x02: Fault
19	Get	Redundancy - CHAIN Mode	USINT	0x00: None (Disable) 0x01: Head 0x02: Tail 0x03: Member

20	Get	Redundancy - CHAIN State	USINT	CHAIN mode is disable: 00: None CHAIN mode is Head: 0x00: Discover 0x01: Monitor 0x02: Fault 0x03: Holde CHAIN mode is Member: 0x00: Forwarding 0x01: Hold CHAIN mode is Tail: 0x00: Discover 0x01: Monitor 0x02: Fault
21	Get	Redundancy - COUPING Mode	USINT	0x00: None (Disable) 0x01: Head 0x02: Tail
22	Get	Redundancy - COUPING State	USINT	COUPING mode is disable: 0x00: None COUPING mode is Head: 0x00: Monitor 0x01: Fault 0x02: Link-Up 0x03: Hold COUPING mode is Tail 0x00: Discover 0x01: Monitor 0x02: Fault
Common	Services			
Service Code	Need in Ir Class	nplementation Instance	Service Name	Description of Service
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.
0x10		V	Set_Attribute_Single	Modifies an attribute value.

C.3 DVS-G116W02-4GF

• Support Function Code 0x03 and 0x04

Identity O	dentity Object (0x01)				
Class Attr	ibutes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Revision	UINT	Revision of this object	
2	Get	Max Instance	UINT	Maximum instance number of this object	
Instance A	Attributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Vendor ID	UINT	799, Vendor ID of "Delta Electronics, Inc. "	

2	Get	Device Type	UINT	0x2C, " Managed Ethernet Switch Device".
3	Get	Product Code	UINT	Product code of device (8A13H)
		Revision	STRUCT of:	Revision of the Identity Object
4	Get	Major	USINT	
		Minor	USINT	
5	Get	Status	WORD	0, Not used
6	Get	Serial Number	UDINT	Serial number of device
7	Get	Product Name	STRING	"DVS-G116W02-4GF", Product name of device.
Common	Services			
Service	Need in Ir	nplementation		Description of Conving
Code	Class	Instance	Service Marine	Description of Service
0x01		V	Get_Attribute_All	Returns a predefined listing of this objects attributes.
0x05		V	Reset	Invokes the reset service for the device.
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.

Message Router Object(0x02)						
Class Attr	Class Attributes					
Attr ID	Access Rule	Name	Data Type	Description of Attribute		
1	Get	Revision	UINT	Revision of this object		
Instance A	Instance Attributes					
Attr ID	Access Rule	Name	Data Type	Description of Attribute		
2	Get	Number Available	UINT	Maximum number of CIP connections supported		
3	Get	Number Active	UINT	Number of CIP connections currently used by system components		
Common Services						
Service	Need in Implementation		O amila a Nama	Description of Sorvice		
Code	Class	Instance	Service Marrie			
0x0E	V	v	Get_Attribute_Single	Returns the contents of the specified attribute.		

Assembly	Assembly Object (0x04)				
Class Attributes					
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Revision	UINT	Revision of this object	
Instance	Attributes	i			
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
3	Get/Set	Data	ARRAY of BYTE		
4	Get	Size	UINT		
Instanco					

Instance

Instance Number	Size (bytes)	Name	Туре	Description of Attribute
1	18	Power Source and Link Status	Inupt	Refer to Base Switch Object Attr ID 4 Byte 0: Power Source Status (Least Significant Byte) Byte 1: Power Source Status (Most Significant Byte) Refer to Base Switch Object Attr ID 8 Byte 2-5: Global Link Status DWORD 0 Byte 6-9: Global Link Status DWORD 1 Byte 10-13: Global Link Status DWORD 2 Byte 14-17: Global Link Status DWORD 3
2	16	Global Admin State	Input	Refer to Base Switch Object Attr ID 7 Byte 0-3: Global Admin Status DWORD 0 Byte 4-7: Global Admin Status DWORD 1 Byte 8-11: Global Admin Stauts DWORD 2 Byte 12-15: Global Admin Status DWORD 3
3	2	Contact Status	Input	Refer to Base Switch Object Attr ID 10 Byte 0: Contact Status (Least Signifcant Byte) Byte 1: Contact Status (Most Signifcant Byte)
50	16	TBD	Output	TBD
64	76	Device Status	Input	Refer to I/O Assembly - Input
Common	Services			
Service Code	Need in Ir Class	nplementation	Service Name	Description of Service
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.
0x10		v	Set_Attribute_Single	Modifies an attribute value.

I/O Assembly				
Direction	Name	Size	Description	
	Power Source Status	WORD	Refer to Base Switch Object Attr ID 4 Power Source Status (Least Significant Byte) Power Source Status (Most Significant Byte)	
Input	Global Link Status	ARRAY OF DWORD	Refer to Base Switch Object Attr ID 8 Global Link Status DWORD 0 Global Link Status DWORD 1 Global Link Stauts DWORD 2 Global Link Status DWORD 3	

	Global Admin State	ARRAY OF DWORD	Refer to Base Switch Object Attr ID 7 Global Admin Status DWORD 0 Global Admin Status DWORD 1 Global Admin Stauts DWORD 2 Global Admin Status DWORD 3
	Contact Status	WORD	Refer to Base Switch Object Attr ID 10
	AlarmStauts	ULINT	Refer to Delta IES Object Attr 11
	Bandwidth overload	ULINT	Refer to Delta IES Object Attr 12
	Loopback detection port status	ULINT	Refer to Delta IES Object Attr 13
	SFP Failure	ARRAY OF USINT	Refer to Delta IES Object Attr 14
	Redundancy Protocol	USINT	Refer to Delta IES Object Attr 15
	RSTP Root	USINT	Refer to Delta IES Object Attr 16
	Redundancy - RING Mode	USINT	Refer to Delta IES Object Attr 17
	Redundancy - Ring State	USINT	Refer to Delta IES Object Attr 18
	Redundancy - CHAIN Mode	USINT	Refer to Delta IES Object Attr 19
	Redundancy - CHAIN Statue	USINT	Refer to Delta IES Object Attr 20
	Redundancy - COUPING Mode	USINT	Refer to Delta IES Object Attr 21
	Redundancy - COUPING State	USINT	Refer to Delta IES Object Attr 22
Output	Port Admin State	ARRAY OF DWORD	Refer to Base Switch Object Attr ID 7 Global Admin Status DWORD 0 Global Admin Status DWORD 1 Global Admin Stauts DWORD 2 Global Admin Status DWORD 3

Connection Manager Object (0x06)					
Class Attri	Class Attributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Revision	UINT	Revision of this object	
Instance A	Instance Attributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
Common S	Services				
Service	Need in Ir	nplementation	Oamiaa Nama	Description of Convise	
Code	Class	Instance	Service Marile		
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.	
0x4E		V	Forward_Close	Closes a connection	
0x54		V	Forward_Open	Open a connection	
Instance A Attr ID Common S Service Code 0x0E 0x4E 0x54	Access Rule Services Need in Ir Class	Name nplementation Instance V V	Data Type Service Name Get_Attribute_Single Forward_Close Forward_Open	Description of Attribute Description of Service Returns the contents of the specified attribute. Closes a connection Open a connection	

Port Object (0xF4)				
Class Attributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute
1	Get	Revision	UINT	Revision of this object

2	Get	Max Instance	UINT	Maximum instance number
3	Get	Num Instances	UINT	Number of port currently instantiated
8	Get	Entry Port	UINT	Returns the port through which this request entered the device
		Port Instance Info	ARRAY of STRUCT of	
9	Get	Port Type	UINT	Enumerateds the type of port
		Port Number	UINT	CIP port number associated with this port
Instance A	Attributes			·
Attr ID	Access Rule	Name	Data Type	Description of Attribute
1	Get	Port Type	UINT	Enumerates the type. (4 = EthetNet/IP)
2	Get	Port Number	UINT	CIP port number associated with this port
	Get	Link Object	STRUCT of	
3		Path Length	UINT	Number of 16 bit words in the following path
		Link Path	Padded EPATH	Logical path segments that identify the object for this port
4	Get	Port Name	SHORT_STRING	String which names the physical network port
7	Get	Node Address	Padded EPATH	Node number of this device on port
Common	Services			·
Service	Need in I	mplementation	Carries Name	Description of Convine
Code	Class	Instance	Service Name	Description of Service
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.

TCP/IP Interface Object (0xF5)					
Class Attr	Class Attributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Revision	UINT	Revision of this object	
Instance A	Attributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute	
1	Get	Status	DWORD	Interface status 0 = The Interface Configuration attribute has not been configured. 1 = The Interface Configuration attribute contains configuration obtained from BOOTP, DHCP or non-volatile storage.	

5	Get/Set	Interface Configuration IP Address Network Mask Gateway Address Name Server Namer Server 2	STRUCT of UDINT UDINT UDINT UDINT UDINT	link object TCP/IP network interface configuration. The device's IP address The device's network mask Default gateway address Primary name server Secondary name server Default domain name
5	Get/Set	Interface Configuration IP Address Network Mask Gateway Address Name Server Namer Server 2	STRUCT of UDINT UDINT UDINT UDINT UDINT	link object TCP/IP network interface configuration. The device's IP address The device's network mask Default gateway address Primary name server Secondary name server
5	Get/Set	Interface Configuration IP Address Network Mask Gateway Address Name Server	STRUCT of UDINT UDINT UDINT UDINT	link object TCP/IP network interface configuration. The device's IP address The device's network mask Default gateway address Primary name server
		Interface Configuration IP Address Network Mask Gateway	STRUCT of UDINT UDINT UDINT	link object TCP/IP network interface configuration. The device's IP address The device's network mask Default gateway address
		Interface Configuration IP Address Network Mask	STRUCT of UDINT UDINT	link object TCP/IP network interface configuration. The device's IP address The device's network mask
		Interface Configuration	STRUCT of	link object TCP/IP network interface configuration.
		Interface		link object
1	1	Path	Padded EPATH	Logical segments identifying the physical
4	Gel	Path size		SIZE OF Path
Л	Oct	Object		Path to physical link object
		Physical Link		Path to physical link chiest
3	Get/Set	Configuration Control	DWORD	Bit 0-3: Configuration Method 0 = The device shall use statically-assigned IP configuration values. 1 = The device shall obtain its interface configuration values via BOOTP. 2 = The device shall obtain its interface configuration values via DHCP. 3-15 = Reserved for future use. Bit 4: DNS Enable If 1 (TRUE), the device shall resolve host
2	Get	Configuration Capability	DWORD	Bit 0: BOOTP Clinet 1 (TRUE) shall indicate the device is capable of obtaining its network configuration via BOOTP. Bit 1: DNS Client 1 (TRUE) shall indicate the device is capable of resolving host names by querying a DNS server. Bit 2: DHCP Client 1 (TRUE) shall indicate the device is capable of obtaining its network configuration via DHCP. Bit 3: DHCP-DNS Update Shall be 0 Bit 4: Configuration Settable 1 (TRUE) shall indicate the Interface Configuration attribute is settable.

Code	Class	Instance		
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.
0x10		V	Set_Attribute_Single	Modifies an attribute value.

Ethernet	Ethernet Link Object (0xF6)					
Class At	tributes					
Attr ID	Access Rule	Name	Data Type	Description of Attribute		
1	Get	Revision	UINT	Revision of this object		
2	Get	Max Instance	UINT	Maximum instance number of an object currently created in this class level of the device.		
3	Get	Number of Instances	UINT	Number of object instances currently created at this class level of the device. (The value is mapping the number of ports in Switch device)		
Instance	Attribute	S				
Attr ID	Access Rule	Name	Data Type	Description of Attribute		
1	Get	Interface Speed	UDINT	Interface speed currently in use Speed in Mbps (e.g., 0, 10, 100, 1000, etc.)		
2	Get	Interface Flags	DWORD	Interface status flags		
3	Get	Physical Address	ARRAY of 6 USINTs	MAC layer address		
		Interface Counters	STRUCT of:			
		In Octets	UDINT	Octets received on the interface		
		In Ucast Packets	UDINT	Unicast packets received on the interface		
		In Nucast Packets	UDINT	Non-unicast packets received on the interface		
		In Discards	UDINT	Inbound packets received on the interface but discarded		
4	Get	In Errors	UDINT	Inbound packets that contain errors (does not include In Discards)		
		In Unknown Protos	UDINT	Inbound packets with unknown protocol		
		Out Octets	UDINT	Octets sent on the interface		
		Out Ucast Packets	UDINT	Unicast packets sent on the interface		
		Out Nucast Packets	UDINT	Non-unicast packets sent on the interface		
		Out Discards	UDINT	Outbound packets discarded		
		Out Errors	UDINT	Outbound packets that contain errors		

C-29

С

		Media Counters	STRUCT of:	Media-specific counters
		Alignmenet Errors	UDINT	Frames received that are not an integral number of octets in length
		FCS Errors	UDINT	Frames received that do not pass the FCS check
		Single Collisions	UDINT	Successfully transmitted frames which experienced exactly one collision
		Multiple Collisons	UDINT	Successfully transmitted frames which experienced more than one collision
		SQE Test Errors	UDINT	Number of times SQE test error message is generated
_	Cat	Deferred Transmissions	UDINT	Frames for which first transmission attempt is delayed because the medium is busy
5	Get	Late Collisions	UDINT	Number of times a collision is detected later than 512 bit-times into the transmission of a packet
		Excessive Collisions	UDINT	Frames for which transmission fails due to excessive collisions
		MAC Transmit Errors	UDINT	Frames for which transmission fails due to an internal MAC sublayer transmit error
		Carrier Sense Errors	UDINT	Times that the carrier sense condition was lost or never asserted when attempting to transmit a frame
		Frame Too Long	UDINT	Frames received that exceed the maximum permitted frame size
		MAC Receive Errors	UDINT	Frames for which reception on an interface fails due to an internal MAC sublayer receive error
10	Get	Interface Label	SHORT_STRING	Human readable identification
Common	Services			
Service	Need in Ir	mplementation	Convice Norme	Departmention of Convice
Code	Class	Instance	Service Name	
0x0E	V	v	Get_Attribute_Single	Returns the contents of the specified attribute.

Base Switch Object (0x51)				
Class Attributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute
1	Get	Revision	UINT	Revision of this object. The current value assigned to this values is 1
Instance Attributes				
Attr ID	Access Rule	Name	Data Type	Description of Attribute
1	Get	Device Up Time	UDINT	Time since device was powered up (s) (Note: the value is 32-bit)
2	Get	Total port count	UDINT	Number of physical ports

3	Get	System Firmware Version	SHORT_STRING	Human readable representation of System Firmware Version (Note: ASCII characters, max length is 32 bytes)	
4	Get	Power Source	WORD	Status of switch power source Bit 0-1: Power Source 1 Bit 2-3: Power Source 2 Bit 14-15: Power Source 8 00 = Not Present (power source not present in switch) 01 = Not Powered (power source present but not powered) 10 = Faulted (power source present but faulted) 11 = Powered and ok (power source present, powered and OK)	
5	Get	Port Mask Size	UINT	Number of DWORDs in port array attributes (Minimum = 4, supporting 128 ports)	
7	Get / Set	Global Port Admin State	ARRAY OF DWORD	Port Admin Status (Note: Size of array = attribute 5) DWORD[0]: Port 0 - 31 admin status DWORD[1]: Port 32 - 63 admin status DWORD[2]: Port 64 - 95 admin status DWORD[3]: Port 96 - 127 admin status 0 = Port (or Interface) Disabled 1 = Port (or Interface) Enabled	
8	Get	Global Port Link Status	ARRAY OF DWORD	Port Link Status (Note: Size of array = attribute 5) DWORD[0]: Port 0 - 31 link status DWORD[1]: Port 32 - 63 link status DWORD[2]: Port 64 - 95 link status DWORD[3]: Port 96 - 127 link status 0 = Link inactive (Down) 1 = Link Active (UP)	
10	Get	Constact Status	WORD	Switch Contact Closure (DI) Bit 0-1: Switch Contact 1 (DI 1) Bit 2-3: Switch Contact 2 (DI 2) Other Reserved (should be 0) 00 = Switch Contact not support/presed 01 = Switch Contact is OPEN (OFF) 10 = Switch Contact is CLOSED (ON) 11 = Reserved	
Common Services					
Service	Need in Ir	nplementation	Service Name	Description of Service	
Code	Class	Instance		Returns the contents of the specified	
0x0E	V	V	Get_Attribute_Single	attribute.	
0x10		V	Set_Attribute_Single	Modifies an attribute value.	

Delta IES Object (0x64)

Class Attributes

Attr ID	Access Rule	Name	Data Type	Description of Attribute
1	Get	Revision	UINT	Revision of this object
Instance A	Attributes			
Attr ID	Access Rule	Name	Data Type	Description of Attribute
1	Get/Set	Reboot Device	USINT	Reboot device Set 0x0001 to reboot device, and return to 0x0000 if reboot is completed.
2	Get/Set	Reset Device	USINT	Reset to defualt Set 0x0001 to reset configuration, and return to 0x0000 if reset is completed.
3	Get	Firmware Release Date	UDINT	Ex: 20120918, PM9:00 Word 0 = 0x1215, Word 1 = 0x0C09
4	Get	Relay Output Status	WORD	Relay Output Status Bit 0-1: Relay Output 1 status Bit 2-3: Relay Output 2 status Other Reserved (should be 0) 00 = Digital output not support/presed 01 = Switch Contact is OPEN (OFF) 10 = Switch Contact is CLOSED (ON) 11 = Reserved
11	Get	AlarmStauts	ULINT	Alarm Status (0 is ON, 1 is OFF) Bit 0: switch code start Bit 1: switch warm start Bit 2: power1 state on->off Bit 3: power1 state off->on Bit 4: power2 state off->on Bit 5: power2 state off->on Bit 6: power3 state off->on Bit 7: power3 state off->on Bit 8: DI1 state on->off Bit 9: DI1 state off->on Bit 6: DI1 state off->on Bit 6: DI1 state off->on Bit 7: DI1 state off->on Bit 8: DI2 state off->on Bit 9: DI2 state off->on Bit 10: authentication failure Bit 11: dot1d Bridge New Root Bit 12: dot1d Bridge Topology Changed Bit 13: LLDP Remote Tables Changed Bit 14: configuration changed Bit 15: firmware update Bit 17: passward changed
12	Get	Bandwidth overload	ULINT	Bit 0: Port 0 state Bit 1: Port 1 state Bit 63: Port 63 state 0 = OFF or not support 1 = Bandwidth overload

13	Get	Loopback detection port status	ULINT	Bit 0: Port 0 state Bit 1: Port 1 state Bit 63: Port 63 state 0 = OFF or not support 1 = Loopback detected
14	Get	SFP Failure	ARRAY OF USINT	Support 8 port. Byte 0: SFP port 1 Failure state Byte 1: SFP port 2 Failure state Byte 7: SFP port 8 Failure state Bit 0: SFP port present 0 = Not present, 1 = present Bit 1: Temp alram state 0 = ON, 1 = OFF Bit 2: Voltage alarm state 0 = ON, 1 = OFF Bit 3: Bias alarm state 0 = ON, 1 = OFF Bit 4: TX Power state 0 = ON, 1 = OFF Bit 5: RX Power state 0 = ON, 1 = OFF Bit 5: RX Power state 0 = ON, 1 = OFF Bit 6-7: Reserved
15	Get	Redundancy Protocol	USINT	0x00: None 0x01: RSTP/STP
16	Get	RSTP Root	USINT	0x0000: Not Root 0x0001: Root
17	Get	Redundancy - RING Mode	USINT	0x00: None (Disable) 0x01: Master 0x02: Slave
18	Get	Redundancy - Ring State	USINT	RING function is disable: 0x00: None RING Mode is Master: 0x00: Discover 0x01: Monitor 0x02: Fault RING Mode is Slave: 0x00: Forwarding 0x01: Hold 0x02: Fault
19	Get	Redundancy - CHAIN Mode	USINT	0x00: None (Disable) 0x01: Head 0x02: Tail 0x03: Member

20	Get	Redundancy - CHAIN State	USINT	CHAIN mode is disable: 00: None CHAIN mode is Head: 0x00: Discover 0x01: Monitor 0x02: Fault 0x03: Holde CHAIN mode is Member: 0x00: Forwarding 0x01: Hold CHAIN mode is Tail: 0x00: Discover 0x01: Monitor 0x02: Fault	
21	Get	Redundancy - COUPING Mode	USINT	0x00: None (Disable) 0x01: Head 0x02: Tail	
22	Get	Redundancy - COUPING State	USINT	COUPING mode is disable: 0x00: None COUPING mode is Head: 0x00: Monitor 0x01: Fault 0x02: Link-Up 0x03: Hold COUPING mode is Tail 0x00: Discover 0x01: Monitor 0x02: Fault	
Common Services					
Service Code	Need in Ir Class	nplementation	Service Name	Description of Service	
0x0E	V	V	Get_Attribute_Single	Returns the contents of the specified attribute.	
0x10		V	Set_Attribute_Single	Modifies an attribute value.	



Appendix D EDS File

Table of Contents

D.1 EDS (Electronic Data Sheet) File......D-2

D.1 EDS (Electronic Data Sheet) File

The EDS file is used to specify and describe the communication data of an EtherNet/IP switch. We provide the EDS file to help you identify the communication data or objects of the Delta managed switch, and you can use the notepad or the text editor to open the EDS file.

The EDS file list is shown below:

- File
- Device
- Device Classification
- Params
- Connection Manager
- Port
- Ethernet Link Class