

EASE1000

User's Manual

First Edition Issue Date: September 15, 2016



NOTES

- 1) The information contained herein is subject to change without notice.
- 2) Although LAPIS Semiconductor is continuously working to improve product reliability and quality, semiconductors can break down and malfunction due to various factors. Therefore, in order to prevent personal injury or fire arising from failure, please take safety measures such as complying with the derating characteristics, implementing redundant and fire prevention designs, and utilizing backups and fail-safe procedures. LAPIS Semiconductor shall have no responsibility for any damages arising out of the use of our Products beyond the rating specified by LAPIS Semiconductor.
- 3) Examples of application circuits, circuit constants and any other information contained herein are provided only to illustrate the standard usage and operations of the Products. The peripheral conditions must be taken into account when designing circuits for mass production.
- 4) The technical information specified herein is intended only to show the typical functions of the Products and examples of application circuits for the Products. No license, expressly or implied, is granted hereby under any intellectual property rights or other rights of LAPIS Semiconductor or any third party with respect to the information contained in this document; therefore LAPIS Semiconductor shall have no responsibility whatsoever for any dispute, concerning such rights owned by third parties, arising out of the use of such technical information.
- 5) The Products are intended for use in general electronic equipment (i.e. AV/OA devices, communication, consumer systems, gaming/entertainment sets) as well as the applications indicated in this document.
- 6) The Products specified in this document are not designed to be radiation tolerant.
- 7) For use of our Products in applications requiring a high degree of reliability (as exemplified below), please contact and consult with a LAPIS Semiconductor representative: transportation equipment (i.e. cars, ships, trains), primary communication equipment, traffic lights, fire/crime prevention, safety equipment, medical systems, servers, solar cells, and power transmission systems.
- 8) Do not use our Products in applications requiring extremely high reliability, such as aerospace equipment, nuclear power control systems, and submarine repeaters.
- 9) LAPIS Semiconductor shall have no responsibility for any damages or injury arising from non-compliance with the recommended usage conditions and specifications contained herein.
- 10) LAPIS Semiconductor has used reasonable care to ensure the accuracy of the information contained in this document. However, LAPIS Semiconductor does not warrant that such information is error-free and LAPIS Semiconductor shall have no responsibility for any damages arising from any inaccuracy or misprint of such information.
- 11) Please use the Products in accordance with any applicable environmental laws and regulations, such as the RoHS Directive. For more details, including RoHS compatibility, please contact a ROHM sales office. LAPIS Semiconductor shall have no responsibility for any damages or losses resulting non-compliance with any applicable laws or regulations.
- 12) When providing our Products and technologies contained in this document to other countries, you must abide by the procedures and provisions stipulated in all applicable export laws and regulations, including without limitation the US Export Administration Regulations and the Foreign Exchange and Foreign Trade Act.
- 13) This document, in part or in whole, may not be reprinted or reproduced without prior consent of LAPIS Semiconductor.

Copyright 2016 LAPIS Semiconductor Co., Ltd.

LAPIS Semiconductor Co., Ltd.

2-4-8 Shinyokohama, Kouhoku-ku,
Yokohama 222-8575, Japan
<http://www.lapis-semi.com/en/>

Table of Contents

Chapter 1 PREFACE

For Safe and Correct Operation	1
Precautions.....	1
Description of Term	4

Chapter 2 General Description

2 General Description.....	1
2.1 Product Overview	1
2.2 EASE1000 Components.....	2
2.3 Appearance	3
2.4 Terms of Use	4
2.5 Target System Requirements.....	5
2.5.1 Target System Circuit Configuration	6
2.5.1.1 Connection of RESET_N pin, P00/TEST0 pin	6
2.5.1 Target System Circuit Configuration	6
2.6 Supplying Target LSI VDD	7
2.6.1. Supplying Target LSI VDD from EASE1000	7
2.6.2 Outputting Target System Power Supply to Target LSI VDD	7
2.7 Target System Board Layout.....	8
2.7.1 Notes of Target System Board Layout.....	8

Chapter 3 START

3 START.....	1
3.1 Starting EASE1000.....	1
3.1.1 Starting Procedure	1
3.1.2 Removal Procedure	2

Chapter 4 FUNCYIONS

4 FUNCTIONS.....	1
4.1 On-chip debug function	1
4.2Flash writer function	1
4.3 Indicator	1

Chapter 5 Notes on Use of EASE1000

5 Notes on Use of EASE1000	1
5.1 About Usage Environment.....	1
5.2 About Flash Writing	1
5.3 About Cables	1

Chapter 6 Appendices

6 Appendices.....	1
6.1 EASE1000	1
6.2 EASE1000 Interface cable	1
6.3 USB cable.....	1
6.2 EASE1000 Interface Cable Appearance	2

Revision History



Revision History.....	1
-----------------------	---

Chapter1 PREFACE

For Safe and Correct Operation

This user's manual uses various terms and pictorial indications for you to use this product safely and correctly and to prevent harm to you and others and property damages. Their meanings and displays are as follows:

Meaning of term

 Warning	Incorrect handling in defiance of this display may cause death or serious injury.
 Note	Incorrect handling in defiance of this display may cause injury or property damage.

Example of pictorial indication



△ symbol indicates a risk and calls attention. In the picture, a specific note ("Electric shock hazard" in the left figure) is drawn.









● symbol forces an action and indicates the instruction. In the picture, a specific instruction ("Disconnect the power plug from outlet" in the left figure) is drawn.









○ symbol indicates a banned action. In the picture, a specific instruction ("No decomposition" in the left figure) is drawn.






Precautions

Be sure to read this page before using this product.

 Warning	
<ul style="list-style-type: none"> Do not use the product at a voltage other than specified one. It might cause fire or electric shock. 	
<ul style="list-style-type: none"> In case of an abnormal state such as reeking or abnormal odor, rapidly disconnect the power plugs of EASE1000 and any other external powers from outlet. Leaving such situation as it might cause fire or electric shock. 	
<ul style="list-style-type: none"> Do not install the product in a wet or high-humidity environment. It might cause fire or electric shock. 	
<ul style="list-style-type: none"> Do not place any object on the product. It might cause fire or electric shock. 	
<ul style="list-style-type: none"> If you awake to any failure, use caution to rapidly disconnect the power plugs of EASE1000 and any other external powers from outlet. Leaving such situation as it might cause fire or electric shock. 	

 Note	
<ul style="list-style-type: none"> Do not place the product on an unstable or slope place. It might cause falling and injury. 	
<ul style="list-style-type: none"> Do not use the product in a place with excessive vibration, electromagnetic field, or corrosive gas. It might lead to loosened or disconnected connections of various cables, causing failures. 	
<ul style="list-style-type: none"> Do not use the product under out of the operational temperature, direct sunlight, or dusty condition. It might cause fire or failure. 	
<ul style="list-style-type: none"> Be sure to use the attached cables and accessories. Other items might cause fire or failure. 	
<ul style="list-style-type: none"> Do not use the attached cables and accessories on other than this system. It might cause fire. 	

Be sure to read this page before using this product.

 Note	
<ul style="list-style-type: none">Do not apply a voltage exceeding the 5.5V to the VTref pin of the EASE1000 Interface cable. It might cause fire or failure.	
<ul style="list-style-type: none">The order of power ON and OFF needs extra attention. Incorrect order might cause fire or failure.	
<ul style="list-style-type: none">Be sure to turn off the EASE1000 before connecting or disconnecting it. Otherwise, it might cause fire or failure.	
<ul style="list-style-type: none">Be sure to turn off the EASE1000 and the user application system before connecting or disconnecting them. Otherwise, it might cause fire or failure.	

<ul style="list-style-type: none">The EASE1000 is an unfinished product and intended for research and development and for expert use in the research and development facility only. The EASE1000 is not intended for use for volume production or parts thereof.
<ul style="list-style-type: none">Do not use the EASE1000 for the final check of target LSI of operation.
<ul style="list-style-type: none">The guarantee period to the initial failure of EASE1000 is one year. The obstacle by the wrong usage and reconstruction etc. cannot be guarantee.
<ul style="list-style-type: none">The content specified herein is subject to change for improvement without notice. Therefore, when using the EASE1000, the contents of the manual should check in the newest.

Description of Term

The following shows the terms used in this user's manual and their descriptions.

Term	Description
EASE1000	It is an on-chip emulator for "ML62Q1000 series" of Lapis Semiconductor. It has a function as a writer (hereinafter referred to as flash writer) to a LSI with built-in flash memory, as well as the on-chip emulator function.
DTU8 debugger	It is software to control the on-chip emulator function of EASE1000 and is a Windows application running on the PC.
FWuEASE flash writer host program	It is software to control the flash writer function of EASE1000 and is a Windows application running on the PC.
MWuEASE flash multi writer host program	It is software to control the multi flash writer function of EASE1000 and is a Windows application running on the PC.
Target system	It is a board having a LSI to be debugged by EASE1000 or whose flash memory to be written or erased.
Host PC	It is a PC with the DTU8 debugger, FWuEASE flash writer host program, and USB driver installed.
USB cable	It is a cable to connect EASE1000 with the host PC.
Target LSI	It is LSI debugged by EASE1000.
EASE1000 interface cable	It is an interface cable to connect EASE1000 with the target system.

Chapter 2 General Description

2. General Description

2.1 Product Overview

EASE1000 is an on-chip emulator for "ML62Q1000 series" (hereinafter referred to as target LSI) of Lapis Semiconductor.

In combination with the DTU8 debugger, it provides the on-chip debug function.

Having the flash writer function as well, EASE1000 can be used as a flash writer in combination with the FWuEASE flash writer host program or MWuEASE flash multi writer host program




Figure 2-1 EASE1000 System Diagram

2.2 EASE1000 Components

The following shows the EASE1000 components.




Figure 2-2 EASE1000 Components

2.3 Appearance

The following shows the appearance diagram of EASE1000 and description of each part. In this description, a component surrounded by brackets is the name printed on the case.




Figure 2-3 EASE1000 Appearance (Top View)

- **Target interface connector (TARGET)**

A connector to connect EASE1000 with the target system. Connect the supplied EASE1000 interface cable.

- **USB connector (USB)**

A connector (Type-B mini) to connect EASE1000 with the host PC. Connect the supplied USB cable.

- **POWER indicator (POWER)**

An LED to indicate the EASE1000 state. It lights up or blinks in green.

For the relationship between the indicator light state and EASE1000 state, see "4.3 Indicator".

- **BUSY indicator (BUSY)**

An LED to indicate the EASE1000 state. It lights up or blinks in yellow.

For the relationship between the indicator light state and EASE1000 state, see "4.3 Indicator".

2.4 Terms of Use

EASE1000 should be used in an environment which meets the following conditions.

Terms of use for EASE1000	
Parameter	Description
Power supply	USB VBUS output (5 V, 500 mA) on the host PC
Usage environment	Temperature: 5 to 40 °C Relative humidity: 30 to 80% (no condensation)
Target LSI Positive power supply (VTref) voltage	Target LSI operation voltage 1.6 to 5.5 V

For an operating environment for software running on the host PC, see the following documents.

- DTU8 User's Manual
- FWuEASE Flash Writer Host Program User's Manual
- MWuEASE Flash Multi Writer Host Program User's Manual

When using EASE1000 as an on-chip emulator or flash writer, the power supply output from EASE1000 to the target LSI is as follows:

Output power supply of EASE1000	
Parameter	Description
Power supply for target LSI (3.3VOUT)	3.3 V (typ)/100 mA (max)

The power supply for the target LSI is output after debugging with target LSI by DTU8 debugger or when FWuEASE Flash Writer Host Program / MWuEASE Flash Multi Writer Host Program is in a plug state.

2.5 Target System Requirements

The target system connected with EASE1000 must meet the following requirements.

Target System requirements	
Item	Description
Interface connector	Must support the EASE1000 interface cable Must have a 14-pin 2.54 mm pitch connector (Compatible connector: HIF3FC-14PA-2.54DSA)
Target LSI Positive power supply (V_{DD}) voltage	1.6 to 5.5V (Note 1)
Power consumption (V_{Tref})	10mA

■Note 1■

- Since the target LSI positive power supply is used for the internal circuit of EASE1000, its power consumption increases when EASE1000 is in use.

Use an appropriate amount of the target system positive power supply while considering the power consumed by EASE1000.

- Do not connect EASE1000 when measure the consumption current of a target system.

The on-chip debugging circuit in target LSI influences, and consumption current increases.

The following shows the power consumption of the V_{Tref} pin used inside EASE1000.

EASE1000 V_{Tref} pin power consumption (except for transient current)	
Target LSI positive power supply (V_{DD}) voltage	Power consumption (max)
+5.5V	10mA
+3.3V	2mA

2.5.1 Target System Circuit Configuration

This section describes the circuit configuration of the target system which is necessary to connect a target LSI with EASE1000.

A pin used to connect a target LSI with EASE1000 is different depending on the specifications of the target LSI. Use an appropriate pin according to the LSI user's manual.

2.5.1.1 Connection of RESET_N pin, P00/TEST0 pin

EASE1000 use RESET_N pin and P00/TEST0 pin of target LSI.

- Do not connect the parts which RESET_N pin is fixed to a High level.

The pull-up resistance is connectable with RESET_N pin.

- When using P00/TEST0 pin, be sure to set P00 as an input mode by a application program.

If P00 is set as an output mode, it becomes impossible to use EASE1000.

2.6 Supplying Target LSI V_{DD}

2.6.1 Supplying Target LSI V_{DD} from EASE1000

EASE1000 has the pin (3.3VOUT) to output +3.3 V/100 mA (max) as a target LSI operation power supply.

When this power supply is used, the flash writer, on-chip debug emulator's application program download and software breakpoint functions are available even when the power supply voltage of the target system is set to a value outside the flash memory operation voltage range of the target LSI.




Figure 2-4 Target System Connection Example (3.3VOUT Used)



Note

When using the 3.3VOUT power supply of EASE1000, do not apply power of the target system to the V_{DD} pin of the target LSI. If both power supplies are connected, it may damage EASE 1000 or cause an electric shock or fire.

2.6.2 Outputting Target System Power Supply to Target LSI V_{DD}

The following shows a circuit configuration example for the case of outputting the target system power supply to the target LSI V_{DD} without using 3.3VOUT of EASE1000.




Figure 2-5 Target System Connection Example (3.3VOUT Not Used)

2.7 Target System Board Layout

The following shows a recommended board layout of the EASE1000 interface connector in the target system.




Figure 2-6 EASE1000 Interface Connector Recommended Board Layout

Also, design the pin assignment of the EASE1000 interface connector according to the following table.

Table 1 List of EASE1000 Interface Connector Pins

Pin No.	EASE1000 pin name	Description
1	VTref	Target LSI positive power supply
2	Vss	Target LSI negative power supply
3	N.C	Unused (This should be left unconnected.)
4	Vss	Target LSI negative power supply
5	RST_OUT/SCK	Target LSI system reset signal/communication clock
6	Vss	Target LSI negative power supply
7	SDATA	Target LSI communication data
8	Vss	Target LSI negative power supply
9	N.C	Unused (This should be left unconnected.)
10	Vss	Target LSI negative power supply
11	N.C.	Unused (This should be left unconnected.)
12	Vss	Target LSI negative power supply
13	3.3VOUT	3.3 V output pin
14	N.C	Unused (This should be left unconnected.)

2.7.1 Notes of Target System Board Layout

The following shows the notes of target system board layout

- The length of a cable connecting EASE1000 with the target system (EASE1000 interface cable) is approximately 15 cm. Locate the EASE1000 interface connector at the end of PCB if possible in order to make the cable between the EASE1000 interface connector and target LSI as short as possible.

(Compatible connector: HIF3FC-14PA-2.54DSA)

- It is recommended that the wiring connected to RST_OUT/SCK and SDATA be shielded with Vss

Chapter 3 Start

3 START

3.1 Starting EASE1000

This section describes how to start EASE1000.

For the following software running on the host PC, see the appropriate user's manual.

- DTU8 User's Manual
- FWuEASE Flash Writer Host Program User's Manual
- MWuEASE Flash Multi Writer Host Program User's Manual

3.1.1 Starting Procedure

Start EASE1000 according to the following procedure.

- (1) Connect EASE1000 with the target system through the supplied EASE1000 interface cable.
- (2) Connect EASE1000 with the host PC through the supplied USB cable.

EASE1000 is USB bus-powered. When the USB cable is connected to EASE1000, EASE1000 is turned on, and the POWER indicator on EASE1000 lights up in green.

- (3) Turn on the target system.
- (4) Start the software on the host PC.




Figure 3-1 EASE1000 System Diagram



Note

Be sure to start according to the starting procedure.
Failing to obey the procedure may damage EASE 1000 or the target system, or cause an electric shock or fire.



Note

Be sure to use the cables attached to EASE 1000.
Using different cables may damage EASE 1000 or the target system, or cause an electric shock or fire.

3.1.2 Removal Procedure

- (1) Close the software on the host PC.
- (2) Turn off the target system.
- (3) Disconnect the USB cable from EASE1000.
- (4) Disconnect the EASE1000 interface cable between EASE1000 and the target system.

**Note**

Be sure to disconnect according to the disconnecting procedure.
Failing to obey the procedure may damage EASE 1000 or the target system, or cause an electric shock or fire.

Chapter 4 FUNCTIONS

4 Functions

4.1 On-chip debug function

Connecting EASE1000 with a target LSI and using the DTU8 debugger provides the on-chip debug function.

- Application program download/display/change
- CPU status (register, Flash memory/Data memory, SFR) display/change
- Emulation (real time emulation function, step emulation function)
- Various Break

4.2 Flash writer function

Connecting EASE1000 with a target LSI and using the FWuEASE flash writer host program or MWuEASE flash multi writer host program provides the flash writer function.

4.3 Indicator

The indicator mounted on EASE1000 notifies of the EASE1000 status.

The following shows the relationship between the EASE1000 state and indicator light state.

Table 4-1 Relationship Table between EASE1000 State and Indicator Light State

EASE1000 state	Indicator type	Indicator light state
Idle state	POWER	On
	BUSY	Off
Emulating	POWER	On
	BUSY	On
Writing flash memory	POWER	On
	BUSY	On
Updating firmware	POWER	Blink (Approximately 0.25-second interval)
	BUSY	On
VTref abnormal voltage detection	POWER	On
	BUSY	Blink (Approximately 0.5-second interval)
Device driver recognition failure	POWER	Blink (Approximately 0.5-second interval)
	BUSY	Blink (Approximately 0.5-second interval)
Command execution error	POWER	Blink (Approximately 0.5-second interval)
	BUSY	Off
Communication error with target LSI	POWER	Blink (Approximately 0.5-second interval)
	BUSY	Blink (Approximately 0.5-second interval, reversed)
Firmware binary error	POWER	Blink (Approximately 0.25-second interval)
	BUSY	Blink (Approximately 0.25-second interval)
EASE1000 failure	POWER	Off
	BUSY	Off

The following describes the above EASE1000 states.

Table 4-2 State explanation of EASE1000

Idle state	Indicates the command reception waiting state from the software on the host PC to EASE1000.
Emulating	Indicates that EASE1000 is emulation state.
Writing flash memory	Indicates that flash memory writing to the target LSI is in progress.
VTref abnormal voltage detection:	Indicates that the voltage level of the target LSI positive power supply (VTref) is out of the guaranteed operation range of EASE1000. Check if there are any problems with the connection with the target system or the power supply output state.
Device driver recognition failure	Indicates that installation of the EASE1000 device driver was not recognized on the host PC when the USB cable was connected with EASE1000 (EASE1000 is powered on). Install the device driver according to the dialog box that appears on the host PC.
Command execution error	Indicates that the command response from the target LSI to EASE1000 was abnormal. Check if there are any problems with the connection with the target system or the command execution order.
Communication error with target LSI	Indicates that EASE1000 does not communicate with the target LSI correctly. Check if there are any problems with the connection with the target system.
Firmware binary error	Indicates that the data of control firmware of EASE1000 is corrupt. Update the firmware. If the error still occurs, contact your dealer or our sales representative.
Updating firmware	Indicates that the control firmware of EASE1000 is being updated. After update, EASE1000 is automatically restarted.
EASE1000 failure	Indicates that EASE1000 is broken. Rapidly disconnect the USB cable of EASE1000 and any other external powers from outlet. Leaving such situation as it might cause fire or electric shock. If there is no problem with the connection with the target system or USB cable, contact your dealer or our sales representative.

Chapter 5 Notes on Use of EASE1000

5 Notes on Use of EASE1000

5.1 Notes on Debug

- (1) About the execution cycle at the wait mode.

On wait mode, STEP execution may differ from the execution cycle of Go- execution.

The final check of an application program should use Go-execution.

- (2) About the RAM Match Break

- The timing of RAM Match Break is after executing a maximum of 3 instruction from the instruction which read/write access of RAM.

- The RAM Match Break of DSR (0F000H) cannot choose.

- (3) About the peripheral operation during Break

The operation of the following peripheral stops during Break.

An interrupt request will be in a suspension state and an interrupt will generate it after an emulation start.

The peripheral which operation stops during a break

- I²C master module
- I²C bus unit (master / slave)
- Serial unit (SIO / UART)
- General timer
- Functional timer
- External interrupts (A stop of a sampling clock)
- Low-speed time base counter
- DMA controller
- Analog module (CMP / DAC / AD converter / VLS)
- Buzzer
- CRC

- (4) About STOP / STOP-D / HALT / HALT-D

The state of STOP / STOP-D / HALT / HALT-D will become invalid the Force break is used in the state of STOP / STOP-D / HALT / HALT-D.

The state of STOP / STOP-D / HALT / HALT-D is canceled by break when Break-point is set up immediately after the instruction which sets up STOP / STOP-D / HALT / HALT-D.

- (5) About Real-Time-Watch

The Real-Time-Watch of DSR (0F000H) cannot choose.

- (6) About change of the register value of DTU8 debugger

- When high-speed clock operation is chosen for target LSI, the FHWUPT register cannot be changed in the SFR window of DTU8 debugger..
- When following peripheral is changed by DTU8 debugger, it is set as LSI before an emulation start.
 - CPU register: R0, R1, EA, PSW
 - SFR: DSR, FCON

(7) About the status window of execution time

The value of Timer displayed in the status window of DTU8 is measured by the timer of EASE1000..

Therefore, it differs from the execution time of LSI.

When a measurement period is short, an error of measurement becomes large.

5.2 About the 3.3VOUT pin

The specification of the 3.3VOUT pin is 3.3V/100mA.

When using the 3.3VOUT pin with the target system, do not exceed the range of specification.

Using exceeding specification, may damage the target system or EASE1000.

5.3 About Usage Environment

EASE1000 may be affected by the external environment of the host PC, USB cable, EASE1000 interface cable, and the target system. Please check the operation in the specific customer environment before use.

5.4 About Flash Writing

Confirm before using EASE1000 as a flash writer that the target LSI power supply voltage (V_{DD}) is within the range of the flash memory operating condition.

Also, confirm that the application program operates normally after writing.

5.5 About Cables

Be sure to use the USB cable and EASE1000 interface cable supplied as EASE1000 accessories. The operation is not guaranteed if a cable other than the EASE1000 accessories is used.



Note

Be sure to use the cables attached to EASE1000.
Using different cables may damage EASE1000 or the target system, or cause an electric shock or fire.

Chapter 6 Appendices

6. Appendices

6.1 Form information

6.1.1 EASE1000

Item	Description
Outside dimension	50 (W)×17(H)×90(D)[mm]
Weight	0.1kg

6.1.2 EASE1000 Interface cable

Item	Description
Cable length	150[mm]
Connector form	2.54mm pitch 14 pins Two-row socket

6.1.3 USB cable

Item	Description
Cable length	100[cm]
Connector form	host side : USB Type-A EASE1000 side : USB Type-B mini

6.2 EASE1000 Interface Cable Appearance




Figure 6-1 EASE1000 Interface Cable Appearance

Revision History

Revision History

Document No.	Rev.	Date	Description
FEXTEASE1000-01	1.00	September 15, 2016	First Edition