


TECHNICAL DATA


## 2373-LTC | Adapter, Lemo to Universal TC (TC)



### Product overview: 2373-LTC | Adapter, Lemo to Universal TC (TC)

Plug any thermocouple with mini-thermocouple jacks into the universal thermocouple adapter for convenient measurement with the 1523 or 1524 Reference Thermometer. The 2373 LTC lemo-to-universal thermocouple adapter connector supports reference junction compensation (RJC) with its own internal precision thermistor.

## Ordering information



### **2373-LTC**

Adapter, Lemo to Universal TC (TC)

---



**Fluke.** *Keeping your world up and running.®*

**Fluke Corporation**  
PO Box 9090, Everett, WA 98206 U.S.A.

**For more information call:**  
In the U.S.A. (800) 443-5853  
In Canada (800) 36-FLUKE  
From other countries +1 (425) 446-5500  
[www.fluke.com](http://www.fluke.com)

©2025 Fluke Corporation.  
Specifications subject to change without notice.  
02/2025

**Modification of this document is not permitted without written permission from Fluke Corporation.**