





The heat sink has mounting ears and goes with a thermal paste which make it easy to be mounted onto a NanoPC-T2/T3.







## Directions:

Before mount your heat sink to a board's IC clean the IC's surface carefully. Remove the protective covers of the thermal paste, stick the paste to the heat sink and then stick the heat sink to the IC.

Note: the heat sink is conductive. During your operation handle it carefully and don't make it touch other electronic components

